

Genel SH47

SHAD SH47 Motorcycle Top Case User Manual

Model: SH47

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup & Installation](#) [Operating Instructions](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your SHAD SH47 Motorcycle Top Case. The SHAD SH47 is a high-quality motorcycle rear case designed for secure storage and convenience. It features a 47-liter capacity, capable of holding two full-face helmets and travel accessories. Constructed from reinforced polypropylene, it offers durability and waterproof protection for your belongings. Its compact design and carbon-look finish enhance both functionality and aesthetics for various motorcycle types.

2. SAFETY INFORMATION

- Always ensure the top case is securely mounted to the motorcycle before riding.
- Do not exceed the maximum load capacity of 6 kg (13.2 lbs). Overloading can affect motorcycle stability and handling.
- Distribute weight evenly inside the case to maintain balance.
- Regularly check all mounting screws and fasteners for tightness. Loose components can lead to detachment during operation.
- Be aware that adding a top case can change the motorcycle's center of gravity and aerodynamic characteristics, especially at higher speeds or in windy conditions. Adjust your riding style accordingly.
- Ensure the case is fully closed and locked before starting your journey.
- The white reflector enhances visibility at night; keep it clean and unobstructed.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- SHAD SH47 Top Case (1 unit)
- D1B40PA Base Plate (1 unit)
- Mounting Screws and Hardware (1 set)
- Keys for Lock System (2 units)
- User Manual (This document)

4. SETUP & INSTALLATION

The SHAD SH47 top case requires a compatible motorcycle rack (not included) for installation of the D1B40PA base plate.

1. **Prepare Motorcycle Rack:** Ensure your motorcycle has a suitable rear rack for mounting a top case. If not, a compatible rack must be installed first (sold separately).
2. **Mount the Base Plate:** Position the D1B40PA base plate onto your motorcycle's rear rack. Use the provided mounting screws and hardware to securely fasten the base plate. Ensure the plate is centered and stable. *Do not overtighten screws, but ensure they are firm.*
3. **Attach the Top Case:** Align the SH47 top case with the base plate. Press down firmly until you hear a click, indicating that the case is locked onto the base plate.
4. **Verify Security:** Gently pull upwards on the top case to confirm it is securely attached to the base plate. The handle lock system should engage automatically.
5. **Lock the Case:** Use the provided key to lock the top case to prevent unauthorized removal and to secure the lid.



Image: The SHAD SH47 motorcycle top case in an open position, revealing its spacious interior designed to accommodate two full-face helmets. The case is black with a carbon look finish, and the interior shows the capacity for storage.

5. OPERATING INSTRUCTIONS

5.1 Opening and Closing the Top Case

- **To Open:** Insert the key into the lock cylinder and turn it to the unlock position. Press the release button (if applicable) or lift the lid directly.
- **To Close:** Lower the lid until it clicks securely into place. Ensure the lid is fully seated and sealed.

5.2 Locking and Unlocking

- **To Lock:** With the lid closed, turn the key to the lock position. Remove the key. This secures both the lid and the case to the base plate.
- **To Unlock:** Insert the key and turn it to the unlock position. The lid can now be opened, and the case can be detached from the base plate if desired.

5.3 Detaching the Top Case (Optional)

To remove the top case from the base plate for carrying:

1. Ensure the case is unlocked.
2. Locate the release lever or button, usually near the lock mechanism.
3. Activate the release mechanism while lifting the case upwards from the base plate.
4. Use the integrated practical carrying handle for easy transport.

5.4 Loading the Top Case

- The SH47 has a maximum load capacity of 6 kg (13.2 lbs).
- It can comfortably accommodate two full-face helmets.
- Place heavier items at the bottom and center of the case to maintain motorcycle stability.

6. MAINTENANCE

- **Cleaning:** Clean the top case with mild soap and water. Avoid abrasive cleaners or solvents that could damage the reinforced polypropylene material or the carbon-look finish. Rinse thoroughly and dry with a soft cloth.
- **Waterproof Seal:** Periodically inspect the rubber seal around the lid for any signs of wear or damage to ensure its waterproof integrity.
- **Lock Mechanism:** Lubricate the lock cylinder and hinges occasionally with a silicone-based lubricant to ensure smooth operation.
- **Mounting Hardware:** Regularly check the tightness of all screws and fasteners securing the base plate to the motorcycle rack. Retighten if necessary.
- **Reflector:** Keep the white reflector clean to ensure maximum visibility during night rides.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Top case does not lock securely.	Lid not fully closed; obstruction; lock mechanism dirty/damaged.	Ensure lid is fully closed and aligned. Check for obstructions. Clean and lubricate lock mechanism.

Problem	Possible Cause	Solution
Top case feels loose on the base plate.	Mounting screws loose; case not properly engaged with base plate.	Check and retighten all mounting screws for the base plate. Re-attach the top case, ensuring it clicks into place.
Water inside the case.	Damaged or misaligned waterproof seal; lid not fully closed.	Inspect the rubber seal for damage and proper seating. Ensure the lid is completely closed and latched.
Key is difficult to turn in the lock.	Lock cylinder dirty or dry.	Apply a small amount of silicone-based lubricant into the lock cylinder.

8. SPECIFICATIONS

Model:	SH47
Capacity:	47 Liters (accommodates two full-face helmets)
Maximum Load:	6 kg (13.2 lbs)
Dimensions (L x D x H):	57.5 cm x 31.2 cm x 42 cm (22.6 in x 12.3 in x 16.5 in)
Material:	Reinforced Polypropylene, Plastic
Color:	Black with Carbon Look finish, White Reflector
Compatibility:	Motorcycles, Scooters
Mounting System:	Requires D1B40PA Base Plate (included)

9. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation provided at the point of purchase or contact your authorized SHAD dealer. Keep your proof of purchase for any warranty claims.

For technical assistance or inquiries regarding your SHAD SH47 top case, please visit the official SHAD website or contact their customer service department.

