

SAMVIX Dynamite 2.0

Samvix Dynamite 2.0 Kosher 16GB MP3 Player Instruction Manual

Model: Dynamite 2.0

1. INTRODUCTION

The Samvix Dynamite 2.0 is a compact and durable MP3 player designed for distraction-free audio playback. It features 16GB of internal storage, expandable memory, Bluetooth 5.0 connectivity, and a robust metal body. This manual provides detailed instructions for setting up, operating, and maintaining your device.

Key Features:

- **Distraction-Free Listening:** Plays music and audio files without internet, video, or radio interruptions.
- **Expandable Storage:** 16GB internal memory with SD slot support up to 128GB.
- **Durable Design:** Extra-strong metal body with high-quality touch buttons.
- **Wireless and Built-In Audio:** Bluetooth 5.0 for wireless connection and a built-in speaker with switch.
- **Multi-Function Tools:** Includes clock, alarm, calendar, stopwatch, and internal recording with copy and paste functionality.

2. GETTING STARTED

2.1 Package Contents

Please check the package for the following items:

- Samvix Dynamite 2.0 MP3 Player
- USB Charging Cable
- Instruction Manual



Image: The Samvix Dynamite 2.0 MP3 Player shown in its retail packaging. The box highlights features like 16GB storage, Bluetooth, built-in speaker, and copy & paste system.

2.2 Charging the Device

Before first use, fully charge your Dynamite 2.0 MP3 player.

1. Connect the small end of the USB cable to the charging port on your MP3 player.
2. Connect the larger end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The device will indicate charging status on its screen.
4. Once fully charged, disconnect the cable.

2.3 Power On/Off

- **To Power On:** Press and hold the Power button until the screen lights up.
- **To Power Off:** Press and hold the Power button until the power-off prompt appears, then confirm.

3. OPERATING INSTRUCTIONS

3.1 File Transfer

You can transfer music and other audio files to your device using a USB connection.

1. Connect your MP3 player to a computer using the provided USB cable.
2. The device will appear as a removable disk drive on your computer.
3. Drag and drop your desired audio files into the appropriate folders on the MP3 player. The device supports MP3, AAC, FLAC, WAV, WMA, and OGG formats.
4. Safely eject the device from your computer before disconnecting the USB cable.

3.2 Inserting/Removing SD Card

The device supports an SD card up to 128GB for expanded storage.

- **To Insert:** Locate the SD card slot. Gently push the SD card into the slot until it clicks into place.
- **To Remove:** Gently push the SD card inward until it springs out, then pull it out.

3.3 Navigating the Interface

The Dynamite 2.0 features high-quality touch buttons for easy navigation.

- Use the directional touch buttons to move through menus and selections.
- Press the central button to confirm a selection.
- Use the Back button to return to the previous screen.

3.4 Playing Music

1. From the main menu, select 'Music' or 'Audio Files'.
2. Browse through your folders or playlists to find the desired track.
3. Select a track to begin playback.
4. Use the touch buttons to control playback (play/pause, next/previous track, volume).

3.5 Using Bluetooth Connectivity

Connect your MP3 player wirelessly to Bluetooth headphones or speakers.

1. Ensure your Bluetooth headphones/speaker are in pairing mode.
2. On the MP3 player, navigate to 'Settings' and then 'Bluetooth'.
3. Turn Bluetooth 'On' and select 'Search for Devices'.
4. Select your device from the list of available devices to pair.
5. Once paired, audio will play through the connected Bluetooth device.

3.6 Using the Built-in Speaker

The Dynamite 2.0 includes a built-in speaker for listening without headphones.

- Locate the speaker switch on the device.
- Toggle the switch to activate or deactivate the built-in speaker.

4. ADVANCED FEATURES

4.1 Audio Recording

The device supports internal audio recording from the built-in microphone or line-in.

1. Navigate to the 'Recorder' or 'Voice Recorder' function from the main menu.
2. Select recording settings (e.g., format, quality/speed). The device supports 2 formats at 4 speeds.
3. Press the Record button to start recording.
4. Press the Stop button to end recording. Recordings are saved automatically.

4.2 Time and Date Functions

The Dynamite 2.0 includes several time-keeping and organizational tools.

- **Clock:** Displays the current time.
- **Alarm Clock:** Set alarms for reminders.
- **Calendar:** View the current date and month.
- **Stopwatch:** Use for timing events.

Access these functions from the main menu or 'Tools' section.

5. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Water Resistance:** This device is not waterproof. Avoid exposure to water or high humidity.

6. TROUBLESHOOTING

6.1 Device Not Turning On

- Ensure the device is fully charged. Connect it to a power source and wait a few minutes before attempting to power on again.
- If the battery is completely drained, it may take a few minutes of charging before the device responds.

6.2 Cannot Transfer Files

- Check the USB cable connection to both the device and the computer.
- Try a different USB port on your computer or a different USB cable.
- Ensure the device is recognized by your computer as a removable disk.

6.3 Bluetooth Connection Issues

- Ensure both the MP3 player and the Bluetooth accessory are in pairing mode and within range.
- Turn Bluetooth off and on again on both devices.
- Delete previous pairings and attempt to pair again.

6.4 No Sound

- Check the volume level on the device and any connected Bluetooth accessories.
- Ensure headphones are properly plugged in, or the built-in speaker switch is activated.
- Verify the audio file format is supported (MP3, AAC, FLAC, WAV, WMA, OGG).

7. SPECIFICATIONS

Feature	Specification
Brand	SAMVIX
Model Name	Dynamite 2.0
Memory Storage Capacity	16 GB (Internal), up to 128 GB (SD Card)
Connectivity Technology	Bluetooth 5.0
Display Technology	LED
Supported Audio Formats	MP3, AAC, FLAC, WAV, WMA, OGG
Special Features	Bluetooth, Built-In Audio, Internal Recording, Clock, Alarm, Calendar, Stopwatch
Compatible Devices	Laptop, Headphone, Personal Computer
Manufacturer Part Number	DYNAMITE2.0-16G BLK

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official SAMVIX website or contact SAMVIX customer service directly. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question