

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SERWALL](#) /

› [SERWALL 33" Outdoor Fire Pit Table Instruction Manual](#)

SERWALL 33-inch Square Propane Fire Pit Table

SERWALL 33" Outdoor Fire Pit Table Instruction Manual

Model: 33-inch Square Propane Fire Pit Table

Brand: SERWALL

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your SERWALL 33-inch Square Propane Fire Pit Table. Please read all instructions carefully before assembly and operation. This fire pit table is designed to create a unique and cozy atmosphere for your outdoor living spaces, offering warmth and comfort.



Figure 1: SERWALL 33-inch Square Propane Fire Pit Table in use.

2. SAFETY INFORMATION

Your safety is paramount. This propane fire pit is equipped with a pulse ignition system, high-quality hoses, and a pressure regulator for safe operation. It produces no smoke or sparks, reducing soot pollution and fire hazards. Always follow these guidelines:

- Ensure the fire pit is placed on a level, non-combustible surface.
- Maintain adequate clearance from combustible materials (walls, furniture, etc.).
- Never leave the fire pit unattended during operation.
- Keep children and pets at a safe distance from the fire pit.
- Do not use the fire pit in enclosed spaces.
- Check all gas connections for leaks before each use.
- The ignition switch requires one AAA battery (not included).

SAFEGUARD YOUR OUTDOOR MOMENTS

High standard of safety design to ensure safe outdoor time



High-Quality Hose
and Regulator



Pulse Ignition System



Stable Base Design



Figure 2: Control panel and safety components.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Fire Pit Table Frame (HDPE material panels, stainless steel burner, high-strength metal frame)
- Glass Wind Guard
- Fire Glass (approx. 6 lbs)
- Removable Lid
- Hoses and Pressure Regulator
- Assembly Hardware (screws, wrench)

- Durable Nylon Cover
- Instruction Manual




Figure 3: Easy Assembly Diagram.

4. ASSEMBLY INSTRUCTIONS

The SERWALL fire pit table is designed for easy assembly, with 80% of components pre-assembled and 100% of holes pre-drilled. Assembly typically takes about 20 minutes with one person.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Assemble Base:** Follow the provided diagrams to connect the side panels and secure them to the base using the included hardware. Ensure all connections are snug but do not overtighten until all parts are aligned.
3. **Install Propane Tank Shelf:** Position the pull-out shelf for the propane tank inside the base. This user-friendly design simplifies tank changes.
4. **Attach Tabletop:** Carefully place the tabletop onto the assembled base, aligning the pre-drilled holes. Secure with screws.
5. **Place Fire Glass:** Distribute the provided fire glass evenly around the burner ring in the fire pot.
6. **Install Wind Guard:** Assemble the tempered glass wind guard around the fire pot.
7. **Connect Propane Tank:** Connect your 20 lbs propane tank to the regulator and hose assembly located inside the fire pit table. Ensure all connections are tight.

Your browser does not support the video tag. Please update your browser.

Video 1: SERWALL Propane Fire Pit Table Assembly Guide. This video demonstrates the step-by-step process of assembling the fire pit table, including attaching the legs, installing the propane tank shelf, and placing the fire glass.



USER-FRIENDLY DESIGN

The pull-out shelf is designed to make changing tank easier and more convenient



^ Durable Sliding Rail



^ Silent Rubber Wheel



^ Height-adjustable Feet

Figure 4: User-friendly pull-out shelf for propane tank access.

5. OPERATING INSTRUCTIONS

To operate your fire pit table:

1. **Open Gas Valve:** Slowly open the valve on your propane tank.
2. **Ignite:** Turn the control knob on the fire pit table to the 'ON' position. Press and hold the pulse igniter button repeatedly until the flame ignites.
3. **Adjust Flame:** Once lit, release the igniter button and adjust the flame height using the control knob (Low to High). The 50,000 BTUs provide ample heat.
4. **Wind Guard:** The tempered glass wind guard effectively prevents the flame from being blown out by wind, enhancing stability and aesthetic appeal.

5. **To Turn Off:** Turn the control knob to the 'OFF' position. Close the valve on the propane tank.

Your browser does not support the video tag. Please update your browser.

Video 2: SERWALL 33 Inch Square Propane Fire Pit Table Overview. This video provides a general overview of the fire pit table, including its features and operation.

Design PULSE IGNITION SYSTEM

The pulse ignition switch on the propane fire table offers a convenient, safe, and reliable way to ignite the fire while extending the device's lifespan.



Figure 5: Pulse Ignition System for easy startup.

6. MAINTENANCE

To ensure the longevity and optimal performance of your fire pit table:

- **Cleaning:** The HDPE material panels are easy to clean with soap or fresh water. Regularly wipe down the surfaces to remove dust and debris.
- **Durability:** The HDPE material panels, stainless steel burner, and high-strength metal frame are designed to withstand various weather conditions without deformation or discoloration.
- **Storage:** A durable nylon cover is included to protect the fire pit table from the elements when not in use. Utilize the removable lid to convert the fire pit into a functional table surface when the fire is off.
- **Adjustable Feet:** The height-adjustable feet help keep the table stable on uneven surfaces, preventing wobbling.

Design REMOVABLE LID

The fire pit table comes with a removable lid, allowing it to easily switch between a fire pit and a dining table. Use the lid for a smooth surface when dining, or remove it to enjoy the warmth of the fire pit.



Figure 6: Removable lid for versatile use.

7. TROUBLESHOOTING

If you encounter any issues with your fire pit table, please refer to the following common solutions:

- **No Ignition:** Check if the AAA battery in the igniter is correctly installed and has power. Ensure the propane tank valve is fully open and there is sufficient gas. Verify all gas connections are secure.
- **Low Flame:** Ensure the propane tank has enough gas. Check for any kinks in the gas hose. Adjust the control knob to the 'MAX' position.
- **Flame Blows Out:** Ensure the glass wind guard is properly installed.

If problems persist, please contact customer support for assistance.

8. SPECIFICATIONS

Feature	Detail
Material	Metal Frame and HDPE Panels
Product Dimensions	33.5"L x 33.5"W x 24.4"H
Fire Pot Size	11"L x 11"W x 2.4"D
Heat Output	50,000 BTUs
Propane Tank Compatibility	20 lbs propane tank
Item Weight	103.4 pounds
Included Accessories	Glass Wind Guard, 6 lbs Fire Glass, Removable Lid, Durable Nylon Cover

PRODUCT DIMENSIONS



Figure 7: Product Dimensions and key features.

9. WARRANTY AND SUPPORT

SERWALL is committed to customer satisfaction. If you have any product questions or require assistance with product care, please contact our customer support. We aim for 100% satisfaction with our outdoor furniture. For after-sales support, please refer to the contact information provided with your purchase or visit the official SERWALL website.