

YVY K20Lite

YVY K20Lite Electric Bike User Manual

Model: K20Lite

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, assembly, and maintenance of your YVY K20Lite Electric Bike. Please read this manual thoroughly before your first ride and retain it for future reference. Understanding the features and proper handling procedures will ensure a safe and enjoyable experience.

2. SAFETY INFORMATION

Always prioritize safety when operating your electric bike. Failure to follow safety guidelines can result in serious injury or damage to the bike.

- Always wear a helmet and appropriate safety gear.
 - Ensure all components are securely fastened before each ride.
 - Familiarize yourself with local regulations regarding electric bike usage.
 - Do not operate the bike under the influence of alcohol or drugs.
 - The 48V 20Ah removable battery is UL-certified. Always use the original charger provided to protect battery lifespan and ensure safety.
 - Be aware of your surroundings and ride defensively.
-

3. PRODUCT OVERVIEW

The YVY K20Lite Electric Bike is designed for versatile riding across various terrains, including mountains, snow, sand, and city roads. It features a robust 1500W motor, a 48V 20Ah removable battery, dual suspension, and 20-inch fat tires.



Image: YVY K20Lite Electric Bike, showcasing its robust frame and fat tires.

Key Features:

- **Powerful Motor:** 1500W motor capable of reaching speeds up to 35 MPH and climbing 30° inclines.
- **Long-Range Battery:** UL-certified 48V 20Ah removable battery offering up to 30 miles in pure electric mode and 80 miles with pedal assist (PAS 1 Mode).
- **All-Terrain Capability:** 20"x4.0" fat tires and dual suspension system (front fork shocks and seat shock) for a smooth ride on diverse surfaces.
- **Advanced Braking:** Hydraulic disc brakes with EABS system for responsive stopping power in various conditions.
- **Versatile Riding Modes:** Pure electric, electric assist, and pedal-only modes.
- **Convenience Features:** Digital display, headlight, taillight, phone holder with USB charging port.

1500W

POWERFUL MOTOR



7 SPEED
Shimano Gears



35 MPH
Max Speed



85 N.M
Max Torque



30°
Climbing Slope



Image: Illustration of the 1500W motor's power, speed, torque, and climbing capability.



Image: Close-up of the bike's full suspension system, highlighting front fork and seat shocks.

4. ASSEMBLY

Your YVY K20Lite Electric Bike comes 90% pre-assembled. The following steps outline the final assembly process. For a visual guide, please refer to the official assembly video below.

Video: Official EUYBIKE F6B Electric Bike Install Video. This video demonstrates the step-by-step assembly process for the electric bike, including unpacking, attaching components, and preparing for the first ride.

Assembly Steps:

1. **Unpacking:** Carefully remove the bike and all components from the packaging. Check against the included components list (e-bike, charger, manual, assembly tool, pedals).
2. **Handlebar Installation:** Insert the handlebar stem into the fork tube. Ensure it is aligned and securely tightened using the provided tools.
3. **Kickstand Attachment:** Attach the kickstand to the designated mounting points on the frame and tighten the bolts.

4. **Rear Rack Installation:** Secure the rear rack to the frame using the provided screws and tools.
5. **Pedal Attachment:** Identify the left (L) and right (R) pedals. Thread them into the crank arms (left pedal counter-clockwise, right pedal clockwise) and tighten securely with a wrench.
6. **Front Fender Installation:** Mount the front fender to the front fork using the provided hardware.
7. **Headlight Installation:** Attach the headlight to the front fork or handlebar, then connect its cable to the corresponding port.
8. **Front Wheel Installation:** Carefully align the front wheel with the front fork, ensuring the brake rotor slides correctly into the caliper. Secure the wheel with the axle nuts.
9. **Seat Post and Saddle:** Insert the seat post with the saddle into the frame's seat tube. Adjust the height for comfortable riding and secure it with the quick-release lever.
10. **Folding Mechanism:** Familiarize yourself with the frame's folding mechanism for storage and transport. Ensure it is securely locked in place before riding.



Image: Close-up views of various bike components including the super bright headlight, LCD display, comfortable seat, taillight, hydraulic dual brakes, and phone holder with charger.

5. BATTERY INFORMATION AND CHARGING

The YVY K20Lite is equipped with a UL-certified 48V 20Ah removable battery, providing reliable power for extended rides.



Image: The YVY K20Lite Electric Bike with its 48V 20Ah removable battery, highlighting its range and charging capabilities.

Battery Removal and Installation:

To remove the battery, first tilt the seat forward by pulling the lever located under the seat. Insert the key into the battery lock, push it in, and turn it to unlock. The battery can then be pulled straight up using its handle. To reinstall, simply slide the battery back into place until it clicks, then lock it with the key.

Video: EUYBIKE F6 Electric Bike Display Video. This video demonstrates the removal and installation of the battery, as well as riding the bike in snowy conditions.

Charging:

- A full charge typically takes 6-7 hours.
- Always use the original charger provided with your bike.
- The battery can be charged while installed on the bike or removed.
- Do not leave the battery charging unattended for extended periods.

6. OPERATING INSTRUCTIONS

The YVY K20Lite offers three versatile riding modes to suit your preference and terrain.



Image: Visual representation of the YVY K20Lite Electric Bike's three riding modes: Bike Mode (pedal only), Assisted Riding (pedal assist), and Throttle Mode (pure electric).

Riding Modes:

1. **Pure Electric Mode:** Use the motor and throttle for propulsion without pedaling.
2. **Electric Assist Mode (PAS):** The motor provides assistance to your pedaling, making it easier to ride, especially on inclines or for longer distances. The level of assistance can be adjusted via the display.
3. **Pedal-Only Mode:** Ride the bike like a traditional bicycle without any motor assistance.

Controls and Display:

- **LCD Display:** Provides information such as speed, battery level, odometer, and pedal assist level.
- **Throttle:** Located on the handlebar, used to engage pure electric mode.

- **7-Speed Drivetrain:** Allows for manual gear changes to adapt to different riding conditions.
- **Brakes:** Hydraulic disc brakes on both front and rear wheels for effective stopping.

7. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your YVY K20Lite Electric Bike.

- **Tires:** Check tire pressure regularly. The 20-inch fat tires require specific pressure for optimal performance and safety.
- **Brakes:** Inspect brake pads and rotors for wear. Ensure brake levers are responsive and cables are not frayed.
- **Chain:** Keep the chain clean and lubricated to prevent rust and ensure smooth gear changes.
- **Battery:** Store the battery in a cool, dry place. Avoid fully discharging the battery for extended periods.
- **Fasteners:** Periodically check all bolts and screws for tightness, especially after the first few rides.
- **Cleaning:** Clean the bike with a damp cloth. Avoid using high-pressure washers directly on electrical components.

8. TROUBLESHOOTING

This section addresses common issues you might encounter with your YVY K20Lite Electric Bike.

Problem	Possible Cause	Solution
Bike does not power on	Battery not charged or not properly installed; power button not pressed.	Charge battery, ensure it's securely installed and locked, press power button on display.
Motor not assisting	PAS level set to 0; loose motor cable connection; brake levers engaged.	Increase PAS level on display, check motor cable, ensure brake levers are fully released.
Brakes feel weak	Worn brake pads; air in hydraulic system; misaligned caliper.	Inspect and replace brake pads, bleed hydraulic system (professional service recommended), adjust caliper alignment.
Unusual noises during ride	Loose components; chain issues; brake rub.	Check all fasteners, clean and lubricate chain, adjust brake caliper.

9. SPECIFICATIONS

Feature	Detail
Brand	YVY
Model Name	K20Lite

Feature	Detail
Bike Type	Electric Bike, E-Mountain Bike, City Bike, Commuting Bike, Beach Ebike, Fat tire Electric Bike, Electric Commuter Bike, Urban E bike, Road Bike
Age Range	Adult
Motor Wattage	1500W
Battery	48V 20Ah Removable (UL-Certified)
Max Speed	Up to 35 MPH
Max Range	Up to 30 miles (pure electric), 80 miles (PAS 1 Mode)
Charging Time	6-7 hours
Tires	20"x4.0" Fat Tires
Suspension Type	Dual (Front Fork Shocks, Seat Shock)
Brake Style	Hydraulic Disc Brake with EABS
Number of Speeds	7
Frame Material	High-Carbon Steel
Item Weight	88 Pounds
Maximum Weight Recommendation	330 Pounds
Special Features	Digital Display, Phone Holder with USB Charging Port, Headlight, Taillight, Odometer

10. WARRANTY AND SUPPORT

YVY provides a 12-month manufacturer warranty for your electric bike. For any inquiries or assistance, our customer service team is available to provide fast responses within 24 hours.

For support, please refer to the contact information provided in your product packaging or visit the official YVY website.