waxkiss PWM-WHITE

waxkiss Paraffin Wax Machine (Model PWM-WHITE) Instruction Manual

1. Important Safety Information

Please read all safety instructions carefully before using the waxkiss Paraffin Wax Machine. Keep this manual for future reference.

- Children shall not play with the product.
- Do not immerse the unit in water or other liquids.
- Always unplug the machine when not in use and before cleaning.
- Ensure the machine is placed on a stable, heat-resistant surface.
- Do not touch the melted wax directly until it has cooled to a safe temperature. Always test the wax temperature before use.
- Use only paraffin wax specifically designed for paraffin therapy machines.
- If you have any skin conditions, circulatory problems, or are pregnant, consult a doctor before use.

2. Product Overview

The waxkiss Paraffin Wax Machine is designed for moisturizing and softening skin on hands, feet, and elbows. It features a 3000ml capacity, two heating modes (manual and reservation), and accurate digital temperature control.

2.1. Key Features

- **Safety and Durability:** 3000ml capacity with a PP flame-retardant inner pot for safe and long-lasting use.
- **Convenient Heating Modes:** Manual temperature adjustment and a reservation heating mode (intelligent heating and cooling, available after a 3-hour reservation) with a digital display.
- **Premium Wax Ingredients:** Kit includes fragrance-free paraffin wax refills designed for enhanced heat retention and moisturizing properties.

2.2. Package Contents

Upon opening your waxkiss Paraffin Wax Machine package, you should find the following items:

- Paraffin Wax Warmer Unit
- Detachable Electrical Cord
- Paraffin Wax Refills (quantity may vary, typically 4 packs of 200g each)
- Thermal Mitts (1 pair)
- Thermal Booties (1 pair)
- PE Mitts (disposable liners)
- PE Booties (disposable liners)
- Heat Insulating Grid
- User Manual (this document)



Image: Contents of the waxkiss Paraffin Wax Machine package.


3. Setup and First Use

Follow these steps to set up your paraffin wax machine for the first time.

1. **Placement:** Place the paraffin wax machine on a flat, stable, and heat-resistant surface. Ensure it is away from water sources and out of reach of children and pets.
2. **Connect Power:** Connect the detachable electrical cord to the machine and then plug it into a suitable power outlet.

   Your browser does not support the video tag.

   Video: Demonstrates connecting the power supply to the paraffin wax machine.
3. **Add Wax:** Open the paraffin wax refills and place the wax blocks directly into the inner pot of the machine. Do not add water or other liquids. For hands, approximately 3 bags of wax are recommended. For feet, approximately 4 bags are recommended.



Images: Paraffin wax bags and recommended quantities for different body parts.

Your browser does not support the video tag.

Video: Demonstrates the paraffin wax melting process.

4. **Power On and Set Temperature:** Press the power button to turn on the machine. The display will show "131" (default temperature heating mode). You can manually adjust the temperature using the '+' and '-' buttons. The maximum temperature is 212°F.



Image: Control panel with power and temperature settings.

5. **Melting Wax:** Allow the wax to melt completely. This can take several hours depending on the amount of wax. The display will show the real-time temperature as it heats up.

6. **Temperature Adjustment for Use:** Once the wax is fully melted, manually reduce the temperature to a comfortable level for dipping. Beginners are advised to start at 122°F (50°C) and gradually increase to 127-131°F (53-55°C) as tolerated. Always test a small amount of wax on your wrist before full immersion.

4. Operating Instructions

4.1. Manual Heating Mode

In manual mode, you directly control the heating temperature.

1. Follow steps 1-5 from "Setup and First Use" to melt the wax.
2. Once the wax is melted, adjust the temperature to a safe and comfortable level (e.g., 122-131°F).
3. Proceed with the paraffin treatment as described in Section 4.3.

4.2. Reservation Heating Mode

This mode allows you to set a time for the wax to be ready for use.

1. After adding wax and plugging in the machine, press the power button. The display will show "131".
2. Press the "SET" button to switch to the reservation heating mode. The display will show "H03" (default 3 hours).
3. Use the '+' and '-' buttons to adjust the reservation time from H03 (3 hours) up to H99 (99 hours). The machine will intelligently heat and cool the wax to be ready at your set time.
4. Once the reservation time counts down and the wax is ready, proceed with the paraffin treatment.



Image: Reservation function display on the control panel.

4.3. Performing a Paraffin Treatment

Once the wax is melted and at a safe, comfortable temperature:

1. **Clean Skin:** Ensure your hands, feet, or elbows are clean and dry.
2. **Test Temperature:** Dip a small area of your wrist into the wax to ensure the temperature is comfortable and not too hot.
3. **Dip:** Slowly dip your hand, foot, or elbow into the melted wax. Remove it for a few seconds to allow the wax to solidify slightly, then re-dip. Repeat this 3-5 times to build up a thick layer of wax.



Image: Hand dipping into melted wax.

4. **Cover:** Immediately after the final dip, place a disposable PE mitt/bootie over the waxed area. For enhanced heat retention, cover with a thermal mitt/bootie.



Image: Hand covered with liner and thermal mitt.

5. **Relax:** Leave the wax on for 10-15 minutes to allow the heat and moisturizing properties to penetrate the skin.
6. **Remove Wax:** Gently peel off the hardened wax. It should come off easily. Discard the used wax and liners. Do not reuse wax that has been removed from your skin.



Image: Peeling off hardened paraffin wax.

7. **Moisturize:** After removing the wax, your skin will feel soft and moisturized. You may apply a lotion if desired.

5. Maintenance and Storage

Proper maintenance ensures the longevity and hygiene of your paraffin wax machine.

- **Cleaning:** After use, allow the remaining wax in the machine to cool and solidify. Once solid, you can usually lift out the wax block. If necessary, gently scrape any residue from the inner pot using a non-abrasive tool. Wipe the interior and exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Wax Reuse:** Wax that has been used for a treatment and removed from the skin should be discarded. Wax remaining in the machine can be reused for subsequent treatments.
- **Storage:** Store the machine in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the lid is securely closed to prevent dust accumulation.
- **Hidden Stand:** The machine features a hidden stand that can be extended at a 30-degree angle to help utilize remaining wax.



Image: Hidden stand feature for optimal wax use.

6. Troubleshooting

If you encounter issues with your waxkiss Paraffin Wax Machine, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in correctly, power outlet issue, or power button not pressed.	Ensure the power cord is securely plugged into both the machine and a working outlet. Press the power button firmly.
Wax is not melting.	Temperature set too low, insufficient time, or too much wax.	Increase the temperature setting. Allow more time for melting (can take several hours for a full pot). Ensure the lid is on during melting.

Problem	Possible Cause	Solution
Wax is too hot/cold for dipping.	Temperature not adjusted correctly after melting.	After wax is fully melted, reduce the temperature to 122-131°F (50-55°C) for comfortable use. Always test before dipping.
Wax does not peel off easily.	Wax layer is too thin.	Ensure you dip 3-5 times to build a sufficiently thick layer of wax.

If the problem persists, please contact customer service.

7. Specifications

- **Product Dimensions:** 7.87 x 9.88 x 14.92 inches
- **Weight:** 6.02 Pounds
- **Capacity:** 3000ml
- **Inner Pot Material:** PP Flame Retardant Material
- **Model:** PWM-WHITE
- **Manufacturer:** waxkiss
- **UPC:** 850067660408
- **ASIN:** B0FWXN2WMW



Image: Product dimensions diagram.



Image: PP inner pot material for safety and durability.

Your browser does not support the video tag.

Video: Overview of the paraffin wax machine's 3L optimum size.

8. Warranty and Support

waxkiss provides comprehensive customer support for your paraffin wax machine.

- **Warranty:** A one-year factory warranty is provided for this product.
- **Customer Service:** If you encounter any problems, such as missing accessories or functional failures, please email our customer service team. We offer 24/7 round-the-clock customer service and will resolve the issue promptly or provide a refund.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question