

Phueut K LW-2502

Phueut K LW-2502 Electric Spin Scrubber User Manual

Model: K LW-2502 | Brand: Phueut

Overview Setup Introduction Operation Safety Information Maintenance Package Contents Troubleshooting Product Specifications Warranty & Support

1. INTRODUCTION

Thank you for choosing the Phueut K LW-2502 Electric Spin Scrubber. This device is designed to assist with various cleaning tasks, offering both wet and dry functionality. It is compatible with specific WHL-series steam cleaners for enhanced cleaning performance. Please read this manual thoroughly before first use to ensure safe and efficient operation.

2. IMPORTANT SAFETY INFORMATION

- **Steam Cleaner Compatibility:** This electric spin scrubber is designed for use with WHL-603, WHL-608, WHL-609, WHL-618, WHL-622, and WHL-623 steam cleaners only. The steam cleaner is sold separately.
- **Power Off Before Maintenance:** Always ensure the appliance is turned off before filling or refilling any tanks, or when changing brush heads or accessories.
- **Cool Down Period:** Allow the device to cool completely before swapping out brush heads or other accessories, especially after steam cleaning, to prevent burns.
- **Water Exposure:** Avoid submerging the main unit in water. Clean with a damp cloth.
- **Children and Pets:** Keep the device out of reach of children and pets.
- **Charging:** Use only the provided charging cable. Do not attempt to charge with damaged cables or in wet conditions.

3. PACKAGE CONTENTS

Your Phueut K LW-2502 Electric Spin Scrubber package includes the following items:

- 1 x Phueut K LW-2502 Electric Spin Scrubber Main Unit

- 9 x Essential Cleaning Accessories (various specialized brushes and microfiber cloths)
- 1 x Charging Cable
- 1 x User Manual

4. PRODUCT OVERVIEW

The Phueut K LW-2502 is a versatile handheld electric scrubber designed for various cleaning tasks. It features a powerful motor, a rechargeable battery, and interchangeable brush heads.



Image 4.1: The Phueut K LW-2502 Electric Spin Scrubber demonstrating its multi-purpose use with different brush types, including Chenille, Towel sleeves, and a Straight Brush, suitable for cleaning cars, upholstery, and various surfaces.

The scrubber is compatible with specific WHL-series steam cleaners, allowing for combined steam and scrubbing action for deep cleaning.



Image 4.2: Diagram illustrating the compatibility of the Phueut KLV-2502 Electric Spin Scrubber with various WHL-series steam cleaners (WHL-623, WHL-618, WHL-603, WHL-608, WHL-609, WHL-622). Note that the steam cleaner is sold separately.

INNOVATIVE DESIGN

DUAL DRY/WET USE

212-215°F



NOTE The steam cleaner needs to be purchased

Image 4.3: The Phueut KLV-2502 Electric Spin Scrubber demonstrating its dual dry/wet use capability, including operation with steam at temperatures between 212-215°F. The steam cleaner is not included and must be purchased separately.

5. SETUP

5.1 Charging the Battery

1. Connect the charging cable to the charging port on the scrubber unit.
2. Plug the other end of the charging cable into a suitable power adapter (not included) and then into a wall outlet.
3. The charging indicator light will illuminate. A full charge takes approximately 3.5 hours.
4. When the battery level drops below 25%, a red light reminder will activate, indicating it's time to recharge.

5.2 Attaching Accessories

1. Ensure the scrubber is turned off before attaching or detaching any accessories.
2. Select the desired brush head or accessory for your cleaning task.
3. Align the accessory with the attachment point on the scrubber and push firmly until it clicks into place.
4. To remove, press the release button (if applicable) or twist and pull the accessory off.

5.3 Connecting to a Steam Cleaner (Optional)

This scrubber is compatible with WHL-603, WHL-608, WHL-609, WHL-618, WHL-622, and WHL-623 steam cleaners. Ensure your steam cleaner is one of these models.

1. Ensure both the scrubber and the steam cleaner are turned off and cool.
2. Connect the hose from the compatible WHL-series steam cleaner to the designated port on the electric spin scrubber. The connection typically involves a simple push and turn mechanism.
3. Verify the connection is secure before operating.

6. OPERATING INSTRUCTIONS

6.1 Powering On/Off

- To turn on the scrubber, press the power button.
- To turn off the scrubber, press the power button again.

6.2 Adjusting Speed Settings

The scrubber offers two adjustable speed settings:

- **180 RPM:** Ideal for heavy kitchen grease, tough stains, and robust cleaning tasks.
- **150 RPM:** Suitable for gentle cleaning on delicate surfaces such as glass, car windows, and other sensitive areas.

Press the speed adjustment button to toggle between the two speeds.

6.3 General Cleaning Tips

- Apply appropriate cleaning solution to the surface or brush head as needed.
- Hold the scrubber firmly and guide it over the surface to be cleaned. Avoid applying excessive pressure; let the scrubber do the work.
- For optimal results, move the scrubber slowly and evenly across the area.

6.4 Using with a Steam Cleaner (Combined Mode)

When connected to a compatible WHL-series steam cleaner:

1. Ensure the steam cleaner is filled with water and ready for operation according to its own manual.
2. Turn on the steam cleaner and allow it to heat up.
3. Turn on the electric spin scrubber and select the desired speed.
4. Direct the combined steam and scrubbing action onto the target surface. The high temperature steam (212–215°F) helps loosen grime while the scrubber cleans.
5. After use, turn off both devices and allow them to cool before disconnecting.

7. MAINTENANCE

7.1 Cleaning the Main Unit

- Ensure the unit is turned off and disconnected from any power source or steam cleaner.
- Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit

in water.

- Allow the unit to dry completely before storing.

7.2 Cleaning and Replacing Accessories

- After each use, remove the brush head or accessory.
- Rinse brush heads under running water to remove debris and cleaning solution residue. For microfiber cloths, wash according to fabric care instructions.
- Allow all accessories to air dry completely before reattaching or storing.
- Replace accessories when they show signs of wear or damage to maintain optimal cleaning performance.

7.3 Storage

- Store the electric spin scrubber and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.
- Ensure the battery is partially charged (around 50%) before long-term storage to prolong battery life.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Scrubber does not turn on.	Battery is depleted.	Charge the battery for at least 3.5 hours.
Scrubber stops during operation.	Battery is low.	Recharge the battery.
Poor cleaning performance.	Worn-out brush head or incorrect accessory for the task.	Replace the brush head or select a more appropriate accessory.
Scrubber not connecting to steam cleaner.	Incompatible steam cleaner model or improper connection.	Ensure your steam cleaner is a compatible WHL-series model. Re-check the connection to ensure it is secure.

9. SPECIFICATIONS

Feature	Detail
Model Number	KLW-2502
Brand	Phueut
Battery Capacity	2500mAh
Charging Time	Approx. 3.5 hours
Continuous Runtime	Up to 150 minutes
Speed Settings	180 RPM, 150 RPM
Number of Accessories	9
Product Dimensions	16.99 x 16.99 x 5.51 cm
Item Weight	921 g
Compatible Steam Cleaners	WHL-603, WHL-608, WHL-609, WHL-618, WHL-622, WHL-623

10. WARRANTY AND SUPPORT

Phueut products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or contact Phueut customer support.

If you encounter any issues or have questions about your Phueut KLW-2502 Electric Spin Scrubber, please contact our customer support team for assistance. Contact details can typically be found on the product packaging or our official website.