

BANTI VCUB-SD0028-160ANT-02

BANTI L-Shaped Adjustable Standing Desk Instruction Manual

Model: VCUB-SD0028-160ANT-02

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your BANTI L-Shaped Adjustable Standing Desk. Designed for home office and gaming environments, this electric standing desk allows for seamless transitions between sitting and standing positions, promoting a healthier and more productive workspace. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

2. SAFETY INFORMATION

- Do not exceed the maximum weight recommendation of **176 pounds (80 kg)** on the desktop.
- Ensure all cables are properly managed and secured to prevent entanglement during height adjustments.
- Keep children and pets away from the desk during operation to prevent injury.
- Use the child safety lock feature on the controller to prevent accidental operation.
- Do not place liquids directly on the desk surface without proper coasters or protection.
- Only use the provided power adapter and components.
- If any unusual noise, smell, or smoke occurs, immediately unplug the power cord and contact customer support.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop Panels (L-shaped configuration)
- Desk Frame (Legs, Crossbars)
- Control Panel with Memory Function
- Power Adapter and Cable
- Headphone Hooks (x2)
- Adjustable Feet (x6)

- All necessary Screws and Fasteners
- Installation Tool (Allen wrench, screwdriver)
- Installation Instruction Manual

4. SETUP AND ASSEMBLY

Assembly typically takes less than 30 minutes. Follow the detailed steps provided in the included installation instruction manual. Ensure you have adequate space for assembly.

4.1 Desk Dimensions

DESK DIMENSIONS



Easy Installation
≤30min



Rock-solid Stability
20mm/s




Better Load Capacity
176lbs



The desk features a 63-inch wide and 55-inch deep L-shaped desktop. The depth of each segment is approximately 23.6 inches. Refer to the diagram for detailed measurements to plan your space effectively.

4.2 Reversible Layout



No Layout Limites

Reversible left/right build to match any room



A The long side is on the Left

The long side is on the Right **A**

The L-shaped desktop can be configured with the longer side on either the left or right, providing flexibility to suit your room layout. Follow the specific instructions in the assembly manual for your desired orientation.

4.3 Additional Features

x2

Desk Hooks



Anti-collision Technology



Adjustable Feet

x6



Attach the two included headphone hooks to the desired locations on the desk frame. Install the six adjustable feet at the bottom of the desk legs to ensure stability and level the desk on uneven surfaces.

5. OPERATING INSTRUCTIONS

Your BANTI L-Shaped Standing Desk is equipped with an intuitive control panel for easy height adjustment and memory functions.

5.1 Height Adjustment

SMOOTH SITTING TO STAND

Adjust height from 27.5 " to 46.8 "



The desk can be adjusted electrically from a minimum height of **27.5 inches** to a maximum height of **46.8 inches**. Use the up and down arrow buttons on the control panel to smoothly raise or lower the desk to your desired height.

5.2 Memory Presets and Child Safety Lock

CONVENIENT CONTROLLER



LED Display
Controller



UP / DOWN
Movement



3 Height
Memory Buttons



Anti-collision
function



The control panel features an LED display and three memory buttons (1, 2, 3) to store your preferred sitting and standing heights. To set a memory position:

1. Adjust the desk to your desired height using the up/down arrows.
2. Press the 'S' button, then immediately press one of the memory buttons (1, 2, or 3) until you hear a beep or see the display flash. The height is now saved.

To activate a saved height, simply press the corresponding memory button (1, 2, or 3). The desk will automatically move to the preset position.

The control panel also includes an exclusive **child safety lock**. Consult the full installation manual for instructions on how to activate and deactivate this feature to prevent accidental operation.

5.3 Anti-Collision Function

The desk is equipped with an anti-collision system. If the desk encounters an obstacle during height adjustment, it will automatically stop and reverse slightly to prevent damage or injury. Ensure the area around the desk is clear before operation.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your standing desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Cable Management:** Periodically check and reorganize cables to prevent tangling or pinching during height adjustments.
- **Fastener Check:** Every few months, check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Motor Care:** The high-performance motor is designed for durability (up to 50,000 cycles) and requires no special lubrication. Keep the motor area free from dust and debris.

7. TROUBLESHOOTING

If you encounter issues with your BANTI L-Shaped Standing Desk, refer to the following common troubleshooting steps.

- **Desk Not Moving:**
 - Check if the power cord is securely plugged into both the desk and a working wall outlet.
 - Ensure the child safety lock is not activated.
 - Check for any obstructions under or around the desk that might be triggering the anti-collision function.
- **Uneven Movement or Noise:**
 - Verify that the desk is properly leveled using the adjustable feet.
 - Ensure all assembly screws are tightened.
 - The desk operates at a quiet 48 dB; excessive noise may indicate an issue. Unplug and contact support if persistent.
- **Error Codes on Display:**
 - Refer to the detailed troubleshooting section in your full installation manual for specific error code interpretations and solutions.
 - Often, unplugging the desk for 10-15 seconds and plugging it back in can resolve minor electronic glitches.

If problems persist after attempting these steps, please contact BANTI customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	VCUB-SD0028-160ANT-02
Desk Type	L-Shaped Electric Standing Desk
Desktop Dimensions (D x W)	55" x 63" (139.7 cm x 160 cm)
Height Adjustment Range	27.5" - 46.8" (69.85 cm - 118.87 cm)
Maximum Weight Capacity	176 lbs (80 kg)
Noise Level	Approximately 48 dB

Desktop Material	Wood (Laminated)
Base Material	Alloy Steel
Color	Rustic Brown
Special Features	Adjustable Height, Electric, Ergonomic, Memory Presets (3), Anti-Collision, Reversible Layout

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the seller directly. BANTI is committed to providing quality products and customer satisfaction.

If you require technical assistance, have questions about assembly, or need to report a missing/damaged part, please contact BANTI customer support through their official website or the retailer where the product was purchased.

© 2023 BANTI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I set up the BANTI L-Shaped Standing Desk (VCUB-SD0028-160ANT-02) for both right-side and left-side configurations?

The BANTI L-Shaped Adjustable Standing Desk (Model VCUB-SD0028-160ANT-02) features a reversible layout, meaning you can install the longer side of the desk on either the left or the right side depending on your preference.To...

[Read full answer](#)