

[Manuals.plus](#) /

> [YUSSBCU](#) /

> YUSSBCU Video Walkie Talkies for Kids User Manual (Model 765267889729)

YUSSBCU 765267889729

YUSSBCU Video Walkie Talkies for Kids User Manual

Model: 765267889729

INTRODUCTION

Thank you for choosing the YUSSBCU Video Walkie Talkies for Kids. This manual provides essential information for setting up, operating, and maintaining your new video intercom devices. Designed for children aged 3-12, these walkie talkies offer a unique blend of audio and video communication, enhancing interactive play both indoors and outdoors.



Image: The YUSSBCU Video Walkie Talkies offer advanced features like video calls and rechargeable batteries, a significant upgrade from traditional, battery-operated voice-only devices.

PACKAGE CONTENTS

- 2 x Video Walkie Talkies
- 2 x USB Charging Cables
- 2 x Lanyards
- 1 x User Manual (this document)

SETUP

1. Charging the Devices

The walkie talkies are equipped with a rechargeable battery. Before first use, fully charge both units using the provided USB cables.

1. Connect the USB-C end of the charging cable to the charging port on the side of the walkie talkie.
2. Connect the USB-A end of the cable to a compatible USB power adapter (not included) or a computer USB port.
3. The battery indicator on the screen will show charging status. A full charge typically takes 2-2.5 hours.
4. Once fully charged, disconnect the cables.



Image: The walkie talkies feature easy USB-C charging, eliminating the need for frequent battery replacements.

2. Attaching the Lanyard

For convenience and to prevent loss, attach the included lanyard to each walkie talkie.

1. Locate the small loop on the top side of the walkie talkie.
2. Thread the thin end of the lanyard through the loop.
3. Pass the larger end of the lanyard through the threaded loop and pull tight to secure.

3. Powering On/Off

To power on or off, locate the power switch button on the side of the device and press and hold it for a few seconds until the screen activates or deactivates.

OPERATING INSTRUCTIONS

1. Basic Communication (Push-to-Talk)

The walkie talkies are designed for simple 1-to-1 communication. They automatically connect when powered on and within range.

1. Ensure both walkie talkies are powered on and within range.
2. To speak, press and hold the large intercom key on the side of the device.
3. Speak clearly into the microphone (MIC hole).
4. Release the intercom key when you are finished speaking to allow the other person to respond.



Image: Key components of the walkie talkie, including the intercom key for push-to-talk functionality.

2. Video Functionality

These walkie talkies feature real-time video calls, allowing users to see each other during communication.

- **Real-Time Video Calls:** When communicating, the screen will display the live video feed from the other device.
- **Switching Video Views:** Short press the 'M' (Mode) button (also labeled as Camera Conversion/Voice Change button) to cycle through different video display modes. You can view your own camera feed, the other person's camera feed, or a split-screen view.



Image: The 'M' button allows for quick switching between various video display modes, including single and split-screen views.

3. Magic Voice Switching

Add fun to your conversations with multiple voice modes.

- Long press the 'M' (Mode) button to switch between 3 different voice modes: Original, Child, Robot, and Alien.

4. Volume Adjustment

Adjust the volume to suit your environment.

- Use the '+' and '-' buttons on the side of the walkie talkie to increase or decrease the volume. There are six adjustable volume levels.

5. Range and Signal

The walkie talkies offer reliable communication over various distances.

- **Indoor/Neighborhood:** Up to 100 meters (approximately 328 feet).
- **Open Outdoor Conditions:** Up to 400 meters (approximately 1312 feet).
- The signal strength indicator on the screen will show the current connection quality.




Image: The walkie talkies provide a substantial range for outdoor play, allowing children to communicate across distances.



Image: The devices support communication through walls, making them suitable for indoor use across different rooms.

MAINTENANCE

1. Cleaning

To keep your walkie talkies in good condition, wipe them with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.

2. Battery Care

To maximize battery life:

- Charge the devices fully before first use.
- Avoid completely draining the battery regularly.
- Store the walkie talkies in a cool, dry place when not in use.

TROUBLESHOOTING

If you encounter any issues with your YUSSBCU Video Walkie Talkies, please refer to the following common solutions:

- **No Power:** Ensure the device is fully charged. Connect it to the USB charger and wait for the battery indicator to show charging.
- **No Connection/Poor Signal:** Make sure both devices are powered on and within the specified operating range. Obstacles like thick walls or large metal structures can reduce range. Try moving closer to the other device or to an open area.
- **No Audio/Video:** Check the volume settings using the '+' and '-' buttons. Ensure the intercom key is pressed and held firmly when speaking. Verify that both devices are on the same channel (automatic for these 1-to-1 devices).
- **Screen Frozen/Unresponsive:** Try turning the device off and then on again. If the issue persists, allow the battery to fully drain and then recharge it.

SPECIFICATIONS

Feature	Description
Brand	YUSSBCU
Model Number	765267889729
Color	BLUE/BLUE (as per product variant)
Number of Channels	1 (1v1 Single-channel encryption)
Special Features	Lightweight, Rechargeable, Shockproof, Video Intercom, Magic Voice Switching
Talking Range (Indoor/Neighborhood)	Up to 100m (approx. 328 feet)
Talking Range (Open Outdoor)	Up to 400m (approx. 1312 feet)
Voltage	3.7 Volts
Water Resistance Level	Moisture Resistant
Battery	1 Nonstandard Battery (included), Rechargeable
Screen	2.0 Inch IPS 480P Screen

WARRANTY

This product comes with a **1 Year Warranty** from the manufacturer, YUSSBCU. Please retain your proof of purchase for any warranty claims.

SUPPORT

For further assistance, technical support, or warranty inquiries, please contact YUSSBCU customer service. Refer to the packaging or the official YUSSBCU website for contact details.

PRODUCT VIDEOS

Your browser does not support the video tag.

Video: This video demonstrates the YUSSBCU Video Walkie Talkies in action, showcasing their features and ease of use for children.

Your browser does not support the video tag.

Video: An overview of the YUSSBCU Video Walkie Talkies, highlighting their video communication capabilities and suitability for children's play.