

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [MINISO](#) /
- › [MINISO Disney Zootopia Soft Vinyl Plush Toy Blind Box Instruction Manual](#)

MINISO B0FX31CGGZ

MINISO Disney Zootopia Soft Vinyl Plush Toy Blind Box Instruction Manual

Brand: MINISO | Model: B0FX31CGGZ

1. INTRODUCTION

The MINISO Disney Zootopia Soft Vinyl Plush Toy Blind Box offers a unique collectible experience. Each sealed box contains one random character figurine from the beloved Disney movie Zootopia, crafted from soft vinyl and plush materials. These figures are designed for display and collecting, providing a delightful surprise with every unboxing.

ALL MEMBERS



Figure 1: An illustration of the blind box concept, showing various Zootopia characters.

2. SAFETY INFORMATION

- **Keep away from fire:** This product is not fire-resistant.
- **Small parts warning:** The package contains small parts. Do not swallow. This product is not suitable for children under 3 years of age due to choking hazards.
- **Recommended age:** This product is recommended for individuals aged 15 years and above.
- **Guardian consent:** Minors within the applicable age range must obtain guardian consent before purchasing or using this product.
- **Disposal:** Please recycle and dispose of this product responsibly to minimize environmental impact.

3. WHAT'S IN THE BOX

Each MINISO Disney Zootopia Soft Vinyl Plush Toy Blind Box contains:

- One (1) random Disney Zootopia soft vinyl plush toy figure.

Please note that the specific character inside is a surprise and cannot be determined from the outer packaging. There are 6 regular designs in this series, with no hidden styles. The probability of drawing each regular style is

evenly distributed at 1:6.



Figure 2: The exterior packaging of the MINISO Disney Zootopia Blind Box.

4. SETUP

Follow these steps to unbox your Zootopia figurine:

1. Carefully remove the sealed blind box from any external packaging.
2. Locate the opening tab on the blind box and gently open it.
3. Remove the inner foil bag containing your surprise Disney Zootopia soft vinyl plush toy.
4. Tear open the foil bag to reveal your collectible figure.
5. Some figures may have a protective film over their eyes or glasses; gently peel this off.

5. OPERATING (DISPLAY & COLLECTION)

Your MINISO Disney Zootopia figure is designed for display and can be integrated into your collection in various ways:

- **Display:** Place your figure on a shelf, desk, or any flat surface to showcase its design.

- **Keychain Functionality:** Each figure includes a small ring or loop, allowing it to be attached to a bag, backpack, or keys as a charm.
- **Collecting:** Collect all 6 unique characters from the series. You can identify which character you received by comparing it to the character list provided on the box or in Figure 3.



Figure 3: All six collectible characters in the MINISO Disney Zootopia series.



Figure 4: The six regular models, each featuring a keychain for portability.

Examples of characters you might receive:



Officer Judy Hopps



Nick Wilde



Bellwether

6. MAINTENANCE

To ensure the longevity and appearance of your MINISO Disney Zootopia plush toy, follow these care instructions:

- **Cleaning:** For minor dirt or dust, gently wipe the surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. Do not machine wash or tumble dry.
- **Storage:** Store the toy in a clean, dry place away from direct sunlight and extreme temperatures to prevent fading or material degradation.
- **Handling:** Handle with care to avoid damage to the vinyl parts or plush fabric.

7. TROUBLESHOOTING

While these products are generally robust, here are some common concerns and solutions:

- **Received a duplicate character:** Blind boxes contain random figures. Receiving a duplicate is part of the blind box experience. Consider trading with other collectors.
- **Minor cosmetic imperfections:** Due to manufacturing processes, slight variations or minor imperfections may occur. If you believe there is a significant defect, please refer to the warranty and support section.
- **Keychain detachment:** Ensure the keychain ring is securely fastened. If it detaches, it can usually be reattached.

8. SPECIFICATIONS

Product Dimensions	4.76 x 3.35 x 7.68 inches
Item Weight	5.9 ounces
Model Number	B0FX31CGGZ
Manufacturer Recommended Age	15 - 18 years (Note: Minors under 8 years old are not allowed to purchase blind box products.)
Main Materials	Body: Polyester Fiber, Filling: 100% Polyester Fiber, Face: Vinyl (PVC), Lanyard Ring: Zinc Alloy

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your MINISO Disney Zootopia Soft Vinyl Plush Toy Blind Box, please contact MINISO customer service. While specific warranty details are not provided in this manual, MINISO typically offers support for product defects. Please retain your proof of purchase for any inquiries.

You can find contact information for MINISO customer support on their official website or through the retailer where the product was purchased.

