

Gevi DCMF0-BK0A1

Gevi 10-Cup Grind & Brew Coffee Maker

MODEL: DCMF0-BK0A1

Instruction Manual

1. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycles.
- The carafe is designed for use with this appliance only. It must never be used on a range top.
- Do not place a hot carafe on a cold or wet surface.

- Do not use a cracked carafe or a carafe having a loose or weakened handle.
- Do not clean carafe with cleansers, steel wool pads, or other abrasive material.

2. PRODUCT COMPONENTS

The Gevi 10-Cup Grind & Brew Coffee Maker includes the following components:

- 1 x Drip Coffee Maker (Main Unit)
- 1 x Glass Coffee Pot (Carafe)
- 1 x Scoop
- 1 x Permanent Filter
- 1 x Filter Ring
- 1 x Removable Filter Holder
- 1 x Manual



Figure 2.1: Included components of the Gevi 10-Cup Grind & Brew Coffee Maker.

3. SETUP

3.1 Initial Cleaning

Before first use, wash all removable parts (glass carafe, scoop, permanent filter, filter ring, removable filter holder, and water tank) in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the coffee maker with a soft, damp cloth.

3.2 Assembly

1. **Install the Filter Holder:** Open the swing-out filter basket. Place the removable filter holder into its designated slot.
2. **Insert Permanent Filter:** Place the permanent filter into the removable filter holder.
3. **Add Filter Ring:** Place the filter ring on top of the permanent filter.
4. **Position Carafe:** Place the empty glass carafe onto the warming plate.
5. **Fill Water Tank:** Open the water tank lid. Fill the removable water tank with clean, room-temperature water up to the desired cup mark (e.g., MAX 10). Ensure the water level matches the amount of coffee you intend to brew.
6. **Close Water Tank:** Close the water tank lid securely.

1.5L Visible & Removable Water Tank

Perfect for Brewing up to 10 Cups without Interruption



Figure 3.1: Removable and visible water tank.



Figure 3.2: Adding water to the tank.

Your browser does not support the video tag. Please update your browser to view this content.

Video 3.1: Step-by-step guide on how to set up the Gevi 10-Cup Grind & Brew Coffee Maker.

4. OPERATING INSTRUCTIONS

4.1 Making Coffee with Whole Beans

- 1. Prepare the Machine:** Ensure the filter holder, permanent filter, filter ring, and carafe are correctly in place, and the water tank is filled to the desired level.

- 2. Add Coffee Beans:** Open the bean hopper lid and add whole coffee beans using the provided scoop. Close the bean hopper lid.
- 3. Adjust Grind Level:** Rotate the grind regulator on the bean hopper to select your preferred grind size (finer or coarser).
- 4. Power On:** Plug in the coffee maker and press the **ON/OFF** button to turn it on.
- 5. Select Cup Size:** Press the **GRIND CUP** button to select the desired number of cups (4-10).
- 6. Choose Brewing Style:** Press the **RECIPES** button to cycle through the available brewing styles: CLASSIC, INTENSE, RICH, or ICE.
- 7. Start Brewing:** Press the **ON/OFF** button again to start the grinding and brewing process. The machine will automatically grind the beans and then brew the coffee.
- 8. Keep Warm Function:** After brewing, the warming plate will automatically keep the coffee hot for up to 4 hours (60-240 minutes, adjustable via touchscreen).



Figure 4.1: Adding whole beans or ground coffee.

Your browser does not support the video tag. Please update your browser to view this content.

Video 4.1: Instructions on how to make coffee using whole beans with the Gevi 10-Cup Grind & Brew Coffee Maker.

Your browser does not support the video tag. Please update your browser to view this content.

4.2 Making Coffee with Ground Coffee

1. **Prepare the Machine:** Ensure the filter holder, permanent filter, filter ring, and carafe are correctly in place, and the water tank is filled to the desired level.
2. **Add Ground Coffee:** Add your desired amount of pre-ground coffee into the permanent filter.
3. **Disable Grinding:** Press the **GRIND OFF** button to ensure the grinder does not activate.
4. **Power On:** Plug in the coffee maker and press the **ON/OFF** button to turn it on.
5. **Select Cup Size:** Press the **GRIND CUP** button to select the desired number of cups (4-10).
6. **Choose Brewing Style:** Press the **RECIPES** button to cycle through the available brewing styles: CLASSIC, INTENSE, RICH, or ICE.
7. **Start Brewing:** Press the **ON/OFF** button again to start the brewing process.
8. **Keep Warm Function:** After brewing, the warming plate will automatically keep the coffee hot for up to 4 hours (60-240 minutes, adjustable via touchscreen).

Your browser does not support the video tag. Please update your browser to view this content.

Video 4.3: Instructions on how to make coffee using pre-ground coffee with the Gevi 10-Cup Grind & Brew Coffee Maker.

4.3 Programmable Brewing (Delay Brew)

The coffee maker features a 24-hour programmable timer, allowing you to set a delay brew for fresh coffee at a specific time.

1. **Set Current Time:** With the machine plugged in and powered on, use the **HOUR** and **MIN** buttons to set the current time.
2. **Prepare for Brewing:** Follow steps 1-6 from either "Making Coffee with Whole Beans" or "Making Coffee with Ground Coffee" sections.
3. **Set Delay Time:** Press the **DELAY BREW** button. The display will show "PM" or "AM" and the time will flash. Use the **HOUR** and **MIN** buttons to set your desired brew start time.
4. **Activate Delay Brew:** Press the **DELAY BREW** button again to confirm. The delay brew indicator will light up, and the machine will start brewing at the set time.

Wake Up with Hot Coffee

24-hour Programmable Timer



Figure 4.2: Setting the 24-hour programmable timer for delay brew.

Your browser does not support the video tag. Please update your browser to view this content.

Video 4.4: Guide on how to set the delay brew function.

Your browser does not support the video tag. Please update your browser to view this content.

Video 4.5: Instructions for scheduling brewing time on the Gevi coffee maker.

5. MAINTENANCE

5.1 Daily Cleaning

1. **Unplug:** Always unplug the coffee maker before cleaning.
2. **Clean Carafe:** Wash the glass carafe, permanent filter, filter ring, and removable filter holder in warm, soapy water. Rinse thoroughly and dry. These parts are not dishwasher safe.
3. **Wipe Exterior:** Wipe the exterior surfaces of the coffee maker, including the warming plate, with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.

5.2 Descaling

Mineral deposits (limescale) can build up in your coffee maker over time, affecting performance and coffee taste. Descale your machine regularly (e.g., every 2-3 months, or more often if you have hard water).

- 1. Prepare Descaling Solution:** Fill the water tank with a mixture of white vinegar and water (e.g., 1:2 ratio) or a commercial descaling solution according to product instructions.
- 2. Start Cleaning Cycle:** Select the **CLEAN** mode on the touchscreen. Press the **ON/OFF** button to start the cleaning process. The machine will run a cycle to flush the internal water lines.
- 3. Rinse Cycles:** After the descaling cycle is complete, empty the carafe. Fill the water tank with fresh, clean water and run 2-3 full brewing cycles (without coffee) to rinse out any remaining descaling solution.

Your browser does not support the video tag. Please update your browser to view this content.

Video 5.1: Detailed instructions on how to descale the Gevi 10-Cup Drip Coffee Maker.

5.3 Cleaning the Bean Hopper

The bean hopper is removable for easy cleaning. Regularly remove any residual coffee beans or grounds to prevent clogging and maintain optimal grinding performance.



Figure 5.2: Removable bean hopper for easy cleaning.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee not brewing.	No water in tank; machine not plugged in; delay brew set.	Fill water tank; ensure power connection; check delay brew settings.
Weak coffee.	Insufficient coffee grounds; coarse grind setting; incorrect brewing style.	Add more coffee; select finer grind; choose a stronger brewing style (e.g., Intense, Rich).
Grinder not working.	Bean hopper empty; grind off selected; bean hopper not locked.	Fill bean hopper; ensure GRIND OFF is not selected; ensure bean hopper is locked in place.
Coffee overflows.	Too much water; filter basket clogged.	Do not overfill water tank; clean filter basket and ensure proper placement.
Touchscreen unresponsive.	Temporary software glitch; power issue.	Unplug the machine for 30 seconds, then plug back in. If issue persists, contact customer support.

7. SPECIFICATIONS

- **Brand:** Gevi
- **Model Name:** Drip Coffee Machine (DCMF0-BK0A1)
- **Color:** Black
- **Product Dimensions:** 10.7"D x 7.9"W x 17.8"H
- **Item Weight:** 4.7 pounds
- **Coffee Maker Type:** Drip Coffee Machine
- **Operation Mode:** Fully Automatic
- **Voltage:** 120 Volts
- **Coffee Input Type:** Whole Bean
- **Is Dishwasher Safe:** No (for most components)
- **Special Feature:** Programmable, Built-in Burr Grinder, Touch Screen, 4-Hour Keep Warm



Figure 7.1: Product dimensions of the Gevi 10-Cup Grind & Brew Coffee Maker.

8. WARRANTY AND SUPPORT

Every Gevi product (purchased through official or authorized channels) includes a 12-month warranty and lifetime technical support.

If you encounter any problems when using your Gevi coffee machine, please feel free to contact us for assistance.

- **Warranty Period:** 12 Months
- **Support:** Lifetime Technical Support

Related Documents - DCMF0-BK0A1

	<p><u>Gevi GECMA025A-U Coffee Maker Instruction Manual</u></p> <p>Comprehensive instruction manual for the Gevi GECMA025A-U coffee maker, covering important safeguards, operation instructions for making drip coffee with beans or powder, automatic start function, cleaning, maintenance, and disposal.</p>
	<p><u>Gevi DCMF0 Drip Coffee Maker with Grinder User Manual</u></p> <p>User manual for the Gevi DCMF0 Drip Coffee Maker with Grinder, covering important safeguards, how to use the machine, brewing coffee, cleaning instructions, troubleshooting, technical parameters, customer support, and warranty information.</p>
	<p><u>Gevi 2-in-1 Burr Coffee Grinder: 35 Precise Grind Settings - Instruction Manual</u></p> <p>Comprehensive instruction manual for the Gevi 2-in-1 Burr Coffee Grinder (Model: GECGI406B-U7) with 35 precise grind settings. Learn about setup, operation, cleaning, maintenance, and troubleshooting for optimal coffee brewing.</p>
	<p><u>Gevi 4-Cup Drip Coffee Machine Instruction Manual</u></p> <p>Comprehensive instruction manual for the Gevi 4-Cup Drip Coffee Machine (Model GECMD008-U), covering important safeguards, operation, cleaning, maintenance, and troubleshooting.</p>
	<p><u>Gevi 2-in-1 Burr Coffee Grinder Instruction Manual</u></p> <p>Comprehensive instruction manual for the Gevi 2-in-1 Burr Coffee Grinder (Model GECGI406B-U7). Learn about its 35 precise grind settings, operation modes (Cup and Time), cleaning procedures, troubleshooting, and warranty information.</p>
	<p><u>Gevi GECGI406B-U7 Coffee Grinder Instruction Manual - Operation, Cleaning, and Troubleshooting</u></p> <p>Comprehensive instruction manual for the Gevi GECGI406B-U7 coffee grinder. Learn about operation modes, cup and time functions, cleaning procedures, maintenance tips, and troubleshooting common issues.</p>