

Hape E8769

Hape Railway Bucket Harbour Set E8769 Instruction Manual

Model: E8769

1. INTRODUCTION

Thank you for choosing the Hape Railway Bucket Harbour Set E8769. This set allows children to create their own unique harbor railway environment. The innovative design integrates the storage bucket and its lid into the play scene, transforming them into landscape elements. This manual provides essential information for safe assembly, operation, and maintenance of your new railway set.

2. SAFETY INFORMATION

- **Recommended Age:** This product is suitable for children aged 3 years and older.
- **Choking Hazard:** The set contains small parts which may pose a choking hazard for children under 3 years. Adult supervision is recommended during play.
- **Assembly:** Adult assembly may be required for initial setup. Ensure all parts are securely connected before allowing children to play.
- **Material Safety:** All Hape products are made from high-quality, non-toxic materials.
- **Inspection:** Regularly inspect the toy for any damage or loose parts. Discontinue use if any damage is found.

3. PACKAGE CONTENTS

The Hape Railway Bucket Harbour Set E8769 includes 50 pieces designed to create a dynamic harbor scene. Please verify that all components listed below are present in your package:

- Wooden railway tracks (various shapes and lengths)
- 1x Train engine
- Wagons (e.g., cargo wagons)
- 1x Red bridge

- 1x Lighthouse
- Traffic signs and cones
- 1x Working crane
- 1x Boat
- 1x Truck
- Cargo containers
- Trees and other landscape elements
- 1x Storage bucket with lid (integrates into play)



Image: All components of the Hape Railway Bucket Harbour Set E8769 laid out, including tracks, train, crane, bridge, and accessories.

4. SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all pieces from the storage bucket. The bucket itself and its lid are designed to be part of the play environment.
2. **Integrate Storage Box:** Place the green storage bucket upside down to serve as a raised platform or mountain. The lid can be used as a separate elevated track section or a flat area for accessories.
3. **Assemble Tracks:** Connect the various wooden track pieces to form a railway layout. Experiment with different configurations to create a unique path for the train. Ensure all track connectors are firmly pushed together.
4. **Position Harbour Elements:** Place the blue harbor base piece, crane, boat, and other accessories like the lighthouse, signs, and trees around your track layout. The crane can be positioned near the harbor to load and unload cargo.
5. **Place Train and Wagons:** Carefully place the train engine and wagons onto the tracks.



Image: The Hape Railway Bucket Harbour Set E8769 fully assembled, showcasing the green storage bucket used as a mountain and the blue harbor base.



Image: A detailed view of the harbor section of the Hape Railway Bucket Harbour Set E8769, featuring the crane, boat, and a train on the tracks.

5. OPERATING INSTRUCTIONS

Once assembled, the Hape Railway Bucket Harbour Set E8769 offers various play possibilities:

- **Manual Train Operation:** Push the train engine and wagons along the tracks. The train is designed for manual play, allowing children to control its speed and direction.
- **Crane Operation:** Use the movable crane to lift and transport the cargo containers. The crane features a magnetic attachment for easy handling of the magnetic cargo.
- **Harbor Activities:** Simulate loading and unloading goods from the boat to the train or truck. The truck can transport

cargo around the harbor area.

- **Expand Your Railway:** This set is compatible with other Hape wooden railway series. You can connect additional Hape tracks and accessories to expand your railway world.



Image: The crane in the Hape Railway Bucket Harbour Set E8769 actively lifting a yellow cargo container, demonstrating its play function.

6. MAINTENANCE

- **Cleaning:** Wipe all wooden and plastic parts with a damp cloth. Do not immerse in water. Avoid using harsh cleaning agents or abrasives.
- **Storage:** After play, disassemble the tracks and store all components neatly inside the provided storage bucket. This helps keep the set organized and prevents loss of small parts.
- **Inspection:** Periodically check all parts for wear and tear, especially the track connectors and moving parts of the crane.

7. TROUBLESHOOTING

- **Tracks Not Connecting:** Ensure the track pieces are aligned correctly and pushed firmly together. Some force may be needed to create a secure connection.
- **Train Derailing:** Check that the tracks are laid on a flat, stable surface. Ensure all track connections are secure and there are no gaps or misalignments.
- **Crane Not Lifting:** Verify that the magnetic cargo is correctly positioned under the crane's magnet. Ensure the crane arm moves freely.
- **Missing Parts:** If any parts are missing upon opening the package, please contact Hape customer support.

8. SPECIFICATIONS

Brand	Hape
Model Number	E8769
Recommended Age	3 years and up
Materials	Wood, MDF, PP, ABS, Magnet
Product Dimensions	23.5 x 32 x 23 cm (approximate)
Country of Origin	China

9. WARRANTY AND SUPPORT

Hape products are manufactured to high-quality standards. For any questions regarding product assembly, operation, or if you encounter any issues, please contact Hape customer support. Please retain your proof of purchase for warranty claims.

For more information, visit the official Hape website:www.hape.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question