



[Manuals.plus](#) /

> [Kdfdfsa](#) /

> Kdfdfsa 881X Digital Piano: 88-Key Semi-Weighted Electronic Keyboard User Manual

## Kdfdfsa 881X

# Kdfdfsa 881X Digital Piano User Manual

MODEL: 881X

## Introduction

This manual provides essential information for the setup, operation, and maintenance of your Kdfdfsa 881X Digital Piano. Designed for both beginners and experienced players, this 88-key semi-weighted electronic keyboard offers a realistic playing experience with versatile features. Please read this manual thoroughly to ensure proper use and longevity of your instrument.

## Safety Information

- Ensure the piano is placed on a stable, flat surface to prevent accidental falls.
- Keep the instrument away from direct sunlight, heat sources, and excessive humidity.
- Do not expose the piano to water or other liquids. Clean only with a dry, soft cloth.
- Use only the provided power adapter. Disconnect the power cord during lightning storms or when unused for long periods.
- Keep small parts and accessories out of reach of young children to prevent choking hazards.

## Package Contents

Verify that all items listed below are included in your package:

- Kdfdfsa 881X Digital Piano
- Double-X Keyboard Stand
- Sustain Pedal
- Music Rest
- USB Power Adapter
- Headphones
- Key Stickers (for beginner learning)

- Keyboard Bag
- User Manual (this document)



Figure 1: Kdfdsa 881X Digital Piano with all included accessories, including the stand, headphones, sustain pedal, music rest, and carrying bag.

## Setup

Follow these steps to set up your digital piano:

1. **Assemble the Keyboard Stand:** Unfold the double-X stand and secure it at your desired height using the adjustment knob. Ensure the stand is stable before placing the piano on it.
2. **Place the Digital Piano:** Carefully place the Kdfdsa 881X Digital Piano onto the assembled stand, ensuring it is centered and stable.
3. **Connect the Sustain Pedal:** Plug the sustain pedal cable into the 'SUS' port on the back of the piano.
4. **Connect the Power Adapter:** Plug the USB power adapter into the 'DC IN' port on the back of the piano, then plug the adapter into a wall outlet.
5. **Attach the Music Rest:** Slide the music rest into the designated slots on top of the piano.

6. **Optional: Apply Key Stickers:** If you are a beginner, you may apply the included key stickers to help identify notes.

Video 1: Unboxing and initial setup of the Kdfdfa 881X Digital Piano, demonstrating stand assembly and basic connections.



Figure 2: Detail of the adjustable double-X stand, showing the knob for height adjustment.



## Multiple Devices Connection

Supports MIDI/USB/SUS/MIC/Headphone connection for rich playability



USB/HDMI



OTG



SUS



MIC



Audio in



Audio  
out



Power  
interface

Figure 3: Rear panel connections including USB, Sustain, Microphone, Audio In/Out, and Power input.

## Operating Instructions

Your Kdfdsa 881X Digital Piano offers a range of features for an enhanced playing experience:

- **Power On/Off & Volume:** Use the dedicated power button to turn the piano on or off. Adjust the master volume using the volume controls on the control panel.
- **Semi-Weighted Keys:** The 88 semi-weighted keys provide a responsive touch, simulating the feel of an acoustic piano while offering a lighter action suitable for various playing styles and beginners.
- **Sounds & Rhythms:** Explore 200 different sounds (tones) and 200 rhythms to customize your music. Use the dedicated buttons on the control panel to select and switch between these options.
- **Demo Songs:** The piano includes 70 demo songs for practice and enjoyment. Refer to the control panel for demo song playback options.
- **Bluetooth Connectivity:** Connect your smartphone or tablet via Bluetooth to access more lessons and interactive learning applications.

- **MIDI/USB/MP3 Functionality:** The piano supports MIDI functionality, allowing connection to a computer or other external devices for music editing or recording. MP3 input is also available for playing along with your favorite tracks.
- **Recording & Playback:** Utilize the built-in recording and playback function to capture your performances and review your progress.
- **Headphone & Microphone Jacks:** For private practice, plug headphones into the dedicated jack. A microphone input is also available for vocal accompaniment.



Figure 4: Control panel highlighting buttons for selecting rhythms, tones, and demo songs.



Power Adapter



6 batteries  
(Not Included)

## Play The Keyboard Anywhere

Two power supply modes

Figure 5: Demonstrating Bluetooth connectivity for interactive lessons on a tablet.

### Maintenance

- **Cleaning:** Wipe the piano's surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Storage:** When not in use, store the piano in its provided keyboard bag to protect it from dust and scratches.
- **Power:** Always disconnect the power adapter when the piano is not in use for extended periods.

# PERFECT SIZE & TOUCH SENSITIVE

Standard 88 Piano Key With Smart Touch Curve Sensitive System



Figure 6: The digital piano with its carrying bag and power adapter, illustrating portability and storage.

## Troubleshooting

- **No Sound:** Check if the power adapter is securely connected and the piano is turned on. Ensure the volume is not set to zero. If headphones are plugged in, sound will only come through the headphones.
- **Keys Not Responding:** Verify that the piano is powered on. If specific keys are not responding, contact customer support.
- **Bluetooth Connectivity Issues:** Ensure Bluetooth is enabled on your device and the piano. Try restarting both devices.

## Specifications

- **Model Name:** Bfgxu00
- **Item Model Number:** 881X
- **Number of Keys:** 88
- **Key Type:** Semi-Weighted

- **Special Feature:** Built-In Speakers
- **Skill Level:** Beginner
- **Item Weight:** 17.21 pounds
- **Package Dimensions:** 54 x 15.25 x 5.6 inches



Figure 7: Overview of the digital piano's dimensions and key accessories.

## Warranty and Support

For warranty information, technical support, or any inquiries regarding your Kdfdfs 881X Digital Piano, please refer to the contact information provided on the product packaging or the official Kdfdfs website. Keep your purchase receipt as proof of purchase for warranty claims.

