Uvital B0FX43JP36

Uvital Large Button Corded Landline Phone Instruction Manual

Model: B0FX43JP36

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Uvital Large Button Corded Landline Phone. Designed for ease of use, this phone features large buttons, adjustable volume, and one-touch dialing for convenience.

Package Contents

Before you begin, please ensure all items are present:

- Uvital Large Button Corded Landline Phone Base
- Handset
- Coiled Handset Cord
- Telephone Line Cord (RJ11)
- User Manual (this document)

Your browser does not support the video tag.

Video: Overview of the Uvital Large Button Phone and its components, including basic setup steps.

Setup

1. **Connect the Handset Cord:** Plug one end of the coiled handset cord into the left side of the phone base unit. Plug the other end into the handset.
2. **Connect the Telephone Line:** Plug one end of the telephone line cord (RJ11) into the "TEL-LINE" jack on the side of the phone base. Plug the other end into your telephone wall socket.



Image: Visual guide for connecting the handset cord and telephone line to the phone base and wall socket.

Operating Instructions

1. One-Touch Dialing Buttons (Photo Buttons)

Your phone features 2 large photo buttons and 1 SOS emergency button for frequently dialed numbers. You can customize the pictures on these buttons.

Programming a Photo Button:

1. Enter the phone number you wish to store, including the area code if necessary**Do not pick up the handset.**
2. Press and hold the desired photo memory key for 5 seconds to complete the storage.
3. To change a stored number, repeat the steps above.

Important: Do not unplug the phone line to avoid losing stored contact numbers.



Image: Detail of the three one-touch photo buttons and the SOS button, highlighting their function.

2. SOS Emergency Button

The SOS button allows for direct dialing in both on-hook and off-hook modes, providing quick access to emergency contacts.



Image: Demonstrates the SOS button's functionality for emergency calls, usable whether the handset is on or off the hook.

3. Hands-Free Mode

Activate hands-free mode for clear conversations without holding the phone. The speakerphone volume is adjustable up to 100dB.




Image: Shows how to activate the hands-free mode and its high volume capability for easier communication.

4. Adjustable Volume Settings

The phone offers adjustable volume levels for the ringer, handset, and speakerphone.

- **Ringer Volume:** 2 adjustable levels (LOW, HIGH), up to 100dB.
- **Handset Volume:** 2 adjustable levels (MED, HIGH).
- **Speakerphone Volume:** Adjustable from MIN to MAX, up to 100dB.



Image: Explains the various volume controls on the phone, including speaker, ringer, and handset volume switches.

5. Visual Loud Ringer (LED Indicator)

An integrated bright LED light flashes for incoming calls, making them more noticeable, especially in noisy environments. This product does not feature a display screen and does not support Caller ID functionality.



Image: Highlights the visual loud ringer feature, showing the LED light flashing when a call comes in.

6. Hearing Aid Compatibility

The Uvital phone is designed to be compatible with hearing aids, meeting the TIA-1083 standard for clearer conversations with reduced background noise.



Image: Illustrates the phone's compatibility with hearing aids for improved call clarity.

Maintenance

To ensure the longevity and proper functioning of your Uvital phone, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the phone's surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cord Care:** Avoid tangling or excessive pulling of the handset and line cords to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No dial tone.	Telephone line not connected properly or service issue.	Ensure the telephone line cord is securely plugged into both the phone base and the wall socket. Check if your landline service is active.
Cannot hear caller or caller cannot hear me.	Volume settings are too low or handset/speakerphone issue.	Adjust the handset volume switch to HIGH or MED. Adjust the speakerphone volume slider to MAX. Ensure the handset cord is securely connected.
Stored memory numbers are lost.	Phone line was unplugged.	Avoid unplugging the phone line. Reprogram the photo buttons as needed.
Ringer is too loud.	Ringer volume set to HIGH.	Adjust the ringer volume switch to LOW.
LED indicator not flashing for incoming calls.	No incoming call or LED malfunction.	Ensure the phone is receiving calls. If the issue persists, contact support.

Specifications

Brand	Uvital
Model	B0FX43JP36
Telephone Type	Corded
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	Corded Electric (No batteries required)
Dialer Type	Single Keypad
Item Weight	0.63 Kilograms
Multiline Operation	Single-Line Operation
Caller ID	No
Ringer Volume	Adjustable (LOW, HIGH, up to 100dB)
Handset Volume	Adjustable (MED, HIGH)
Speakerphone Volume	Adjustable (MIN to MAX, up to 100dB)
Special Features	3 One-Touch Dialing Big Buttons, Hands-Free, Loud Ringer, Adjustable Volume, Flashing LED Indicator, Hearing Aid Compatible

Warranty Information

This Uvital product comes with a**1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or natural disasters.

Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Uvital customer support. Refer to the contact information provided with your product packaging or visit the official Uvital website for the most up-to-date support details.

- **24/7 Quick Reply**
- **Technical Support**
- **Returns & Replacements**

We are committed to providing complete, efficient, and quality products and service to every customer.

© 2024 Uvital. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question