

Manuals.plus /
› Vicco /
› Vicco Sherry Dressing Table with LED Mirror - Instruction Manual

Vicco 57665

Vicco Sherry Dressing Table with LED Mirror

Instruction Manual - Model 57665

- Assembly
- Operation
- Overview
- Maintenance
- Safety Information
- Troubleshooting
- Setup & Specifications
- Support

1. PRODUCT OVERVIEW

The Vicco Sherry Dressing Table is designed to provide a functional and elegant space for your beauty routine. This model features a large mirror with integrated LED lighting and two modules with multiple drawers for organized storage of beauty products and accessories. Its modern design is intended to complement various home interiors.

The dressing table is constructed from easy-care particle board with a robust melamine resin coating, ensuring durability and ease of maintenance.



Image 1: The Vicco Sherry Dressing Table with LED mirror and multiple drawers.

2. SAFETY INFORMATION

Important! Retain these instructions for future reference. Read carefully!

TIPPING HAZARD!

Unanchored furniture can tip over. To prevent this furniture from tipping, it must be anchored to the wall. Use appropriate fastening hardware suitable for your home's walls. If you have questions, consult your local specialized dealer. Please follow each step of the instructions carefully.

3. SETUP AND ASSEMBLY

Assembly of the Vicco Sherry Dressing Table is required. Please ensure all components are present before beginning assembly. Refer to the detailed assembly instructions and mounting hardware included in the packaging.

3.1. Unpacking and Inspection

1. Carefully unpack all components from the packaging.
2. Verify that all parts listed in the assembly instructions are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.
3. Keep packaging materials until assembly is complete, in case any parts need to be returned.

3.2. Assembly Steps

Follow the step-by-step diagrams and instructions provided in the included assembly manual. General steps typically include:

1. Assemble the main frame of the dressing table.
2. Install the drawer slides and assemble the drawers.
3. Attach the drawer modules to the main frame.
4. Mount the LED mirror onto the designated area. Ensure all electrical connections for the LED lighting are securely made according to the instructions.
5. Secure the dressing table to the wall using the provided anti-tip hardware and appropriate wall anchors for your wall type. This step is crucial for safety.




Image 2: Detailed dimensions of the Vicco Sherry Dressing Table (158.2 cm width, 50.1 cm depth, 76 cm height for table, 110 cm width, 70

cm height for mirror).



Image 3: The dressing table shown with additional side shelving units, illustrating potential configurations.

4. OPERATION

4.1. LED Mirror

The integrated LED mirror provides optimal lighting for makeup application and grooming. To operate the LED light:

1. Ensure the dressing table is properly assembled and the LED mirror's power cable is connected to a suitable power outlet.
2. Locate the touch sensor switch on the mirror surface. This is typically a small circular icon.
3. Lightly touch the sensor to turn the LED light ON or OFF.
4. Some models may feature adjustable brightness or color temperature. If available, press and hold the touch sensor to cycle through brightness levels or tap repeatedly to change color temperature. Refer to the specific LED mirror

instructions for detailed functionality.



Image 4: A close-up view of the dressing table surface, highlighting the LED mirror and its touch sensor.

5. MAINTENANCE AND CARE

To ensure the longevity and appearance of your Vicco Sherry Dressing Table, follow these maintenance guidelines:

5.1. Cleaning

- **Surfaces:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or solvents, as these can damage the melamine coating.
- **Mirror:** Clean the mirror with a glass cleaner and a lint-free cloth. Do not spray cleaner directly onto the mirror; instead, apply it to the cloth first.
- **LEDs:** The LED lights are generally maintenance-free. If they become dusty, gently wipe them with a dry, soft cloth.

5.2. General Care

- Avoid placing hot items directly on the surface. Use coasters or protective pads.
- Protect the table from direct sunlight and excessive moisture to prevent warping or discoloration.
- Periodically check all screws and fittings and tighten them if necessary to maintain stability.
- Do not overload drawers to ensure smooth operation and prevent damage to the slides.

6. TROUBLESHOOTING

If you encounter issues with your Vicco Sherry Dressing Table, refer to the following common problems and solutions:

6.1. LED Mirror Not Lighting Up

- **Check Power Connection:** Ensure the power cable is securely plugged into both the mirror and a functional wall outlet.
- **Check Wall Outlet:** Test the wall outlet with another appliance to confirm it is receiving power.
- **Check Touch Sensor:** Ensure you are touching the sensor correctly. If the sensor is unresponsive, try cleaning the mirror surface around the sensor.
- **Internal Wiring:** If the above steps do not resolve the issue, there might be an internal wiring problem. Do not attempt to repair it yourself. Contact customer support.

6.2. Drawers Sticking or Not Closing Properly

- **Check Contents:** Ensure drawers are not overloaded or obstructed by items.
- **Check Alignment:** Verify that the drawer slides are correctly aligned and not bent or damaged.
- **Tighten Screws:** Check and tighten all screws on the drawer slides and drawer boxes.
- **Lubrication:** A small amount of silicone spray can be applied to the drawer slides to improve smoothness, if applicable to the slide type.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Vicco
Model Name	Sherry
Model Number	57665
Color	White/High Gloss White
Material	Engineered Wood (Particle Board with Melamine Coating)
Overall Dimensions (L x P x H)	158.2 x 50.1 x 76 cm
Mirror Dimensions (L x H)	110 x 70 cm
Number of Drawers	9
Item Weight	73.62 Kilograms
Assembly Required	Yes

Style	Modern
Energy Efficiency Class (LED)	F (View EPREL)




Image 5: Energy label for the LED lighting component, indicating class F and 6 kWh/1000h consumption.

8. WARRANTY INFORMATION

Vicco products are covered by standard consumer warranty rights as per local regulations. Please retain your proof of purchase for any warranty claims. For specific warranty details, refer to the documentation provided with your purchase or contact Vicco customer support.

9. CUSTOMER SUPPORT

If you have any questions regarding the assembly, operation, or maintenance of your Vicco Sherry Dressing Table, please contact Vicco customer support. You can typically find contact information on the manufacturer's website or on the packaging materials.

When contacting support, please have your model number (57665) and proof of purchase readily available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FX5HM723>

More documents and user manuals: <https://manuals.plus/>