

[Manuals.plus](#) /

› [Karl home](#) /

› Karl home 5-Tier Metal Storage Shelves User Manual (Model KH-SC-8634)

Karl home KH-SC-8634

Karl home 5-Tier Metal Storage Shelves User Manual

Model: KH-SC-8634

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Karl home 5-Tier Metal Storage Shelves. Please read these instructions carefully before assembly and use to ensure safe and efficient operation. This heavy-duty adjustable wire shelving unit is designed for versatile use in various environments such as garages, pantries, kitchens, and home offices.

SAFETY INFORMATION

Always assemble the shelf unit on a flat, stable surface. Do not overload shelves beyond their weight capacity. Keep fingers and other body parts away from moving parts when adjusting shelf heights. Use caution when moving the shelf unit on wheels to prevent tipping or collision.

PRODUCT COMPONENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Vertical Poles (4 sections per pole, totaling 4 poles)
- Wire Shelves (5 units)
- Plastic Sleeves/Clips (for securing shelves)
- Leveling Feet (4 units)
- Lockable Wheels (4 units)



Image: Fully assembled Karl home 5-Tier Metal Storage Shelves, showcasing its capacity and design.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward and typically requires two people for optimal ease. No complex tools are needed.

1. **Attach Leveling Feet or Wheels:** Screw the leveling feet or the lockable wheels into the bottom of the lower

vertical pole sections. If using wheels, ensure they are locked during assembly.

2. **Assemble Vertical Poles:** Connect the vertical pole sections by screwing them together. The poles are typically threaded for easy connection.
3. **Install Plastic Sleeves:** Snap the two-part plastic sleeves around the vertical poles at the desired height for the first shelf. Ensure the arrows on the sleeves point upwards and that they are placed at the same height on all four poles to ensure a level shelf.
4. **Place First Shelf:** Slide a wire shelf down over the top of the poles until it rests securely on the plastic sleeves. Apply even pressure to all corners to ensure it locks into place.
5. **Repeat for Remaining Shelves:** Continue installing plastic sleeves and placing shelves at your desired heights. The shelves are adjustable, allowing customization for various item sizes.
6. **Final Check:** Once all shelves are in place, gently push down on each shelf to ensure it is fully seated and stable. If using wheels, unlock them for mobility or keep them locked for stationary use.

72.83" H 5 TIER

WIRE SHELVING RACK WITH WHEELS




Image: Step-by-step visual guide for assembling the shelving unit, including pole connection, clip placement, and wheel attachment.

Karl home 5-Tier Metal Storage Shelves

46.06"W x17.72"D x 72.83"H 5 Tier ADJUSTABLE METAL STORAGE SHELVES

1.Crafted from premium iron with a powder-coated black finish, this metal shelving unit features thickened frames, ensuring durability and resistance to rust.

2.With 5 tiers of freely adjustable shelf heights, it's perfect for storing items of various sizes. Equipped with leveling feet and wheels, it offers both stability and ensuring durability and resistance to rust.



Image: Visual representation of the screw-free and nut-free assembly process, highlighting the connection of poles and shelf clips.

OPERATING INSTRUCTIONS

Adjusting Shelf Height

The shelves are fully adjustable to accommodate items of various sizes. To adjust a shelf:

1. Remove all items from the shelf you wish to adjust.
2. Carefully lift the shelf off the plastic sleeves.
3. Remove the plastic sleeves from the poles.
4. Re-position the plastic sleeves at the desired new height, ensuring they are level on all four poles.
5. Place the shelf back onto the sleeves, pressing down firmly to secure it.

-STATIONARY-


699

LBS

-DYNAMIC-

349

LBS



WITH WHEEL
TOTAL LOAD CAPACITY

Image: Demonstration of the adjustable shelf feature, allowing users to customize shelf spacing.

EXCEPTIONAL QUALITY IN EVERY DETAIL!




01

1.Thickened Mesh for Durability



02

2.Powder Coating, Rust-Resistant



03

3.Enhanced Load-Bearing,
Handles Heavy Items Easily

Image: Visual comparison of two shelving units demonstrating the height adjustability for various items.

Using the Wheels

The shelving unit comes with four lockable wheels for easy mobility. To move the unit, ensure all wheel locks are disengaged. To keep the unit stationary, engage the locks on all four wheels.



Image: Detail of the smooth-rolling, lockable wheels, emphasizing mobility and stability.

MAINTENANCE

Regular maintenance will prolong the life and appearance of your shelving unit.

- **Cleaning:** Wipe down the shelves and poles with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Avoid abrasive cleaners or harsh chemicals, as these can damage the powder-coated finish.
- **Inspection:** Periodically check all connections and ensure shelves are securely seated on their clips. Tighten any loose components.
- **Rust Prevention:** The unit features a rust-resistant powder coating. To maintain this, avoid prolonged exposure to excessive moisture or corrosive substances.

TROUBLESHOOTING

Shelf is wobbly or unstable:

Ensure all plastic sleeves are installed at the same height on each pole and that the shelf is fully seated. Check that the leveling feet are properly adjusted or that the wheels are locked if stationary.

Difficulty adjusting shelf height:

Ensure the shelf is completely empty before attempting to lift it. If clips are stuck, gently wiggle them to loosen before removing.

Wheels not rolling smoothly:

Check for debris caught in the wheels. Ensure wheel locks are fully disengaged.

SPECIFICATIONS

Feature	Detail
Model Name	KH-SC-8634

Feature	Detail
Material	Alloy Steel
Finish Type	Powder Coated Black
Number of Shelves	5
Product Dimensions (D x W x H)	46.1" x 17.7" x 72.8" (117cm x 45cm x 185cm)
Mounting Type	Freestanding
Special Features	Adjustable shelves, Lockable wheels, Leveling feet
Assembly	Simple assembly required; no complex tools needed.
Static Load Capacity (approx.)	699 lbs (with leveling feet)
Dynamic Load Capacity (approx.)	349 lbs (with wheels)

Easy to Assemble

It is recommended that 2 people work together




Image: Key dimensions of the 5-tier shelving unit for planning placement.

72.83''H 5TIER

WIRE SHELVING RACK WITH WHEELS




Image: Static and dynamic load capacities of the shelving unit.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official Karl home website. Contact information for support is typically available on the product packaging or the manufacturer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question