

SEDETA B0FX9WPTW1

SEDETA 68.9" Standing L Shaped Gaming Desk Instruction Manual

Model: B0FX9WPTW1

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your new SEDETA 68.9" Standing L Shaped Gaming Desk. Please read this manual thoroughly before assembly and use to ensure safe and efficient operation. Keep this manual for future reference.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before beginning assembly. Do not use damaged parts.
- Assembly requires at least two adults. Some components are heavy and may require assistance to lift and position.
- Use only the provided hardware. Using incorrect screws or tools may damage the product.
- Follow assembly steps precisely. Incorrect assembly can lead to instability and potential injury. Pay close attention to screw types and sizes as indicated in the instructions.
- Do not overtighten screws, especially when working with engineered wood, as this can cause cracking or stripping.
- Keep children and pets away from the assembly area. Small parts can be a choking hazard.
- Ensure the desk is placed on a level surface to prevent wobbling. Adjustable leg pads can be used to stabilize on uneven floors.
- Do not exceed the maximum load capacity of 352 lbs for the adjustable height section.
- When adjusting the desk height, ensure there are no obstructions above or below the desktop. Keep hands and objects clear of moving parts.
- The built-in power strip is for indoor use only. Do not expose to moisture. Ensure the on-off switch is used to power off when not in use for safety.
- Refer to the user manual for safety instructions and warnings.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact customer support.

- Desktop Panels (L-shaped sections)
- Adjustable Height Legs (Motorized)
- Hutch Components (Shelves, side panels, acrylic doors, pegboard)
- Drawer Components (3 wood drawers)
- Metal Frame Supports
- Built-in Power Strip (with 4 AC outlets & 2 USB ports)
- LED Light Strips (RGB, with remote/APP control)
- Hardware Kit (screws, bolts, Allen keys, hooks, adjustable leg pads)
- Instruction Manual

ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 2 hours for two adults. Carefully follow the numbered steps in the provided instruction booklet. It is highly recommended to have a second person assist with lifting and aligning larger components.

General Assembly Tips:

- Unpack all components and lay them out on a soft, clean surface to prevent scratches.
- Identify all hardware by matching them to the labels in the instruction manual. Note that some reviews indicate potential mislabeling of screws (e.g., 'W' vs. 'X' screws); always cross-reference with the visual diagrams and screw sizes to ensure correct usage.
- Do not fully tighten all screws until instructed, as some steps require slight adjustments for proper alignment.
- Exercise caution when tightening screws into engineered wood to prevent chipping or cracking. Hand-tightening is often sufficient.

Visual Assembly Aid:

The following video demonstrates the assembly process for a similar L-shaped standing desk. While specific steps may vary, it provides a general overview of the construction and lifting device installation.

Your browser does not support the video tag.

Video: Standing Desk - Lifting Device Installation. This video illustrates the assembly of the lifting mechanism and general desk structure. Refer to your specific manual for exact steps and part identification.

Key Assembly Steps (Summary):

1. **Assemble the Metal Frame:** Connect the main metal supports for the L-shaped desk sections.
2. **Attach Adjustable Legs:** Secure the motorized adjustable height legs to the main desk frame.
3. **Install Desktop Panels:** Carefully place and secure the L-shaped desktop panels onto the assembled frame.
4. **Construct Hutch:** Assemble the hutch components, including shelves, side panels, and acrylic doors. Attach the pegboard.
5. **Assemble Drawers:** Construct the three wood drawers and install them into their designated sections.
6. **Install Power Strip and LED Lights:** Integrate the built-in power strip and attach the RGB LED light strips according to the instructions. Ensure all wiring is neatly managed.
7. **Final Adjustments:** Ensure all connections are secure. Use adjustable leg pads to level the desk.

OPERATING INSTRUCTIONS

Adjustable Height Function:

Your SEDETA desk features an electric adjustable height mechanism with a sleek LED display. The height can be adjusted from 28.3" to 43.3".

- **Up/Down Control:** Use the ▲ and ▼ buttons on the control panel to raise or lower the desk to your desired height.
- **Memory Presets:** The desk offers 3 customizable height presets. To save a height, adjust the desk to the desired position, then press and hold one of the numbered preset buttons (1, 2, or 3) until the display flashes or beeps, indicating the height is saved. To recall a saved height, simply press the corresponding preset button.
- **Safety:** Always ensure the path of the desk is clear of obstructions during height adjustments. The motor operates quietly for minimal disturbance.



Image: The desk's dimensions and adjustable height range (28.3" to 43.3") are shown, along with a maximum load capacity of 352 lbs.



Image: This illustration demonstrates the desk being used in both sitting (28.3" height) and standing (43.3" height) positions, highlighting its adjustable feature.

LED Light Strips:

The RGB LED light strips offer over 60,000 colors and 29 flashing modes, controllable via an APP or remote control. They also feature a music sync function with a built-in adjustable microphone and a timer function.

- **Power On/Off:** Use the dedicated switch or APP/remote to turn the LED lights on or off.
- **Color/Mode Selection:** Use the APP or remote control to select desired colors, adjust brightness, and choose from various flashing modes.
- **Music Sync:** Activate the music sync function via the APP. The lights will change rhythmically with sound detected by the built-in microphone.
- **Timer Function:** Set a timer for the lights to automatically turn off using the APP.

Built-in Power Strip:

The desk includes a recessed power strip with 4 AC outlets and 2 USB ports for convenient charging of your devices.

- **Usage:** Plug in your gaming gear, tablet, printer, or phone directly into the outlets or USB ports.
- **On-Off Switch:** A dedicated on-off switch allows you to power off all connected devices with one button, enhancing electrical safety.

Recessed Power Strip

Include 4 AC Outlets and 2 USB Ports



4AC Outlets
| 120V / 12A |



2 USB Ports
| 5V / 2A |



Power Switch
ON/OFF



Image: A close-up of the recessed power strip, showing 4 AC outlets (120V/12A) and 2 USB ports (5V/2A), along with an on/off power switch.

MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Dusting:** Regularly dust the desk and hutch shelves to prevent buildup.
- **Cable Management:** Periodically check and organize cables to prevent tangles and damage, especially around moving parts of the adjustable legs.
- **Hardware Check:** Occasionally check all screws and bolts to ensure they remain tight. Retighten if necessary, but do not overtighten.

- **Motor Care:** The high-quality motor is designed for durability. Avoid overloading the desk or forcing it to move if obstructed.

TROUBLESHOOTING

- **Desk Not Adjusting Height:**
 - Check if the power cord is securely plugged into both the desk and a working wall outlet.
 - Ensure the power strip's on-off switch is in the "on" position.
 - Verify there are no obstructions preventing the desk from moving up or down.
 - If the motor makes a sound but the desk doesn't move, check for any jammed items or excessive weight.
- **LED Lights Not Working:**
 - Check the power connection for the LED strips.
 - Ensure the remote control has working batteries or the APP is correctly connected via Bluetooth/Wi-Fi.
- **Desk Wobbles:**
 - Ensure the desk is on a level surface.
 - Adjust the leg pads at the bottom of the desk legs to compensate for uneven flooring.
 - Check that all assembly screws are securely tightened.
- **Drawers Not Sliding Smoothly:**
 - Ensure the drawer slides are properly aligned and free of debris.
 - Verify that the drawers are not overloaded.
- **Missing or Damaged Parts:**
 - If your item arrives damaged, scratched, or with missing parts, please contact SEDETA customer support for assistance.

SPECIFICATIONS

Brand	SEDETA
Model	B0FX9WPTW1
Type	L-Shaped Standing Gaming/Office Desk
Color	White
Material	P2 Particle Board (Engineered Wood), Metal Frame
Product Dimensions (D x W x H)	21.7"D x 68.9"W x 28.3"H
Adjustable Height Range	28.3" to 43.3"
Maximum Load Capacity	352 lbs
Number of Drawers	3
Power Strip	4 AC Outlets (120V/12A), 2 USB Ports (5V/2A), On-Off Switch
LED Lights	RGB, 60000+ colors, 29 modes, APP/Remote control, Music Sync, Timer
Assembly Required	Yes (Tools included)




Image: This diagram provides a comprehensive view of the desk's dimensions, including the 68.9" main desktop length, 21.7" depth, 47.2" side desktop length, and the hutch's 31" height with various shelf and pegboard measurements. The adjustable height range of 28.3" to 43.3" and maximum load capacity of 352 lbs are also indicated.

Large Storage Capacity



Top Open Shelf -----	1	3 Drawers -----	7 8 9
2 Display Cabinets -----	2 3	6 S Hooks -----	5
Long Pegboard -----	4	2 L Hooks -----	6

Image: This image highlights the desk's extensive storage features, including a top open shelf, two display cabinets, a long pegboard, six S-hooks, two L-hooks, and three drawers, all clearly numbered for identification.

WARRANTY AND SUPPORT

SEDETA is committed to providing high-quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any issues, missing parts, or concerns, please contact SEDETA customer support through the retailer where the product was purchased. They will assist with replacements or troubleshooting as needed.

For further assistance, you may visit the official SEDETA store: [SEDETA Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question