

[manuals.plus](#) /› [Jocoevol](#) /› [Jocoevol Modern White 8-Drawer Dresser Instruction Manual \(Model WG-0617\)](#)

Jocoevol WG-0617

Jocoevol Modern White 8-Drawer Dresser

Model: WG-0617

1. INTRODUCTION

Thank you for choosing the Jocoevol Modern White 8-Drawer Dresser. This manual provides essential information for the safe assembly, proper use, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This dresser is designed to offer ample storage and complement various room settings, including bedrooms, living rooms, and hallways.

2. SAFETY INFORMATION

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- Do not allow children to climb on or play with the dresser.
- **Anti-Tip Device:** It is crucial to install the included anti-tip device to prevent serious injury from tipping furniture. Follow the instructions provided with the anti-tip kit.

Image: Anti-Collapse Design. This image illustrates the importance of installing the anti-tip device to secure the dresser to the wall, preventing it from tipping over, especially when children are present. The top diagram shows correct installation with a child safely interacting with the dresser, while the bottom diagram shows an unsecured dresser tipping, posing a hazard.

- Distribute weight evenly in drawers. Do not overload drawers.
- Always open only one drawer at a time to maintain stability.

3. SETUP (ASSEMBLY INSTRUCTIONS)

Before you begin, ensure you have all parts and hardware as listed in your packaging. If any parts are missing or damaged, please contact customer support.

3.1 Unpacking and Preparation

- Carefully unpack all components from the box.
- Lay out all parts on a clean, soft, and flat surface to prevent damage.

- Identify all parts and hardware using the included parts list.

3.2 Assembly Steps

Follow the step-by-step diagrams and instructions provided in your physical assembly guide. General steps typically include:

1. Assemble the main frame of the dresser.
2. Install the drawer slides onto the dresser frame.
3. Assemble each drawer box.
4. Attach the drawer fronts to the assembled drawer boxes.
5. Insert the assembled drawers into the dresser frame.
6. Install the anti-tip device to secure the dresser to a wall.



Image: Dresser with Drawers Open. This image displays the Jocoevol 8-drawer dresser with all drawers extended, showcasing the internal storage capacity and smooth operation of the drawer slides. The drawers are filled with various items, demonstrating its organizational potential.

4. OPERATING INSTRUCTIONS

4.1 Drawer Usage

The dresser features eight smooth-gliding drawers designed for easy access and organization. To open a drawer, gently pull the top edge of the drawer front. To close, push firmly until it is fully seated.



Image: Drawer Interior. This image provides a detailed view inside an open drawer, showing how various personal items such as jewelry, headphones, and small books can be neatly stored. It highlights the depth and usability of the drawer space.

4.2 Classified Storage

Utilize the spacious drawers for classified storage of clothing, accessories, and other personal items. Consider using drawer organizers (not included) to maximize space and maintain order.



Image: Classified Storage. This image displays three open drawers, each containing neatly folded and organized items such as socks and underwear. It illustrates the dresser's capability for classified storage, making small items easily accessible.

5. MAINTENANCE

5.1 Cleaning

To clean the dresser, wipe with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish. Dry immediately with a clean, soft cloth.

5.2 General Care

- Keep the dresser away from direct sunlight and heat sources to prevent warping or discoloration.
- Avoid placing hot or wet items directly on the surface. Use coasters or protective pads.
- Periodically check all hardware connections and tighten if loose.

6. TROUBLESHOOTING

6.1 Drawers Do Not Slide Smoothly

- **Check Alignment:** Ensure the drawer slides are correctly aligned and installed on both the drawer box and the dresser frame.
- **Obstructions:** Look for any objects or debris obstructing the drawer slides.
- **Hardware Tightness:** Verify that all screws securing the slides are tight.



Image: Drawer Slides. This close-up image highlights the ball-bearing drawer slide mechanism, demonstrating the robust

construction designed for smooth and quiet operation. It shows the metal tracks and attachment points.

6.2 Dresser Feels Unstable

- **Re-tighten Hardware:** Ensure all assembly screws are fully tightened.
- **Level Surface:** Place the dresser on a flat, level surface.
- **Anti-Tip Device:** Confirm the anti-tip device is correctly installed and secured to the wall.

7. SPECIFICATIONS

Brand	Jocoevol
Model Name	WG-0617
Product Dimensions	15.3"D x 55.2"W x 32.3"H
Color	White
Material	Engineered Wood
Number of Drawers	8
Item Weight	108.6 pounds
Assembly Required	Yes

Image: Product Size Diagram. This diagram provides a clear visual representation of the dresser's overall dimensions: 55.2 inches wide, 32.3 inches high, and 15.3 inches deep. It also details the internal dimensions of a single drawer, including its height, width, and depth, which are crucial for planning storage.

8. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact Jocoevol customer service directly. You can often find support contact details on the brand's official website or through your retailer.

For assistance, please visit the [Jocoevol Store on Amazon](#).