

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bazivve](#) /

› [Bazivve RQ6900 7D Rotary Electric Shaver for Women User Manual](#)

Bazivve RQ6900

Bazivve RQ6900 7D Rotary Electric Shaver for Women User Manual

Model: RQ6900 | Brand: Bazivve

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Bazivve RQ6900 7D Rotary Electric Shaver. Please read this manual thoroughly before initial use and retain it for future reference. This device is designed for efficient hair removal on various body areas, offering both wet and dry shaving capabilities.

SAFETY INFORMATION

- Always ensure the shaver is fully charged before use to maintain optimal performance.
- Do not attempt to disassemble or repair the shaver yourself. Contact customer support for assistance.
- Keep the device away from children.
- When using the shaver for the first time on delicate areas like underarms, proceed with care as slight irritation may occur.
- Avoid using the shaver on irritated, damaged, or infected skin.
- Ensure the charging port is dry before connecting the USB charging cable.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Bazivve RQ6900 7D Rotary Electric Shaver Unit
- USB Charging Cable
- Cleaning Brush
- User Manual



Image: The Bazivve RQ6900 electric shaver, its retail packaging, and included accessories like the USB charging cable and cleaning brush.

PRODUCT OVERVIEW

The Bazivve RQ6900 features a 7D rotary shaving system designed for efficient and comfortable hair removal.

- **7D Rotary Shaving Heads:** Equipped with seven flexible rotary blades that adapt to body contours, covering a wider surface area for faster hair removal.
- **Precision Blades:** Thinner and sharper blades ensure a close shave, effectively cutting fine hairs at the root.
- **Wet/Dry Use:** IPX7 waterproof rating allows for comfortable shaving in the shower or bath, as well as dry shaving.
- **LED Display:** Shows remaining battery power (e.g., '99' for fully charged), low battery reminders, and washing reminders.
- **USB Rechargeable:** A 1.5-hour charge provides up to 90 minutes of cordless operation.
- **Travel Lock:** Prevents accidental activation during travel.



Image: A detailed view of the 7D rotary shaver heads, illustrating their design for efficient and protective hair removal across different body areas.



Image: The 7D rotary shaver in use on a leg, showcasing its wider shaving surface for quicker hair removal compared to a conventional 5-head shaver.

SETUP

Charging the Shaver

1. Ensure the shaver is dry before charging.
2. Connect the USB charging cable to the shaver's charging port.
3. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
4. The LED display will indicate charging status. A full charge takes approximately 1.5 hours.
5. Once fully charged, the display will show '99'. Disconnect the shaver from the power source.

Activating Travel Lock

To prevent accidental activation, the shaver features a travel lock.

- To activate or deactivate the travel lock, press and hold the power button for 3 seconds.
- The LED display will indicate when the lock is active or deactivated.

OPERATING INSTRUCTIONS

General Shaving Tips

- Ensure your skin is clean before shaving.
- For optimal results, hold the shaver at a 90-degree angle to the skin.
- Move the shaver in small, circular motions or against the direction of hair growth.
- The shaver is suitable for both long and short hair. For longer hair, the precision trimmer blades will perform the initial trim, followed by the ultra-close rotary shaver heads for refinement.

PERFECT FOR BOTH LONG/SHORT HAIR

1st Trim

Precision Trimmer Blades



Trim & Refine

Ultra-Close Rotary Shaver Head



Image: An illustration demonstrating the shaver's dual action for long and short hair, utilizing precision trimmer blades for initial cutting and rotary heads for a smooth finish.

Wet Shaving

- Apply shaving cream, gel, or foam to the desired area.
- Shave as usual. The IPX7 waterproof design allows for safe use in the shower or bath.
- Rinse the shaver head under running water during and after use to remove hair and lather.



IPX7 WATERPROOF

Can be used wet or dry



Image: The electric shaver being used in a wet environment, highlighting its IPX7 waterproof feature for wet shaving.

Dry Shaving

- Ensure your skin is completely dry before dry shaving.
- Shave directly on the skin.

Shaving Different Body Areas

The Bazivve RQ6900 is suitable for legs, arms, back, neck, bikini area, and face.

- **Legs and Arms:** Use long, sweeping strokes or circular motions.
- **Bikini Area and Underarms:** Due to the sensitive nature of these areas, use gentle pressure and short, controlled strokes. For first-time users, slight irritation may occur. Exercise extra caution when shaving underarms.
- **Face:** Use gentle, circular motions.



PERFECT FIT TO THE SKIN

Maximum skin contact for an ultra-smooth shave

Image: The electric shaver being used on an underarm, illustrating its ergonomic design for maximum skin contact and a smooth shave. A caution advises careful use in this sensitive area.

MAINTENANCE

Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene. The LED display will provide a washing reminder when cleaning is recommended.

1. Turn off the shaver and disconnect it from any power source.
2. Gently twist and remove the shaver head from the main body.
3. Disassemble the individual rotary blades from the shaver head.
4. Use the provided cleaning brush to remove any trapped hairs from the blades and the shaver head.
5. Rinse the shaver head and individual blades thoroughly under running water.
6. Allow all parts to air dry completely before reassembling.
7. Reattach the blades and shaver head to the main body.



Image: A visual guide to cleaning the shaver, detailing the removal of the shaver head, disassembly of blades, and rinsing under water.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Low battery or travel lock is active.	Charge the shaver fully. Deactivate the travel lock by pressing and holding the power button for 3 seconds.
Poor shaving performance.	Blades are clogged with hair or battery is low.	Clean the shaver heads thoroughly. Ensure the shaver is fully charged.
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure gentle pressure and proper technique. For sensitive areas, consider using shaving cream or gel. If irritation persists, discontinue use.
Shaver not charging.	Faulty cable, power source, or charging port is wet.	Check the USB cable and power adapter. Ensure the charging port is completely dry. Try a different USB port or adapter.

SPECIFICATIONS

- Model Name:** LADY SHAVER
- Item Model Number:** RQ6900
- Brand:** Bazivve
- Power Source:** Battery Powered (Rechargeable via USB)
- Special Features:** Battery Indicator, Rechargeable, Travel Lock, Waterproof (IPX7)
- Recommended Uses:** Legs, Arms, Back, Neck, Bikini, Face
- Package Dimensions:** 6.06 x 4.84 x 3.42 inches
- Item Weight:** 10.09 ounces

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Bazivve customer service through the retailer

where the product was purchased or refer to the official Bazivve website for contact details.