

[Manuals.plus](#) /

> [Aoxun](#) /

> Aoxun 70-inch Fireplace TV Stand with LED Lights User Manual

Aoxun B0FXF93MPY

Aoxun 70-inch Fireplace TV Stand with LED Lights User Manual

Model: B0FXF93MPY

1. INTRODUCTION

Thank you for purchasing the Aoxun 70-inch Fireplace TV Stand with LED Lights. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read these instructions thoroughly before beginning assembly or operation and retain them for future reference.



Image 1: Aoxun 70-inch Fireplace TV Stand with a television on top, showcasing the integrated electric fireplace and various storage compartments. The stand is black with metallic accents.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all safety warnings and instructions before using this product. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- Always unplug the fireplace from the power outlet before cleaning or performing any maintenance.
- Do not operate the fireplace with a damaged cord or plug, or if the heater has malfunctioned, been dropped, or damaged in any manner.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.

- This TV stand is designed for indoor use only.
- Ensure the TV stand is placed on a level, stable surface to prevent tipping.
- Do not overload the TV stand with weight exceeding its capacity. Refer to specifications for weight limits.
- Keep children and pets away from the fireplace and electrical components.

3. PACKAGE CONTENTS

Your Aoxun Fireplace TV Stand is shipped in two separate packages. Please ensure you have received both packages and all components are present before beginning assembly. Carefully unpack all parts and hardware. If any parts are missing or damaged, do not attempt to assemble the product. Contact customer support for assistance.



Image 2: A diagram illustrating the overall product dimensions and explicitly stating that the item comes in two separate packages.

Typical components include:

- TV Stand Panels (top, bottom, sides, shelves)
- Electric Fireplace Insert

- LED Light Strips and Controller
- Hardware Pack (screws, dowels, cam locks, etc.)
- Remote Control for Fireplace
- Instruction Manual

4. PRODUCT DIMENSIONS

Refer to the diagram below for detailed product dimensions to ensure proper fit in your desired location.



Image 3: A detailed diagram showing the dimensions of the Aoxun TV stand and the separate fireplace insert. The TV stand measures approximately 70 inches in width, 16.8 inches in depth for the main base, and 23.4 inches in total height including the top shelf. The fireplace insert is 36 inches wide and 13.8 inches high.

Overall TV Stand Dimensions (Approximate): 70 inches (Width) x 16.8 inches (Depth) x 23.4 inches (Height)

Fireplace Insert Dimensions (W x H): 36 x 13.8 inches

5. ASSEMBLY AND SETUP

Assembly of the Aoxun Fireplace TV Stand requires two adults. Follow the step-by-step instructions provided in the separate assembly guide included in your package. Ensure all hardware is securely fastened before placing any items on the stand or operating the fireplace.

1. **Prepare Workspace:** Clear a spacious area and lay out all components on a soft, clean surface to prevent scratches.
2. **Assemble TV Stand Frame:** Follow the numbered steps in the assembly guide to construct the main frame of the TV stand.
3. **Install Shelves and Doors:** Attach internal shelves and hinged doors as instructed. The stand features storage cabinets with shelves.
4. **Integrate Fireplace Insert:** Carefully slide the electric fireplace insert into its designated opening in the TV stand. Ensure it is seated correctly and secured if applicable.
5. **Connect LED Lights:** Attach the LED light strips to the designated areas, typically under the top shelf or within compartments. Connect them to the controller.
6. **Cable Management:** Utilize the integrated cable management holes to route and organize power cords and media cables, keeping them tidy and out of sight.
7. **Final Placement:** Position the assembled TV stand on a level surface.



Storage Cabinet
with shelves & hinged doors



Cable Management Hole
keep clean & tidy



Stainless Steel Bracket
much more storage space

Image 4: This image highlights key features for setup and use, including the remote control, a storage cabinet with internal shelves and hinged doors, a circular cable management hole for organization, and the stainless steel brackets supporting the upper shelf.

6. OPERATING INSTRUCTIONS

6.1 Electric Fireplace Operation

The electric fireplace can be operated using the control panel on the unit or the included remote control.



Remote Control
Easy To Use



Temperature Adjustable
62°F to 82°F



Timing setting
1H-8H



Flame Color Adjustable
12 Flame Colors



Energy Saving
750W/1500W




Brightness Adjustable
5 Levels Flame Brightness



Air Outlet



Crystal Stone



**Tempered
Glass Screen**



Mechanical Keying

Image 5: A detailed view of the electric fireplace insert, illustrating its various features such as remote control functionality, temperature adjustment (62°F to 82°F), timing settings (1H-8H), 12 flame color options, energy-saving modes (750W/1500W), 5 levels of flame brightness, an air outlet, crystal stone media, a tempered glass screen, and mechanical keying for manual controls.

- **Power On/Off:** Press the power button on the control panel or remote to turn the fireplace on or off.
- **Temperature Adjustment:** Use the temperature controls to set the desired heat output between 62°F and 82°F.
- **Timing Setting:** Set an automatic shut-off timer from 1 to 8 hours.
- **Flame Color Adjustment:** Choose from 12 different flame colors to match your ambiance.
- **Flame Brightness Adjustment:** Adjust the flame brightness through 5 levels (L1 to L5).
- **Energy Saving:** Select between 750W and 1500W heating modes for energy efficiency.

5 LEVELS FLAME BRIGHTNESS



12 FLAME COLORS ADJUSTABLE




Image 6: This image demonstrates the 5 distinct levels of flame brightness, ranging from dim (L1) to bright (L5), and showcases the 12 available flame colors, offering a variety of aesthetic options for the electric fireplace.

6.2 LED Lights Operation

The integrated LED lights enhance the ambiance of your entertainment center. They are controlled separately, often via a dedicated remote or button.



Image 7: The Aoxun TV stand illuminated with blue LED lights and matching blue electric fireplace flames, demonstrating the customizable ambient lighting feature.

- **Power On/Off:** Use the dedicated button or remote for the LED lights to turn them on or off.
- **Color Selection:** Choose from 12 available LED colors to create your desired atmosphere.
- **Brightness/Mode:** Adjust brightness or select different lighting modes if available.

7. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your Aoxun Fireplace TV Stand.

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Cleaning the Fireplace:** Ensure the fireplace is unplugged and cool before cleaning. Use a soft, damp cloth to wipe the exterior. Do not spray water directly onto the unit.

- **Dusting:** Regularly dust the unit to prevent buildup, especially around ventilation openings.
- **Cord Inspection:** Periodically inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

8. TROUBLESHOOTING

If you encounter issues with your Aoxun Fireplace TV Stand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, tripped circuit breaker, faulty plug/cord.	Check power outlet, reset circuit breaker, ensure plug is fully inserted.
No heat from fireplace.	Heat function off, thermostat setting too low.	Activate heat function, increase temperature setting.
LED lights not working.	Loose connection, remote battery dead, faulty controller.	Check all connections, replace remote battery, contact support if issue persists.
Stand is wobbly.	Uneven surface, loose assembly hardware.	Move to a level surface, tighten all assembly screws.

9. PRODUCT SPECIFICATIONS

Brand: Aoxun

Model: B0FXF93MPY

Color: Black

Overall Product Dimensions (Approximate L x W x H): 70 x 16.8 x 23.4 inches

Item Weight: 98.1 pounds

Fireplace Size: 36 inches

Heating Power: 750W / 1500W (Energy Saving Modes)

Temperature Range: 62°F to 82°F

Timer Settings: 1H - 8H

Flame Colors: 12 adjustable colors

Flame Brightness: 5 levels

LED Lights: 12 colors for choice

Material: Wood composite, tempered glass, stainless steel

UPC: 799413421280

10. WARRANTY AND CUSTOMER SUPPORT

Aoxun products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official Aoxun website. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Aoxun customer support.

Contact Information: Please refer to your purchase documentation or the Aoxun official website for the most current customer support contact details.



© 2025 Aoxun. All rights reserved.