

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OUKITEL](#) /

› **OUKITEL Smartwatch User Manual - Bluetooth Call, 1.91" HD Screen, 100+ Sports Modes, IP68 Waterproof**

OUKITEL B0FXGFXMT5

OUKITEL Smartwatch User Manual

Model: B0FXGFXMT5

INTRODUCTION

Thank you for choosing the OUKITEL Smartwatch. This device is designed to enhance your daily life with smart features, comprehensive health monitoring, and various sports modes. This manual provides detailed instructions to help you set up, operate, and maintain your smartwatch effectively. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

WHAT'S IN THE BOX

- OUKITEL Smartwatch
- Charging Cable
- User Manual

SETUP GUIDE

1. Charging the Smartwatch

Before first use, fully charge your smartwatch. Connect the magnetic charging cable to the charging contacts on the back of the watch and plug the USB end into a power adapter (not included) or a computer's USB port. A full charge typically takes about 2.5 hours.



Image: The OUKITEL Smartwatch connected to its magnetic charging cable, displaying a charging icon on its screen.

A full charge provides approximately 5-10 days of normal usage and up to 30 days in standby mode.

2. App Installation and Pairing

To unlock all features, download the companion app (e.g., "GloryFit" as mentioned in reviews) on your smartphone. The app is compatible with iOS 9.0+ and Android 6.0+ devices.

1. Scan the QR code in the user manual or search for the app name in your phone's app store (Apple App Store for iOS, Google Play Store for Android).
2. Install and open the app.
3. Follow the on-screen instructions to create an account and set up your profile.

4. Enable Bluetooth on your smartphone.
5. In the app, search for your OUKITEL Smartwatch and select it to pair. Confirm the pairing request on both your phone and the smartwatch.

Fonctions de Service Intelligentes

Effectuer/Recevoir des Appels Téléphoniques



Notification D'information



Assistant vocal IA

Hei, Siry, What's the weather like today?

Hei, Siry, will it rain today?




Image: The OUKITEL Smartwatch screen showing an incoming call interface, illustrating its Bluetooth call functionality and readiness for connection.

Basic Navigation

The OUKITEL Smartwatch features a 1.91-inch HD touchscreen for intuitive control. Swipe left, right, up, or down to navigate through menus and functions. Press the side button to return to the home screen or access the app list.

Smart Functions

- **Bluetooth Calls:** Once paired with your phone, you can make and receive calls directly from your smartwatch. Access the dial pad, call history, or contacts on your watch.
- **AI Voice Assistant:** Utilize the integrated AI voice assistant (e.g., Alexa) to perform voice commands such as asking questions, checking the weather, or initiating calls.
- **Notifications:** Receive real-time notifications for calls, SMS, and various social media apps (WhatsApp, Facebook, etc.) directly on your wrist.
- **Music Control:** Control music playback on your smartphone (play, pause, skip tracks) directly from your smartwatch.
- **Other Functions:** Includes weather forecasts, stopwatch, timer, alarm clock, remote camera control, and a "Find My Phone" feature.



Image: A composite image showing the smartwatch interface for making/receiving calls, displaying app notifications, and interacting with the AI voice assistant.

Health Monitoring

The smartwatch provides 24/7 health tracking to help you monitor your well-being.

- **Heart Rate Monitoring:** Continuously tracks your heart rate throughout the day. View real-time data and historical trends in the app.
- **Blood Oxygen (SpO2) Monitoring:** Measures your blood oxygen saturation levels.
- **Sleep Tracking:** Analyzes your sleep patterns, including deep sleep, light sleep, and awake times, to help improve sleep quality.
- **Stress Monitoring:** Monitors your stress levels.



Image: A composite image showing the smartwatch displaying heart rate, blood oxygen levels, and sleep duration data, alongside a person running outdoors.

Sports Modes and Activity Tracking

The smartwatch offers over 100 indoor and outdoor sports modes, including walking, running, cycling, hiking, basketball, and football. It records exercise data such as steps, heart rate, and calories burned.



Image: A person on a bicycle, with the smartwatch displaying various sports modes and an activity analysis screen showing duration, heart rate, calories, and steps.

Customization

Personalize your smartwatch with over 100 built-in watch faces. You can also upload your favorite photos to create unique custom dials through the companion app. The watch supports 6 different menu styles.



Image: The OUKITEL Smartwatch showcasing different menu styles and customizable watch faces, including options to use personal photos.

MAINTENANCE

Water Resistance (IP68)

The OUKITEL Smartwatch is IP68 waterproof, meaning it is resistant to splashes, rain, and sweat. It can withstand daily water exposure like hand washing. However, it is **not suitable** for hot baths, saunas, diving, or exposure to corrosive liquids like seawater.

SUIVI D'ACTIVITÉ TOUTE LA JOURNÉE

Steps: 6550 Steps

Distance: 320 Kcal

Calories: 1.26 Km



Image: The OUKITEL Smartwatch highlighting its IP68 water resistance with icons representing protection against rain, hand washing, and perspiration.

Cleaning and Care

- Wipe the watch and strap regularly with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive materials.
- Ensure the charging contacts are clean and dry before charging.

TROUBLESHOOTING

Problem	Possible Solution
Smartwatch won't turn on.	Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
Cannot pair with smartphone.	Ensure Bluetooth is enabled on your phone. Make sure the smartwatch is within range of your phone. Restart both your phone and the smartwatch. Check if the app is updated to the latest version. Forget the device in your phone's Bluetooth settings and try pairing again through the app.
Inaccurate health data readings.	Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensor on the back of the watch. Avoid excessive movement during measurements.
Screen turns on too frequently (as noted in reviews).	Check the watch settings for "Raise to Wake" or "Wrist Sense" features. You may be able to adjust sensitivity or disable it if it's causing unwanted screen activation.

Problem	Possible Solution
Notifications not appearing.	Ensure the smartwatch is connected to your phone via Bluetooth. Check notification permissions for the app on your phone. Verify that notification settings are enabled within the smartwatch app.

SPECIFICATIONS

Brand	OUKITEL
Model Number	B0FXGFXMT5
Operating System	iOS, Android
Screen Size	1.91 Inches
Connectivity Technology	Bluetooth
Special Features	AI Voice Assistant & Notifications, 100+ Sports Modes, 1.91 Inch HD Screen
Compatible Devices	Smartphone
Water Resistance	IP68
GPS	No GPS
Shape	Rectangular
Target Audience	Women, Men

WARRANTY AND SUPPORT

The OUKITEL Smartwatch comes with a **1-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use.

For technical support, troubleshooting assistance, or warranty claims, please contact OUKITEL customer service through their official website or the contact information provided with your purchase. Please have your model number (B0FXGFXMT5) and proof of purchase ready when contacting support.