

- Manuals.plus /
- > YEAUPE PRO /
 - > YEAUPE PRO Balcony Awning Instruction Manual (Model CZ300, 250x180cm, Grey)

YEAUPE PRO CZ300

YEAUPE PRO Balcony Awning Instruction Manual

Model: **CZ300** | Dimensions: **250 x 180 cm** | Color: **Grey**

Thank you for choosing YEAUPE PRO. This manual provides essential information for the safe and efficient use of your new balcony awning.

1. PRODUCT OVERVIEW

The YEAUPE PRO Balcony Awning is designed to provide flexible sun and UV protection for your outdoor spaces without the need for drilling. Featuring a crank mechanism for easy operation and adjustable height, this awning is suitable for balconies, terraces, and windows. Its durable, waterproof, and UV-resistant polyester fabric ensures long-lasting performance.



FLEXIBLE INSTALLABLE

Vertical & Diagonal
Extended from 0° to 90 °

Driven by crank



Angle adjustable



Image 1.1: The YEAUPE PRO Balcony Awning providing shade on a balcony. This image highlights the flexible installation options, the crank-driven operation, and the adjustable angle feature.

2. SAFETY INFORMATION

Please read and understand all safety instructions before installation and use. Failure to follow these instructions may result in injury or product damage.

- Ensure the installation surface (floor and ceiling/overhang) is stable and capable of supporting the awning's tension.
- Do not install the awning in locations with weak or unstable structures.
- Always retract the awning during strong winds, heavy rain, or snow to prevent damage to the awning and potential hazards.
- Keep children and pets away from the awning during installation and operation.
- Do not hang objects from the awning frame or fabric.

- Regularly check all connections and tensioning mechanisms for security.
- Use only the provided crank handle for operation.

3. PACKAGE CONTENTS


Before beginning installation, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- Awning Fabric (Polyester with PU coating)
- Telescopic Support Poles (Galvanized Iron)
- Cross Arm (Aluminum)
- Crank Handle
- Mounting Hardware (e.g., tensioning screws, caps)
- Instruction Manual

4. SETUP AND INSTALLATION

This awning features a drill-free installation system, relying on tension between the floor and an overhead structure (e.g., balcony ceiling, overhang). It is recommended that two people perform the installation.

1. **Measure Installation Area:** Ensure the height of your installation area is between 220 cm and 300 cm. The awning fabric width is 250 cm.
2. **Assemble Support Poles:** Connect the sections of the telescopic support poles. Ensure the tensioning mechanisms are loose.
3. **Attach Awning Fabric:** Carefully slide the awning fabric onto the designated bars of the frame. Ensure the fabric is correctly oriented.
4. **Position Poles:** Place the assembled poles vertically in the desired location, ensuring they are aligned and the awning frame is level.
5. **Adjust Height and Tension:** Extend the telescopic poles until they make firm contact with the floor and the overhead structure. Use the tensioning screws to secure the poles firmly in place. The system relies on pressure, so ensure adequate tension without over-tightening to avoid damage.
6. **Attach Crank Handle:** Secure the crank handle to its designated attachment point on the awning mechanism.
7. **Test Operation:** Slowly extend and retract the awning using the crank handle to ensure smooth operation and proper tension.



Height-Adjustable

The telescopic pole extends up to 300cm



Roller Rotation

Smooth operation without jamming



No Drilling Installation

No screws or expansion bolts required



360 ° Handle Adjustment

Simple & practical design, easy to use

Image 4.1: Key features for installation and operation, including height adjustment of the telescopic pole, smooth roller rotation, the drill-free base, and the 360-degree adjustable handle.

YEAUPE PRO

Product Specifications




Image 4.2: Product specifications diagram illustrating the awning's dimensions and adjustable height range.

5. OPERATING INSTRUCTIONS

Your YEAUPE PRO Balcony Awning is designed for simple manual operation.

- **Extending the Awning:** Insert the crank handle into the designated loop or hook. Rotate the handle clockwise to extend the awning fabric.
- **Retracting the Awning:** Rotate the crank handle counter-clockwise to retract the awning fabric. Ensure the fabric rolls up smoothly without jamming.
- **Adjusting Angle:** The awning's angle can be adjusted to optimize shade. Refer to the installation diagram for specific adjustment points.
- **Handle Adjustment:** The crank handle may offer 360-degree adjustment for comfortable operation.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your awning.

- **Cleaning the Fabric:** The polyester fabric with PU coating is waterproof and easy to clean. Use a mild soap solution and a soft brush or cloth. Rinse thoroughly with clean water and allow to air dry completely before retracting. Do not use harsh chemicals or abrasive cleaners.
- **Cleaning the Frame:** Wipe down the galvanized iron poles and aluminum cross arm with a damp cloth to remove dirt and debris.
- **Seasonal Storage:** For prolonged periods of non-use or during harsh weather conditions (winter), it is recommended to retract the awning completely. If possible, disassemble and store in a dry, protected area.
- **Inspection:** Periodically inspect all components for wear, damage, or loose connections. Tighten any loose screws or adjust tension as needed.



Image 6.1: Demonstrates the waterproof protection of the YEAUPE PRO awning fabric.



THICKENED SUNSHADE

Image 6.2: Illustrates the effectiveness of the thickened, UV-resistant fabric in providing sun protection.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Awning is unstable or wobbles.	Insufficient tension in support poles.	Increase tension using the adjustment mechanism on the telescopic poles. Ensure poles are perpendicular to surfaces.
Awning fabric does not extend or retract smoothly.	Obstruction in the roller mechanism; fabric misaligned; crank mechanism issue.	Check for debris or obstructions. Ensure fabric is rolling evenly. Inspect crank handle connection.

Problem	Possible Cause	Solution
Water pooling on fabric.	Awning angle is too flat; fabric sag.	Adjust the awning's angle to allow for proper water runoff. Ensure fabric is taut.
Awning damaged by wind.	Awning left extended during strong winds.	Always retract the awning in windy conditions. Damage from wind is not covered by warranty.

8. SPECIFICATIONS

Brand:	YEAUPE PRO
Model Number:	CZ300
Material:	Polyester (180 g/m² with PU coating)
Frame Material:	Galvanized Iron (poles), Aluminum (cross arm)
Color:	Grey
Dimensions (W x Projection):	250 cm x 180 cm
Adjustable Height:	220 cm - 300 cm
Operation Mode:	Manual (Crank)
UV Protection:	Yes
Waterproof:	Yes
Assembly Required:	Yes
Country of Origin:	China

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the purchase documentation or contact your retailer. Keep your proof of purchase for any warranty claims.

For further assistance, you may also visit the official YEAUPE PRO store on Amazon:[YEAUPE PRO Store](#)

© 2026 YEAUPE PRO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FXGN12G6>

More documents and user manuals: <https://manuals.plus/>