

GOSUHI B0FXH58FCS

GOSUHI Cloud Couch 139" U-Shaped Sectional Sofa Instruction Manual

Model: B0FXH58FCS

Brand: GOSUHI

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

WARNING:

- All foam and upholstered surfaces meet flammability standards. Keep away from open flames or high heat sources.
- Supervise children and pets to avoid entrapment risks.
- Ensure all components are securely fastened before use.

2. PRODUCT OVERVIEW

The GOSUHI Cloud Couch is a spacious 139" U-shaped sectional sofa designed for comfort and versatility. It features corduroy upholstery, deep seats, a high backrest, and pocket spring cushions.



Figure 1: GOSUHI Cloud Couch 139" U-Shaped Sectional Sofa.

Key Features:

- **Spacious 7-Seater Design:** Comfortably accommodates up to 7 people.
- **Ergonomic Deep Seat & High Backrest Support:** Provides balanced full-body support.
- **Unmatched Cloud-Like Comfort:** Features pocket spring seat cushions and plush foam for a luxurious feel.
- **Premium Corduroy Fabric:** Soft, skin-friendly, breathable, and easy to maintain.
- **Modular Design:** Allows for flexible arrangement of sections.

3. ASSEMBLY INSTRUCTIONS

The GOSUHI Cloud Couch is delivered in multiple boxes for easy maneuvering. All necessary tools are included for assembly. For a visual guide, please refer to the assembly video below.

3.1 Unboxing and Cushion Preparation

1. Carefully unbox all components. The sofa cushions are vacuum-sealed and rolled.
2. Unroll and unpackage all cushions. Allow them to expand for at least 72 hours to reach their full plushness. Gently shake and fluff them to aid in expansion.

Your browser does not support the video tag.

Video 1: Detailed assembly guide for the 139" U-Shaped Sofa. This video demonstrates the step-by-step process of assembling the sofa base, installing the backrests, and preparing the cushions.

3.2 Base Assembly

1. Identify all base components (labeled J, K, L, O, U, Z as per the included instructions).
2. Assemble the individual base sections using the provided bolts and tools. The unique design includes curved, coated wooden supports that lock into place to provide additional spring support.
3. Connect the assembled base sections to form the desired U-shape. You can bolt them together for a fixed configuration or leave them separate for modularity.



Figure 2: Product dimensions for planning your space.

3.3 Backrest and Armrest Installation

1. Attach the backrest panels (labeled D) to the assembled base sections using the provided bolts. These panels are slightly angled for ergonomic support.
2. Install the armrests (labeled B and C) to the ends of the sofa sections.
3. Cover the backrests with the provided soft fabric covers. These covers slip over the top and secure with Velcro along the bottom edge.

4. OPERATING AND USAGE

Once assembled and cushions are fully expanded, your GOSUHI Cloud Couch is ready for use. Its modular design allows for various configurations to suit your living space.

4.1 Comfort and Support

The sofa features deep seats, a 30.5" high backrest, and pocket spring cushions topped with plush foam, providing a "cloud-like" feel that molds to your body while offering consistent support.



Figure 3: Enjoying the spacious and comfortable seating.

Your browser does not support the video tag.

Video 2: Demonstrating the softness and comfort of the sofa's cushions.

4.2 Fabric and Design

The premium corduroy fabric is not only soft and skin-friendly but also breathable, enhancing overall comfort. The design allows for the fabric to "waterfall" down the front of the sofa, providing a continuous plush look.



Figure 4: Spring-loaded cushions provide cloud-like comfort.

5. MAINTENANCE AND CARE

To ensure the longevity and appearance of your GOSUHI Cloud Couch, follow these care instructions:

- **Regular Cleaning:** Vacuum regularly using an upholstery attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Avoid rubbing, which can spread the stain. Use a mild soap solution and a damp cloth for stubborn spots, then blot dry.
- **Washable Covers:** The corduroy upholstery features washable and dryable covers. Remove covers and follow the care instructions on the label (typically machine wash cold, tumble dry low).
- **Cushion Care:** Periodically fluff and rotate cushions to maintain their shape and even out wear.



Figure 5: Premium Corduroy Fabric is breathable, skin-friendly, soft, washable, and dryable.

6. TROUBLESHOOTING

If you encounter any issues with your GOSUHI Cloud Couch, please refer to the following common solutions:

- **Cushions not fully expanded:** Allow up to 72 hours for vacuum-sealed cushions to fully expand. Gently massage and fluff them to help restore their shape. Ensure they are in a well-ventilated area.
- **Squeaking or instability:** Check all bolts and connections in the base frame. Tighten any loose fasteners. Ensure all modular sections are properly aligned and connected.
- **Fabric wrinkles:** Light wrinkles from packaging should dissipate over time with use and fluffing. Gentle steaming can also help.

7. SPECIFICATIONS

Feature	Detail
Brand	GOSUHI
Model	B0FXH58FCS
Product Dimensions (D x W x H)	106.3"D x 139"W x 38.19"H
Item Weight	358.4 Pounds
Seating Capacity	7
Upholstery Fabric Type	Corduroy
Color	Corduroy, Grey
Seat Height	18.5 Inches
Seat Depth	26.5 Inches
Back Style	High Back (30.5 Inches)
Cushion Construction	Pocket Spring
Frame Material Type	Metal
Assembly Required	Yes (Tools Included)

8. WARRANTY AND SUPPORT

Your GOSUHI Cloud Couch comes with a limited warranty. For specific details regarding warranty coverage, please refer to the documentation included with your purchase or contact GOSUHI customer support.

Customer Support:

For any questions, assistance with assembly, or to report issues, please contact GOSUHI customer support through the retailer where the product was purchased. You can also visit the [GOSUHI Store on Amazon](#) for more information.