

[Manuals.plus](#) /

› [GoSale](#) /

› GoSale Yuho O2 Pro True Wireless Earbuds User Manual

GoSale Yuho O2 Pro

GoSale Yuho O2 Pro True Wireless Earbuds User Manual

Model: Yuho O2 Pro

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your GoSale Yuho O2 Pro True Wireless Earbuds. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image: The GoSale Yuho O2 Pro True Wireless Earbuds, black with an orange interior charging case, displaying a digital battery percentage.

PACKAGE CONTENTS

Upon unpacking, please ensure all items listed below are present:

- 1 Pair of GoSale Yuho O2 Pro Earbuds
- 1 Charging Case
- 1 USB Charging Cable (not explicitly mentioned but standard for earbuds)
- User Manual (this document)

SETUP

1. Initial Charging

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the charging case to a power source using a compatible USB cable.
3. The digital display on the charging case will indicate the battery level. Ensure it reaches 100% for both the case and earbuds.



Image: An illustration showing the GoSale Yuho O2 Pro Earbuds and case, highlighting 30 hours of total playtime with the case and 12 hours for earbuds alone.

2. Bluetooth Pairing

Follow these steps to pair your earbuds with a Bluetooth-enabled device:

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "Yuho O2 Pro" from the list.
4. Once connected, a voice prompt will confirm successful pairing.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.

Touch Controls

The Yuho O2 Pro earbuds feature intuitive touch controls on each earbud.




Image: A diagram illustrating the touch controls for the GoSale Yuho O2 Pro Earbuds. It shows single tap for volume, double tap for play/pause or incoming call, triple tap for voice assistant/call reject, and long press for previous/next song or call reject.

Earbud Touch Control Functions

Action	Left Earbud Function	Right Earbud Function
Single Tap	Volume Down	Volume Up
Double Tap	Play/Pause, Answer Incoming Call	Play/Pause, Answer Incoming Call
Triple Tap	Activate Voice Assistant, Reject Call	Activate Voice Assistant, Reject Call

Action	Left Earbud Function	Right Earbud Function
Long Press	Previous Song, Reject Call	Next Song, Reject Call

Active Noise Cancellation (ANC)

The Yuho O2 Pro earbuds feature 45 dB Hybrid Active Noise Cancellation. This function helps reduce ambient noise for a more immersive listening experience.

- To activate or deactivate ANC, refer to the specific touch control gesture in the table above or consult your device's Bluetooth settings if applicable.
- ANC is most effective at reducing low-frequency sounds.

Call Management

Manage your calls directly from the earbuds using the touch controls. The HD Microphones with Clear Voice Tech ensure clear communication.



Image: White GoSale Yuho O2 Pro Earbuds in their charging case next to a smartphone, illustrating the ENC call noise reduction feature for clear conversations.

MAINTENANCE

Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For ear tips, gently remove them and clean with a mild soap solution if necessary, then rinse and dry completely before reattaching.
- Avoid using abrasive materials, alcohol, or chemical cleaners.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged.

- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- The earbuds are IP54 dust and water resistant, but they are not waterproof. Avoid submerging them in water.

TROUBLESHOOTING

If you encounter issues with your GoSale Yuho O2 Pro Earbuds, refer to the following common solutions:

Common Troubleshooting Steps

Problem	Possible Cause	Solution
Earbuds not pairing	Out of range, low battery, pairing mode not active.	◦ Ensure earbuds are charged. ◦ Place earbuds back in case, close, then open to re-enter pairing mode. ◦ Move closer to your device. ◦ Forget "Yuho O2 Pro" in your device's Bluetooth settings and re-pair.
No sound from one earbud	Low battery, connection issue, earbud not properly seated.	◦ Check battery level of both earbuds. ◦ Place both earbuds in the case, close, then open and try again. ◦ Clean earbud contacts and charging pins in the case.
Poor sound quality	Ear tips not sealed, dirty earbuds, interference.	◦ Adjust earbud position for a secure fit. ◦ Clean ear tips and earbud mesh. ◦ Move away from sources of strong electromagnetic interference.
ANC not working effectively	ANC not activated, improper fit, specific noise types.	◦ Ensure ANC is activated via touch controls. ◦ Adjust earbuds for a tight seal in your ear canal. ◦ ANC is most effective for consistent low-frequency sounds.

SPECIFICATIONS

Key technical specifications for the GoSale Yuho O2 Pro True Wireless Earbuds:

- **Model:** Yuho O2 Pro
- **Brand:** GoSale

- **Connectivity:** Wireless (Bluetooth 5.3)
- **Active Noise Cancellation:** Up to 45 dB Hybrid ANC
- **Microphones:** HD Microphones with Clear Voice Tech (6 microphones)
- **Drivers:** 10mm Dynamic Bass Boost Drivers
- **Battery Life (Earbuds):** Up to 11 hours (ANC off)
- **Total Playtime (with Case):** Up to 39 hours
- **Water Resistance:** IP54 Dust & Water Resistant
- **Form Factor:** In-Ear
- **Material:** Plastic, Rubber
- **Product Dimensions:** 5.5 x 5.5 x 2.5 cm
- **Item Weight:** 50 g
- **Special Features:** Microphone Included, Noise Isolation, Sweatproof, Touch Controls



Image: White GoSale Yuho O2 Pro Earbuds in their charging case, with a list of features including HIFI-level sound quality, Bluetooth 5.3 chip, seamless game delay, HD calls without noise, HD digital display, long endurance, and intelligent touch.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact GoSale customer service.

Manufacturer: GoSale, GoSale India

Country of Origin: India

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question