Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nordivale TV Stand

Nordivale 70" Floating TV Stand with 36" Electric Fireplace Instruction Manual

Model: TV Stand | Brand: Nordivale

Introduction

Thank you for choosing the Nordivale 70" Floating TV Stand with 36" Electric Fireplace. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before beginning assembly or use to ensure proper function and safety.

Safety Information

Important Safety Warnings:

- Install on solid concrete or brick walls only. Do not attempt to mount on wooden, drywall, or hollow walls. Improper installation can lead to product failure and injury.
- Be cautious of sharp edges and heavy weight during handling and assembly. It is recommended that two or more people assemble this unit.
- Always follow safety guidelines when using the electric fireplace feature. Do not block air vents.
- Ensure the power cord is not pinched or routed in a way that could cause damage.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the fireplace.
- Do not operate the fireplace if the power cord or plug is damaged, or if the heater malfunctions.

Product Features

The Nordivale Floating TV Stand offers a blend of modern design and functionality:

- **Attractive Floating Design:** A contemporary 70-inch high-gloss floating TV stand combined with a 36-inch mirrored electric fireplace insert.
- **Realistic Electric Fireplace:** The 36-inch fireplace features 5 levels of flame brightness and 12 flame colors.
- **Ambient Lighting:** Includes 12 colors of backlight and 12 LED colors for light strips, allowing for customizable ambiance.
- **High Gloss Finish:** Provides an elegant appearance and is easy to clean.

- **Temperature Control:** Adjust the fireplace temperature from 62°F to 82°F.
- **Timer Function:** Set the fireplace to operate for 0 to 8 hours using the remote control.
- **Storage:** Features glass cabinet doors and adjustable/removable shelves for versatile storage.
- **Cable Management:** Integrated solutions to keep wires organized.

Package Contents

Your Nordivale Floating TV Stand and Electric Fireplace are shipped in two separate boxes. These boxes may arrive on different days. Please ensure you have received both packages before beginning assembly.

- **Box A:** TV Stand components and hardware.
- **Box B:** 36" Electric Fireplace insert and remote control.

Verify all parts are present and undamaged by checking against the parts list in the included assembly guide.



Image: Illustration showing the product being shipped in two separate boxes, Box A for the TV stand and Box B for the electric fireplace, which may arrive on different days.

Setup and Installation

This unit is designed for wall mounting. Proper installation is crucial for safety and stability.

1. **Wall Type:** This unit **must** be installed on solid concrete or brick walls only. Do not attempt to mount on wooden, drywall, or hollow walls, as this can lead to structural failure and potential injury.
2. **Tools Required:** Gather necessary tools as specified in the separate assembly guide (e.g., power drill, level, measuring tape, stud finder if applicable for solid walls).
3. **Assembly:** Follow the step-by-step instructions provided in the dedicated assembly guide for the TV stand. It is recommended to have at least two people for assembly and mounting due to the weight and size of the unit.
4. **Fireplace Insertion:** Once the TV stand frame is assembled and securely mounted, carefully insert the electric fireplace unit into its designated opening.
5. **Cable Management:** Utilize the integrated cable management features to route and organize all power cords and media cables, ensuring a tidy and safe setup.



Image: Product details highlighting dual-layer durable particle board, cable management, and high gloss finish.



Image: The Nordivale floating TV stand installed in a living room, showcasing its modern aesthetic and the electric fireplace in operation.

Operating Instructions

The electric fireplace and LED lighting features are controlled via the included remote control or the control panel on the unit.

Electric Fireplace Operation:

- **Power On/Off:** Press the power button on the remote or control panel to turn the fireplace on or off.
- **Flame Brightness:** Adjust the flame brightness through 5 levels (L1 to L5) using the dedicated button. L1 is the dimmest, L5 is the brightest.
- **Flame Colors:** Select from 12 different flame colors to match your mood or decor.
- **Temperature Control:** Set the desired room temperature between 62°F and 82°F. The heater will automatically turn on or off to maintain this temperature.
- **Timer Function:** Activate the timer to automatically shut off the fireplace after a set duration, from 0 to 8 hours.

LED Lighting Operation:

- **Backlight Colors:** Choose from 12 backlight colors for the TV stand.
- **Light Strip Colors:** Select from 12 LED colors for the integrated light strips.
- **Light/Power Control:** Use the remote or control panel to manage the lighting effects.



Image: Visual guide to the 5 flame brightness levels, 12 LED colors, and 12 flame colors available for the electric fireplace.



Image: Diagram illustrating the various functions and components of the electric fireplace, including timer, temperature, heat settings, flame controls, and physical features like vents and glass screen.

Official Product Video:

Your browser does not support the video tag.

Video: An official product video from Nordivale-service demonstrating the features and appearance of the Black Floating Fireplace TV Stand. This video provides a comprehensive overview of the product in use.

Maintenance

Regular maintenance will help prolong the life and appearance of your TV stand and fireplace.

- **Cleaning the TV Stand:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the high-gloss finish.
- **Cleaning the Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Gently wipe the glass screen with a soft, lint-free cloth. Do not spray cleaners directly onto the unit.

- **Dusting:** Regularly dust all surfaces, including vents, to prevent dust buildup which can affect performance.
- **Inspecting Cords:** Periodically check the power cord for any signs of damage or fraying. If damage is found, discontinue use and contact customer support.

Troubleshooting

If you encounter issues with your Nordivale Floating TV Stand or Electric Fireplace, refer to the following common solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, remote battery low, or unit is off.	Check power connection, replace remote batteries, ensure unit is switched on.
No heat output.	Heater function not activated, or thermostat setting too low.	Activate heater function via remote/panel, increase temperature setting.
Flames are not visible or dim.	Flame brightness set too low.	Increase flame brightness level (L1-L5).
Remote control not working.	Low battery, obstruction, or not pointed at sensor.	Replace batteries, remove obstructions, ensure direct line of sight to the unit's sensor.

If the problem persists after trying these solutions, please contact Nordivale customer support for further assistance.

Specifications

Feature	Detail
Brand	Nordivale
Model Number	TV Stand
Color	Black&black
Size	70IN (TV Stand), 36IN (Fireplace)
Item Dimensions (TV Stand)	70.08 x 13.98 x 15.35 inches (W x D x H)
Item Weight	96 Pounds
Material Type	Engineered Wood, Wood
Style	Modern
Fireplace Heat Output	700W/1500W (Adjustable)
Temperature Range	62°F to 82°F
Timer Setting	0 to 8 hours
Flame Brightness Levels	5
Flame Colors	12

Feature	Detail
Backlight/LED Strip Colors	12
Required Assembly	Yes
Mounting Type	Wall Mounted (Solid concrete or brick walls only)




Image: Guide illustrating the TV stand's compatibility with various TV sizes, accommodating up to 80-inch televisions.

TV Size	Dimension	Capacity
80 Inches	TV Stand-70"W x13.98"Dx15.39"H	Countertop: 220LBS Fireplace-36"Wx13.86"H





Image: Detailed dimensions and capacity specifications for the Nordivale 70-inch Floating TV Stand and 36-inch Electric Fireplace.

Warranty and Support

Nordivale is committed to providing quality products. While specific warranty details are not provided in this document, please retain your proof of purchase for any warranty claims.

For customer support, missing parts, or technical assistance, please contact Nordivale-service directly through the retailer where you purchased the product. Refer to your purchase documentation for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FXLB174T

More documents and user manuals: **https://manuals.plus/**