

SUXI T700

SUXI A3 Android Tablet User Manual

Model: T700

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your SUXI A3 Android Tablet. Please read it thoroughly before operating the device to ensure optimal performance and longevity. The SUXI A3 is a 10.1-inch Android tablet designed for various tasks, including online learning, e-reading, productivity, and entertainment, featuring dual SIM 4G LTE and Wi-Fi 6 connectivity.

2. WHAT'S IN THE BOX

Upon unboxing your SUXI A3 Tablet, verify that all the following items are included:

- SUXI A3 Tablet
- Keyboard
- Mouse
- Protective Cover
- Charging Kit (Data cable and Charging head)
- Touch Pen
- Bracket (Tablet Stand)
- Card Removal Pin
- User Manual

9 reasons for recommendation



2MP Front
8MP Rear

1280*800 HD
visual feast

Android 14



4G LTE

T606
Processor



Face Recognition

Widevine L1



6000mAh



Image: The SUXI A3 Tablet displayed with its full set of accessories, including the detachable keyboard, wireless mouse, protective case, charging cable, power adapter, stylus pen, and SIM card ejector tool, all neatly arranged.

3. PRODUCT OVERVIEW

The SUXI A3 Tablet features a 10.1-inch HD display, powered by an Octa-Core processor, and runs on Android 14. It offers versatile connectivity with Dual SIM 4G LTE and Wi-Fi 6, making it suitable for various applications.

3.1 Key Features

- **Display:** 10.1-inch IPS HD display (1280x800 resolution) with 10-point touch support.
- **Processor:** Unisoc T606 Octa-Core (2.0GHz) for smooth performance.
- **Memory & Storage:** 12GB RAM (virtual) + 128GB internal storage, expandable up to 1TB via microSD card.
- **Operating System:** Android 14.
- **Connectivity:** Dual SIM 4G LTE, Dual-band Wi-Fi 6 (802.11a/b/g/n/ac), Bluetooth.
- **Battery:** 6000mAh long-lasting battery.

- **Cameras:** Front 2MP, Rear 8MP.
- **Audio:** Quad Stereo Speakers, Dual Microphones.
- **Security:** Face Recognition.




Image: An infographic detailing nine key features of the SUXI A3 Tablet, such as Wi-Fi 6, 4G LTE, Android 14 operating system, T606 processor, 6000mAh battery, 2MP front camera, 8MP rear camera, 1280x800 HD display, and face recognition capabilities.

3.2 Physical Components

Familiarize yourself with the tablet's physical layout:

- **Front:** 10.1-inch IPS display, Front Camera.
- **Rear:** Rear Camera, SUXI branding, regulatory markings.
- **Sides:** Power Button, Volume Buttons, USB Type-C Port, SIM/MicroSD Card Slot, Speaker Grilles, Microphone.



Image: The SUXI A3 Tablet in Starry Grey, presented with its detachable keyboard and stylus. The screen highlights key specifications including its 10.1-inch HD display, 4G LTE and WiFi 6 connectivity, Android 14 operating system, 12GB RAM + 128GB storage, and 6000mAh battery capacity.

4. SETUP

4.1 Initial Charging

Before first use, fully charge your tablet. Connect the provided USB Type-C cable to the tablet's charging port and the power adapter to a wall outlet. The charging indicator on the screen will show the charging status.

4.2 Power On/Off

- **To Power On:** Press and hold the Power button until the SUXI logo appears.
- **To Power Off:** Press and hold the Power button, then select 'Power off' from the options on the screen.
- **To Restart:** Press and hold the Power button, then select 'Restart' from the options on the screen.

4.3 SIM Card and microSD Card Installation

The SUXI A3 Tablet supports dual SIM cards for 4G LTE connectivity and a microSD card for expanded storage. The SIM card tray is located on the side of the tablet.

1. Locate the SIM/microSD card slot on the side of the tablet.
2. Insert the provided card removal pin into the small hole next to the tray to eject it.
3. Carefully place your Nano-SIM cards (up to two) and/or a microSD card into the designated slots on the tray. Note that one SIM slot may be shared with the microSD card slot.
4. Gently push the tray back into the tablet until it clicks into place.




Image: A diagram illustrating the dual SIM card tray for 4G connectivity, alongside an image depicting a user enjoying dual-band WiFi on the tablet in a home setting.

4.4 Connecting Accessories (Keyboard, Mouse, Pen)

The SUXI A3 Tablet comes with a keyboard, mouse, and touch pen. These accessories typically connect via Bluetooth.

1. **Enable Bluetooth:** Go to Settings > Connected devices > Bluetooth and turn it on.
2. **Pair Keyboard/Mouse:** Put the keyboard or mouse into pairing mode (refer to their individual instructions, usually a button press). Select the device from the available Bluetooth devices list on your tablet to pair.
3. **Touch Pen:** The touch pen is generally passive and does not require Bluetooth pairing. Simply use it directly on the screen.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

The tablet uses standard Android touch gestures:

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through pages or lists.
- **Pinch:** Zoom in or out on images and web pages.
- **Long Press:** Access contextual menus or move icons.

5.2 Wi-Fi Connectivity

To connect to a Wi-Fi network:

1. Go to Settings > Network & internet > Wi-Fi.
2. Turn on Wi-Fi.
3. Select your desired network from the list.
4. Enter the password if prompted, then tap 'Connect'.

5.3 Cellular Data (4G LTE)

If you have installed a SIM card with an active data plan:

1. Go to Settings > Network & internet > Mobile network.
2. Ensure 'Mobile data' is turned on.
3. You may need to configure APN settings if your carrier does not automatically set them up.

5.4 Parental Control 2.0

The tablet includes advanced parental control features to manage usage and content:

- **One-Click App Block:** Remotely disable specific applications.
- **Usage Time Limits:** Set precise time limits for tablet use.
- **Learning Reports:** Monitor application usage and progress.

Access these features through the dedicated Parental Control application or within the tablet's system settings.

5.5 Display Settings and Eye Protection

The 10.1-inch IPS display is designed with eye protection features:

- **Blue Light Filtering:** The screen filters harmful blue light (415-455nm).
- **Smart Brightness:** Automatic brightness adjustment for reduced eye strain.
- **Paper-like Reading Mode:** Activate this mode in display settings for a more comfortable reading experience.

Pleasing HD screen

The 16:9 display has a resolution of 1280x800, providing clearer and more vivid image quality. The touch screen supports 10-point touch, making the operation more sensitive.

IPS
high definition screen



Ordinary
screen



Image: A visual comparison demonstrating the superior clarity and vividness of the IPS high-definition screen on the SUXI A3 Tablet compared to a standard display.

6. MAINTENANCE

6.1 Cleaning

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture.

6.2 Battery Care

- Avoid exposing the tablet to extreme temperatures (hot or cold).
- Do not allow the battery to fully discharge frequently.
- Use only the provided charging kit or certified compatible chargers.

Bigger screen More enjoyment Ready to go more efficient

Online Learning



E-reading



Image: An infographic illustrating the 6000mAh battery of the SUXI A3 Tablet and its estimated endurance for different activities, including 6 hours of gaming, 5 hours of HD video playback, 8 hours of website browsing, 10 hours of music, and 72 hours of standby time.

7. TROUBLESHOOTING

If you encounter issues with your SUXI A3 Tablet, refer to the following common solutions:

Problem	Solution
Tablet does not power on	Ensure the battery is charged. Connect to the charger for at least 30 minutes before attempting to power on again.
Wi-Fi connection issues	Check if Wi-Fi is enabled in settings. Restart your router and the tablet. Forget the network and reconnect.
Slow performance	Close unnecessary background applications. Clear cache for frequently used apps. Consider a factory reset if the issue persists (back up data first).
Accessories not connecting	Ensure Bluetooth is enabled on the tablet. Put the accessory in pairing mode. Check battery levels of accessories.
SIM card not detected	Ensure the SIM card is correctly inserted into the tray. Restart the tablet. Verify the SIM card is active with your carrier.

For more complex issues, please refer to the official SUXI support website or contact customer service.

8. SPECIFICATIONS

Below are the detailed technical specifications for the SUXI A3 Tablet (Model T700):

Feature	Specification
Model Name	SUXI A3
Item Model Number	T700
Operating System	Android 14
Screen Size	10.1 Inches
Max Screen Resolution	1280 x 800 Pixels
Processor	Unisoc T606 Octa-Core (1.6 GHz)
Graphics Coprocessor	Mali-G57
Memory (RAM)	4 GB (advertised as 12GB with virtual RAM)
Storage (Flash Memory Size)	128 GB
Expandable Storage	Supports up to 1TB MicroSD card
Wireless Type	802.11a/b/g/n/ac (Wi-Fi 6)
Cellular Connectivity	Dual 4G LTE SIM Slot
Average Battery Life	8 Hours (6000mAh)
Item Weight	1.1 pounds (approx. 500g)
Product Dimensions	9.54 x 6.34 x 0.33 inches (242.3 x 161 x 8.5 mm)
Color	Starry Grey
Rear Webcam Resolution	3 MP
Front Webcam Resolution	2 MP

Full of energy, longer battery life

The tablet is equipped with a powerful 6000mAh polymer lithium battery, which is perfect for long work and entertainment. The Type-C charging port allows you to stay powered and connected without frequent charging.



Image: An infographic illustrating the Unisoc T606 octa-core processor, highlighting its A75 high-gain cores, A55 power-saving cores, 12nm manufacturing process, and overall low heat and energy-saving design.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your product packaging or visit the official SUXI website. For technical support or customer service inquiries, please contact SUXI customer support through their official channels.