

[Manuals.plus](#) /

› [YOMILUVE](#) /

› YOMILUVE 47" Farmhouse Computer Desk with Drawers & Outlets User Manual

YOMILUVE 47" Farmhouse Computer Desk with Drawers & Outlets

YOMILUVE 47" Farmhouse Computer Desk with Drawers & Outlets User Manual

Model: 47" Farmhouse Computer Desk with Drawers & Outlets

INTRODUCTION

Thank you for purchasing the YOMILUVE 47" Farmhouse Computer Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain this manual for future reference.

DIMENSIONS



L x W x H
47.3" x 18.9" x 36.4"




Image: The YOMILUVE 47" Farmhouse Computer Desk, showcasing its black and white finish, monitor stand, and drawer configuration.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use damaged parts.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may damage the material.
- Keep small parts away from children during assembly.
- Do not exceed the maximum weight capacity of 300 pounds for the desktop.
- Ensure the desk is placed on a level surface to prevent tipping.

SETUP AND ASSEMBLY

1. Unpacking and Component Check

Carefully remove all contents from the packaging. Lay out all parts and hardware on a clean, soft surface. Refer to the

included assembly diagram (not provided in this manual, refer to your product packaging) to identify each component.

2. Assembly Instructions

Follow the step-by-step instructions provided in your product's assembly manual. Typically, assembly involves:

1. Attaching the side panels to the main desk frame.
2. Assembling and inserting the drawers into their respective slots.
3. Securing the desktop surface.
4. Attaching the monitor stand to the desktop.
5. Installing the integrated power strip.

Note: Assembly typically requires two people for easier handling and stability.

3. Power Connection

Once the desk is fully assembled and in its desired location, plug the power cord from the integrated charging station into a standard 120V AC wall outlet. Ensure the power cord is not pinched or obstructed.

BUILT-IN POWER STRIP

With 2 AC Outlets & 2 USB ports 



Image: A detailed view of the integrated power strip, featuring two AC outlets and two USB ports, ready for device charging.

OPERATING INSTRUCTIONS

1. Drawer Usage

The desk features four drawers for storage: one wide drawer, two small drawers, and one medium drawer. Gently pull the metal handles to open and push to close. Avoid forcing drawers if they feel stuck; check for obstructions.



Image: The desk with all four drawers extended, illustrating the varied sizes and ample storage space for office supplies and documents.

2. Integrated Charging Station

The built-in power strip includes 2 standard AC outlets (120V/12A) and 2 USB ports (5V/2A). Use these to power your computer, monitor, tablet, phone, and other electronic devices. Ensure devices are compatible with the provided power specifications.

3. Full Monitor Stand

The elevated monitor stand provides an ergonomic viewing height, which can help reduce neck and eye strain. It also offers additional storage space underneath for keyboards, mice, or other desk accessories, helping to keep your workspace tidy.



Image: An illustration demonstrating the ergonomic advantages of the full monitor stand, promoting better posture and reducing strain compared to a lower screen position.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the engineered wood finish.
- **Spills:** Promptly wipe up any spills to prevent water damage or staining, as the desk is waterproof.
- **Protection:** Use coasters under drinks and placemats under hot items to protect the desktop surface.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary, but do not overtighten.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the finish.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers stick or do not slide smoothly.	Obstruction in the drawer slide; drawer not properly aligned; loose hardware.	Remove drawer and check for obstructions. Ensure drawer is correctly seated on slides. Check and tighten all drawer hardware.
Power outlets/USB ports not working.	Desk power cord unplugged; wall outlet not functioning; device not properly connected.	Ensure the desk's power cord is securely plugged into a working wall outlet. Test the wall outlet with another device. Ensure devices are fully plugged into the desk's outlets/ports.
Desk wobbles.	Uneven floor; loose assembly hardware.	Ensure the desk is on a level surface. Check and tighten all assembly screws.

SPECIFICATIONS

- Brand:** YOMILUVE
- Model:** 47" Farmhouse Computer Desk with Drawers & Outlets
- Product Dimensions (D x W x H):** 18.9" x 47.3" x 36.4"
- Desktop Height:** 30.5" (from floor to main desktop surface)
- Monitor Stand Height:** 5.9" (above main desktop)
- Material:** High-quality MDF Board (Engineered Wood)
- Color:** Black and White
- Number of Drawers:** 4 (1 wide: 28.5"W x 14.3"D x 5.2"H; 2 small: 13.7"W x 14.3"D x 5.2"H; 1 medium: 13.7"W x 14.3"D x 10.4"H)
- Weight Capacity:** 300 lbs (desktop)
- Integrated Charging Station:** 2 AC Outlets (120V/12A), 2 USB Ports (5V/2A)
- Power Cord Length:** 4.9 feet
- Special Features:** Full Monitor Stand, Durable & Waterproof Construction



Image: A comprehensive diagram illustrating the overall dimensions of the desk, including width, depth, height, and the internal measurements of each drawer type.

WARRANTY AND SUPPORT

Warranty Information

This YOMILUVE product comes with a limited warranty. Please refer to your purchase documentation or contact the retailer for specific warranty terms and conditions. The warranty typically covers manufacturing defects under normal use.

Customer Support

If you have any questions, require assistance with assembly, or encounter any issues with your YOMILUVE desk, please contact our customer support team. Refer to your purchase receipt or the YOMILUVE official website for contact details. For more information, visit the [YOMILUVE Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question