

heetipuk J618

heetipuk IPX7 Waterproof Mini Bluetooth Speaker (Model J618) User Manual

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your heetipuk IPX7 Waterproof Mini Bluetooth Speaker, Model J618. Please read this manual thoroughly before operating the device and retain it for future reference.

WHAT'S IN THE BOX

- Speaker
- USB C Power Cable
- Quick Start Guide
- User's Manual

PRODUCT FEATURES

- **Compact and Portable Design:** Lightweight (3.1 oz) and small (2.4 x 2.4 x 1.9 inches), designed for easy transport with an included carrying strap.
- **Magnetic Base:** Features a stable magnetic design for attachment to metallic surfaces. Includes a free magnetic ring for use with non-magnetic phones or surfaces, allowing the speaker to function as a phone stand in landscape or portrait mode.
- **IPX7 Waterproof & Dustproof:** Rated IPX7 for water resistance, allowing submersion in water up to 1 meter for 30 minutes. Also features a Level 6 dustproof rating.
- **Powerful Sound:** Delivers 5W output power with a maximum volume of 100dB, featuring a bass diaphragm for enhanced bass performance.
- **Extended Playtime:** Provides up to 12 hours of continuous music playback at 70% volume on a single charge.
- **Bluetooth 5.4 & TWS Pairing:** Equipped with Bluetooth 5.4 for stable wireless connection and supports True Wireless Stereo (TWS) pairing for connecting two speakers for an immersive stereo experience.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker using the provided USB-C cable. Connect the USB-C end to the speaker's charging port and the other end to a compatible USB power adapter (not included).



Image: The speaker charging via USB-C cable on a wooden surface.

2. Powering On/Off

Press and hold the power button on the speaker to turn it on or off. An indicator light will confirm the status.

3. Bluetooth Pairing

1. Ensure the speaker is charged and powered on.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices. The speaker will appear as "heetipuk J618" or similar.
4. Select the speaker from the list to pair. A confirmation sound will indicate successful pairing.

4. True Wireless Stereo (TWS) Pairing (Optional)

To achieve a stereo sound experience, you can pair two heetipuk J618 speakers together:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS pairing button (refer to the speaker's button layout for exact location).
3. The primary speaker will search for the secondary speaker. Once connected, a confirmation sound will play.
4. Now, connect your device to the primary speaker via Bluetooth as described in step 3. Audio will play in stereo through both speakers.



Image: Two speakers connected wirelessly to a laptop, demonstrating TWS pairing.

OPERATING THE SPEAKER

Basic Controls

- **Power Button:** Press and hold to turn on/off.
- **Play/Pause Button:** Press once to play or pause music.
- **Volume Up/Next Track:** Press once for volume up, press and hold for next track.
- **Volume Down/Previous Track:** Press once for volume down, press and hold for previous track.

Your browser does not support the video tag.

Video: Demonstrates the speaker's features including Bluetooth playback controls (play/pause, next/previous track).

Magnetic Attachment and Phone Stand Functionality

The speaker features a magnetic base for convenient attachment to metallic surfaces. An included magnetic ring allows you to attach the speaker to non-magnetic surfaces or directly to your phone to use it as a stand.

1. **Attaching to Magnetic Surfaces:** Simply place the speaker's magnetic base against any suitable

metallic surface (e.g., refrigerator, desk leg).


2. **Using the Magnetic Ring:** For non-magnetic phones or surfaces, peel off the adhesive backing from the magnetic ring and firmly attach it to the desired location. The speaker can then be magnetically attached to this ring.
3. **Phone Stand:** When attached to your phone, the speaker can prop it up for viewing in both landscape and portrait orientations.



Image: The speaker magnetically attached to the back of a smartphone, holding it upright as a stand.

MAGNETIC VERSION

**FREE
MAGNETIC RING**



✓ One-Step Installation

✓ Securely adheres

✓ Simply stick it on

Image: The speaker magnetically attached to a shower wall, demonstrating its use in a wet environment.

Waterproof and Dustproof Use

The IPX7 rating means the speaker can be submerged in water up to 1 meter (3.3 feet) for 30 minutes without damage. The IP6X dustproof rating protects against dust ingress. This makes it suitable for use in bathrooms, by pools, at the beach, or during outdoor activities.



Image: The speaker partially submerged in water, highlighting its IPX7 waterproof feature.

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid extreme temperatures.
- **Charging Port:** Ensure the USB-C charging port is dry before charging to prevent damage.

TROUBLESHOOTING

No Power

- Ensure the speaker is fully charged. Connect it to a power source using the USB-C cable.
- Press and hold the power button for a few seconds to ensure it's not just in standby mode.

Cannot Pair via Bluetooth

- Ensure the speaker is in pairing mode (indicator light flashing).
- Turn off Bluetooth on your device and turn it back on.
- Move the speaker closer to your device.
- Ensure no other devices are currently connected to the speaker.

- If TWS mode was previously used, ensure both speakers are disconnected from each other before attempting to pair a single speaker to your device.

No Sound or Low Volume

- Increase the volume on both the speaker and your connected device.
- Ensure the speaker is properly paired and connected to your device.
- Check if the audio source on your device is playing.

TWS Pairing Issues

- Ensure both speakers are the same model and fully charged.
- Make sure both speakers are not connected to any other Bluetooth devices before initiating TWS pairing.
- Keep the speakers within 19 feet (approximately 6 meters) of each other during TWS pairing.

SPECIFICATIONS

Feature	Detail
Brand	heetipuk
Model Number	J618
Speaker Maximum Output Power	5 Watts
Connectivity Technology	Wireless (Bluetooth 5.4)
Audio Output Mode	Stereo (with TWS pairing)
Input Voltage	5 Volts (DC)
Mounting Type	Magnetic, Wall Mount
Enclosure Material	Acrylonitrile Butadiene Styrene (ABS)
Additional Features	Dustproof, Lightweight, Portable, Stereo Pairing, Waterproof
Color	Black
Battery Average Life	Up to 12 Hours (at 70% volume)
Water Resistance Level	IPX7
Bluetooth Range	Up to 32.8 Feet (10 meters)
Item Dimensions (D x W x H)	2.2"D x 1.7"W x 2.2"H
Item Weight	3.1 Ounces
Compatible Devices	Laptop, Smartphone, Tablet
Battery Charge Time	Approximately 11 Hours (for full charge, based on average life)
UPC	799511838294

WARRANTY AND SUPPORT

This heetipuk product comes with a 1-Year Seller Limited Warranty. For warranty claims or technical support, please contact Heetipuk Electronic directly through your purchase platform or their official support channels.