

CHITA DC7503-G0402190-1

CHITA Breakfast Nook Bench with Storage Instruction Manual

Model: DC7503-G0402190-1

[Introduction](#)

[Safety Information](#)
[Maintenance](#)

[Package Contents](#)
[Specifications](#)

[Assembly](#)
[Troubleshooting](#)

[Features](#)
[Support](#)

[Usage](#)

[Care &](#)

1. INTRODUCTION

Thank you for choosing the CHITA Breakfast Nook Bench with Storage. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read it thoroughly before beginning assembly and retain it for future reference.

2. SAFETY INFORMATION

Important Safety Precautions:

- Ensure the bench is properly assembled according to the provided instructions before use.
- Do not exceed the maximum weight recommendation: **500 lbs for the bench seat** and **300 lbs for single seats/corner sections**. Exceeding these limits can cause damage to the product and potential injury.
- Keep small children away from moving parts during assembly.
- When opening and closing storage compartments, ensure hands and fingers are clear to prevent pinching. The soft-close gas struts are designed for safety, but caution is still advised.
- Do not stand on the bench or use it as a step stool.
- Periodically check all connections and fasteners to ensure they remain tight.

3. PACKAGE CONTENTS

Your CHITA Breakfast Nook Bench with Storage is delivered in three separate boxes. These boxes may

arrive on different dates. Please verify all components are present before beginning assembly.

- Box 1: Bench Seat
- Box 2: Corner Seat
- Box 3: Single Seat



Image: Overview of the L-shaped bench dimensions and the three packages included in the delivery.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Detailed step-by-step instructions and all necessary hardware are included within the product packaging. Please follow these instructions carefully to ensure proper and safe assembly.

For visual guidance, please refer to the official product video below, which demonstrates the product's features and modular design.

Your browser does not support the video tag.

Video: Official CHITA Breakfast Nook Bench product overview, showcasing its features and modularity.

5. PRODUCT FEATURES

5.1. Comfortable & Safe Materials

The bench features plush, removable seat and back cushions with a multi-layered foam sandwich construction for comfort and support. The breathable materials are OEKO-TEX and CertiPUR-US Certified, ensuring a healthy seating option.



Image: Details on the comfortable and safe materials used, including high resilient foam and soft filling, along with various certifications.

5.2. Hidden Storage

Each section of the corner bench includes spacious hidden storage with a sturdy wooden lid and smooth-lift gas struts. This allows for easy access to store items and helps keep your space tidy. The soft-close design prevents finger trapping, making it child-friendly.

- Single Seat/Corner Storage Dimensions: 21"W x 21"D x 11.5"H
- Bench Seat Storage Dimensions: 44.5"W x 21"D x 11.5"H

Modular Dining Banquette

Seamlessly join or detach for flexible seating options



Quick-Clip Connector

Image: The spacious hidden storage compartments of the bench, shown open and filled with various items.



Image: A close-up view of an open storage compartment, highlighting the gas strut for smooth and safe operation.

5.3. Modular Design

The 74-inch L-shaped design allows for versatile rearrangements to fit various corners or along windows. This modularity comfortably seats 3–5 people and pairs well with most dining tables, offering an efficient and inviting layout.



Image: The modular design of the banquette, illustrating how sections can be joined or detached using quick-clip connectors for flexible seating options.

5.4. Sturdy Construction

Crafted from solid engineered wood and hardwood, the CHITA dining bench ensures long-lasting durability. The wood is kiln-dried and FSC & EPA certified, sourced from responsibly managed forests with no harmful formaldehyde emissions.

6. USAGE

6.1. Arranging Your Bench

The modular design allows you to configure the bench to best suit your space. Use the included quick-clip connectors to secure the sections together. You can arrange it as an L-shape for a corner nook or separate the pieces for individual seating.

6.2. Accessing Storage

To access the hidden storage, gently lift the seat cushion. The gas struts will assist in holding the lid open. To close, push the lid down until it latches securely. Always ensure the area around the lid is clear before closing.

Seamless Wall Fit



Image: Demonstrates the wipe-clean fabric, how the cushion lifts for easy storage access, and the soft-close safety mechanism of the storage lid.



Image: A close-up of the cushion with a zipper, indicating that the covers are removable for cleaning.

7. CARE & MAINTENANCE

To maintain the appearance and longevity of your CHITA Breakfast Nook Bench, follow these care instructions:

- **Spot Cleaning:** Blot and spot clean spills immediately with a clean, absorbent cloth. Use a water-free stain remover (Cleaning Code: SW) for stubborn stains. Always test the cleaner on an inconspicuous area first.
- **General Cleaning:** Vacuum regularly using an upholstery attachment to remove dust and debris.
- **Cushion Care:** The cushions are removable and reversible. Rotate them periodically to ensure even wear.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals, as these can damage the fabric and finish.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions (D x W x H)	50"D x 73.62"W x 34.25"H
Material	CertiPUR-US Certified High Density Foam, OEKO-TEX Certified Chenille
Frame Material	FSC Certified Solid Wood, TSCA-compliant Engineered Wood
Color	Linen
Style	Modern
Size	4 Seats
Seat Height	20.08 Inches
Item Weight	182.38 Pounds
Maximum Weight Recommendation	500 Pounds (Bench Seat), 300 Pounds (Single/Corner Seat)
Assembly Required	Yes
Included Components	Breakfast Nook Bench with Storage (1 Single + 1 Corner + 1 Double)
Model Number	DC7503-G0402190-1
Brand	CHITA

9. TROUBLESHOOTING

If you encounter any issues with your CHITA Breakfast Nook Bench, please consider the following:

- **Assembly Issues:** Double-check all connections and ensure all hardware is tightened according to the assembly instructions.
- **Stability Concerns:** Ensure the bench is placed on a flat, even surface. Verify all legs are making full contact with the floor.
- **Storage Lid Operation:** If a storage lid is not opening or closing smoothly, check for any obstructions in the mechanism or hinges. Ensure the gas struts are properly installed.

For further assistance, please contact customer support.

10. CUSTOMER SUPPORT & WARRANTY

CHITA is committed to providing quality products and excellent customer service. We stand behind our product with a 1-year support promise.

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact CHITA customer support through the retailer where you purchased the product or visit the official CHITA website for contact information.

Please have your model number (DC7503-G0402190-1) and purchase date available when contacting support.