

- [Manuals.plus](#) /
- › [Marsail](#) /
 - › Marsail Fireplace TV Stand (Model RONGMEI-US VCPIWFS03G-US-17) User Manual

Marsail RONGMEI-US VCPIWFS03G-US-17

Marsail Fireplace TV Stand (Model RONGMEI-US VCPIWFS03G-US-17) User Manual

Comprehensive Instructions for Setup, Operation, and Maintenance

1. INTRODUCTION

Thank you for choosing the Marsail Fireplace TV Stand. This product is designed to accommodate TVs up to 70 inches and features an integrated 23-inch electric fireplace. It offers both functional storage and a decorative element with its farmhouse design. This manual provides essential information for the safe assembly, operation, and maintenance of your new TV stand.



This image displays the Marsail Fireplace TV Stand in a typical living room environment, showcasing its design and the illuminated electric fireplace.

2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- **Electrical Safety:** Ensure the electric fireplace is connected to a properly grounded outlet. Do not overload electrical circuits. Keep power cords away from heated surfaces and foot traffic areas.
- **Placement:** Position the TV stand on a flat, stable surface. Do not block the air vents of the fireplace. Maintain adequate clearance from combustible materials.
- **Overheat Protection:** The electric fireplace includes an overheat protection feature that will automatically shut off the unit if it becomes too hot. If this occurs, unplug the unit, allow it to cool, and check for any obstructions before restarting.
- **Children and Pets:** Keep children and pets away from the fireplace and moving parts. The cabinet doors are equipped with anti-pinch hinges for added safety.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 200 lbs for the TV stand.
- **Ventilation:** Ensure proper ventilation around the fireplace unit.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. Refer to the included installation manuals for a detailed list of parts and hardware.

- Marsail Fireplace TV Stand components (Engineered Wood panels)
- 23-inch Electric Fireplace insert
- Remote Control for Electric Fireplace
- Assembly Hardware
- Installation Manuals

4. SETUP AND ASSEMBLY

Assembly of the Marsail Fireplace TV Stand is required. Please follow the step-by-step instructions provided in the separate installation manual included with your product. It is recommended to have two adults for assembly. Ensure you have adequate space and the necessary tools (typically a screwdriver) before starting.

Product Dimensions



This diagram illustrates the overall dimensions of the TV stand (14.2"D x 61"W x 28.7"H) and indicates its compatibility with TVs up to 70 inches, with a maximum weight capacity of 200 lbs.

Key Assembly Features:

- **Adjustable Shelves:** The cabinets feature adjustable shelves, allowing you to customize storage space for various items like DVDs, books, or gaming consoles.
- **Cable Management:** Integrated cable management cutouts are provided at the back of the open top shelf to help organize and conceal wires for electronic devices.
- **Fireplace Installation:** The 23-inch electric fireplace unit is designed to fit securely into the central opening of the TV stand. Follow the specific instructions for its installation and electrical connection.

Customizable Shelving Options



This close-up shows the interior of one of the TV stand's side cabinets, illustrating the adjustable shelf feature which allows for flexible storage configurations.

5. OPERATING INSTRUCTIONS (ELECTRIC FIREPLACE)

The electric fireplace can be operated using the control panel on the unit or the included remote control.

Fireplace Functions:

- **Power:** Turn the fireplace ON or OFF.
- **Temperature Control:** Adjust the heat output from 64°F to 82°F (18°C to 28°C). The LED display will show the current temperature setting.
- **Flame Brightness:** The realistic 3D flame effects can be adjusted through 4 levels of brightness to suit your preference.
- **Timer:** Set an automatic shut-off timer for 1 to 8 hours.
- **Heat Only Mode:** The flame effect can be operated independently of the heating function, allowing for ambiance without heat.



Four Modes



Remote Control Functions



Power



Timer



Flame



Temperature



Heater

This image details the control panel of the electric fireplace, showing the LED display and buttons. It also highlights the remote control functions for power, timer, flame brightness, temperature adjustment, and heater.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your Marsail Fireplace TV Stand.

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Cleaning the Fireplace:** Ensure the fireplace is unplugged and cool before cleaning. Use a soft, dry cloth to wipe the exterior. Do not spray liquids directly onto the unit.
- **Dusting:** Regularly dust the TV stand and fireplace vents to prevent dust buildup, which can affect performance and safety.
- **Inspections:** Periodically check all connections and hardware to ensure they remain tight. Inspect the power cord for any signs of damage.

7. TROUBLESHOOTING

If you encounter issues with your Marsail Fireplace TV Stand or electric fireplace, refer to the following common solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord loose, overheat protection activated.	Check power outlet, ensure cord is securely plugged in. Unplug unit, wait 15 minutes, then plug back in.
No heat output.	Heater function not activated, temperature set too low.	Ensure heater function is ON. Increase temperature setting.
Remote control not working.	Dead batteries, obstruction, out of range.	Replace batteries. Remove obstructions between remote and unit. Ensure remote is within operating range.
Unusual noises from fireplace.	Dust buildup, loose components.	Unplug unit and clean vents. If noise persists, contact customer support.

8. SPECIFICATIONS

- **Brand:** Marsail
- **Model Name:** TV Stand
- **Model Number:** RONGMEI-US VCPIWFS03G-US-17
- **Product Dimensions:** 14.2"D x 61"W x 28.7"H
- **Material:** Engineered Wood
- **Color:** Gray
- **Power Source:** Corded Electric
- **Fireplace Size:** 23 inches
- **Heat Output:** Adjustable (64°F-82°F)
- **Flame Brightness:** 4 levels
- **Timer:** 1-8 hours
- **Maximum TV Size Supported:** 70 inches
- **Weight Capacity:** Up to 200 lbs
- **Special Features:** Cable Management, Adjustable Shelves, Overheat Protection, Anti-pinch Hinges
- **Item Weight:** 108 Pounds
- **UPC:** 840478848762
- **Certifications:** EPA certified materials



Cable Management



Vintage Handles



Soft-Close Hinges

This composite image highlights key features: a cable management cutout for organizing wires, the design of the vintage-style handles on the cabinet doors, and the soft-close hinges for safe and quiet operation.

9. WARRANTY INFORMATION

The Marsail Fireplace TV Stand comes with a Limited Warranty. Please refer to the warranty documentation included with your purchase for specific terms, conditions, and duration of coverage. Retain your proof of purchase for any warranty claims.

10. CUSTOMER SUPPORT

For further assistance, questions regarding assembly, operation, or warranty claims, please contact Marsail customer support. Refer to your purchase documentation or the Marsail brand store on Amazon for contact details.

Marsail Store: [Visit the Marsail Store on Amazon](#)

© 2023 Marsail. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FXN21WLG>

More documents and user manuals: <https://manuals.plus/>