

HB-B108KW10

Generic 8-in-1 Nut Milk Maker

Model: HB-B108KW10 - Instruction Manual

1. INTRODUCTION

Thank you for purchasing the Generic 8-in-1 Nut Milk Maker. This versatile appliance is designed to simplify the process of making fresh, healthy plant-based beverages and other preparations at home. Please read this manual thoroughly before first use to ensure safe operation and optimal performance. Keep this manual for future reference.



Image 1.1: The Nut Milk Maker shown with prepared beverages and ingredients.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not immerse the main unit, power cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Exercise extreme caution when moving an appliance containing hot liquid.
- The blades are sharp. Handle with care during assembly, disassembly, and cleaning.

3. PRODUCT OVERVIEW

3.1 Components

The Nut Milk Maker consists of the following main components:

- Main Unit with Heating Element and Blending Blades
- Lid with Handle
- Control Panel
- Power Cord
- Measuring Cup (Included Accessory)
- Cleaning Brush (Included Accessory)

3.2 Control Panel and Features

The intuitive control panel allows for easy selection of functions and settings. The appliance features 8 integrated functions and a 12-hour delay start option.



Image 3.1: The Nut Milk Maker's control panel.

- **8-in-1 Versatility:** Soy Milk, Nut Milk, Oat Milk, Fruit & Veggie Drinks, Rice Paste, Smoothies, Boil Water, and High-Temp Cleaning.
- **Large Capacity:** 34 oz (approximately 1 liter) capacity suitable for family use.
- **Low-Noise Operation:** Designed to operate below 80 dB, minimizing disturbance.
- **Hands-Free Cleaning:** Automatic high-temperature water and powerful rotation for thorough cleaning.
- **Smooth Texture:** Equipped with 10 stainless steel blades and a 4-sided turbulence design for ultra-fine blending without the need for filtering.
- **12-Hour Delay Start:** Allows for convenient preparation of drinks at a preset time.

4. SETUP

4.1 Unpacking

1. Carefully remove all components from the packaging.
2. Check that all listed components are present.
3. Remove any protective films or packaging materials.

4.2 Initial Cleaning

Before first use, clean the appliance thoroughly:

1. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
2. Wash the interior of the pitcher and the lid with warm, soapy water. Rinse thoroughly.
3. Run the "High-Temp Cleaning" cycle with clean water (refer to Section 6.1 for details).
4. Ensure all parts are completely dry before assembly and use.

4.3 Placement

Place the appliance on a stable, flat, heat-resistant surface, away from the edge of the counter and out of reach of children.

5. OPERATING INSTRUCTIONS

5.1 General Operation

1. Ensure the appliance is plugged into a grounded electrical outlet.
2. Open the lid and add your desired ingredients and water into the pitcher. Do not exceed the maximum fill line.
3. Close the lid securely.
4. Select the desired function using the control panel.
5. Press the Start/Stop button to begin the program.
6. Once the program is complete, the appliance will beep and enter standby mode.
7. Carefully open the lid and pour out the prepared beverage.



Image 5.1: Pouring a beverage from the Nut Milk Maker.

5.2 Program Functions

The appliance offers 8 distinct programs:

- **Soy Milk:** For preparing traditional soy milk from soybeans.
- **Nut Milk:** Ideal for making milk from various nuts like almonds, cashews, or walnuts.
- **Oat Milk:** Specifically designed for oat-based beverages.
- **Fruit & Veggie Drinks:** For blending fresh fruits and vegetables into juices or smoothies.
- **Rice Paste:** Prepares creamy rice paste or congee.

- **Smoothies:** Quick blending for cold smoothies.
- **Boil Water:** Heats water to boiling temperature.
- **High-Temp Cleaning:** An automatic cleaning cycle using hot water (see Section 6.1).

Refer to the included recipe guide for recommended ingredient ratios and preparation times for each function.

5.3 Delay Start Function

The 12-hour delay start function allows you to set a program to begin at a later time.

1. Add ingredients and water to the pitcher.
2. Select your desired program (e.g., Nut Milk).
3. Press the "Delay" button. Use the +/- buttons to adjust the delay time in hours.
4. Press the Start/Stop button to confirm. The appliance will start the selected program after the set delay time.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygienic operation of your appliance.



6.1 Automatic High-Temp Cleaning

This feature provides hands-free cleaning for the interior of the pitcher and blades.

1. After use, rinse the interior of the pitcher to remove large food particles.
2. Fill the pitcher with clean water up to the minimum fill line. A small amount of mild dish soap can be added if desired.
3. Close the lid securely.
4. Select the "High-Temp Cleaning" program on the control panel.
5. Press the Start/Stop button. The appliance will run a cleaning cycle using hot water and powerful rotation.
6. Once the cycle is complete, carefully discard the water and rinse the interior thoroughly with clean water.

6.2 Manual Cleaning

- Always unplug the appliance before cleaning.
- Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners.
- For stubborn residue inside the pitcher, use the provided cleaning brush and warm, soapy water. Exercise caution around the sharp blades.
- The lid can be washed with warm, soapy water and rinsed.
- Ensure all parts are completely dry before storing or next use.

7. TROUBLESHOOTING

If you encounter issues with your Nut Milk Maker, please refer to the following table before contacting customer support.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; check circuit breaker; try a different outlet.
Program does not start.	Lid not securely closed; program not selected.	Ensure lid is properly seated; select a program and press Start/Stop.
Motor sounds strained or stops.	Overfilling; ingredients too large/hard; overheating.	Do not exceed max fill line; cut ingredients into smaller pieces; allow appliance to cool down.
Beverage is not smooth.	Insufficient blending time; too little liquid.	Ensure correct program is selected; add more liquid if necessary; run program again.
Leakage from lid.	Lid not properly sealed; overfilling.	Ensure lid is securely closed; do not exceed max fill line.

8. SPECIFICATIONS

Brand	Generic
-------	---------

Model Number	HB-B108KW10
Color	Ivory
Capacity	1 Liters (34 oz)
Product Dimensions	7.48"D x 7.48"W x 11.1"H
Item Weight	3.31 pounds
Power Source	AC
Special Feature	Automatic Cleaning, 8-in-1 Functions, 12-Hour Delay
Manufacturer	VEVOR

9. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact the retailer. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact the manufacturer or your point of purchase.
