



[Manuals.plus](#) /

> [Auvsoce](#) /

> Auvsoce 71-inch Loveseat Sofa with USB Charging and Storage, Model B0FXPRF6Q7 Instruction Manual

Auvsoce B0FXPRF6Q7

Auvsoce 71-inch Loveseat Sofa Instruction Manual

Model: B0FXPRF6Q7

1. INTRODUCTION

Thank you for purchasing the Auvsoce 71-inch Loveseat Sofa. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your new furniture. Please read this manual thoroughly before assembly and retain it for future reference.

Safety Information

- Keep all packaging materials away from children to prevent suffocation hazards.
- Ensure all components are securely fastened before use. Regularly check and tighten fasteners.
- Do not stand on the sofa or use it as a step stool.
- Avoid placing hot items directly on the fabric.
- Do not overload the storage compartments.
- Use the USB charging port only for compatible devices and avoid exposing it to liquids.

2. INCLUDED COMPONENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Sofa Frame Sections (Backrest, Seat Base, Armrests)
- Seat Cushions
- Back Cushions
- Legs
- Hardware Pack (bolts, washers, Allen wrench)
- Installation Accessories (pre-installed USB port, storage hinges)




Figure 2.1: Overview of sofa components and assembly points.

3. ASSEMBLY INSTRUCTIONS

The Auvsoce loveseat sofa is designed for quick and tool-free assembly. Follow these steps to set up your sofa.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, soft surface to prevent scratches.
2. **Attach Legs:** Locate the four sofa legs. Align each leg with the pre-drilled holes on the underside of the sofa base. Twist the legs clockwise until they are securely tightened. No tools are required for this step.
3. **Connect Armrests:** Slide the armrests onto the metal brackets located on the sides of the sofa base. Ensure they click into place firmly.
4. **Attach Backrest:** Align the backrest with the corresponding brackets on the rear of the sofa base. Push down firmly until it locks into position.
5. **Place Cushions:** Position the seat cushions onto the sofa base and the back cushions against the backrest. Gently press them to ensure they are seated correctly.
6. **Final Check:** Verify that all connections are secure and the sofa is stable before use.



Figure 3.1: Side view with dimensions for reference during assembly.

4. OPERATING FEATURES

Armrest Storage

The Auvsoce loveseat features integrated storage compartments within both armrests. To access, gently lift the top panel of the armrest. The dimensions of each storage space are approximately 26.8 inches (L) x 15.8 inches (W) x 5.91 inches (D). These are suitable for storing small items like blankets, pillows, magazines, or remote controls.



Figure 4.1: Armrest storage compartment in open position.



Figure 4.2: Dimensions of the internal storage space.

USB Charging Port

A built-in USB charging port is located on one of the armrests for convenient device charging. Simply connect your USB charging cable to the port and your device. Ensure the sofa is positioned near a power outlet for the USB port to function.



Figure 4.3: USB charging port in use.

5. CARE AND MAINTENANCE

Proper care will extend the life and appearance of your Auvsoce loveseat sofa.

- **Regular Cleaning:** Vacuum the corduroy fabric regularly using a soft brush attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain. For stubborn stains, use a mild fabric cleaner specifically designed for corduroy, testing on an inconspicuous area first.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading. Position your sofa away from direct sun exposure or use curtains/blinds.
- **Fluff Cushions:** Periodically fluff and rotate cushions to maintain their shape and even out wear. The high-resilience sponge cushioning is designed to restore its shape.
- **Frame Care:** Wipe the solid wood frame components with a soft, damp cloth. Avoid harsh chemicals.



Figure 5.1: Close-up of the corduroy fabric texture.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Sofa feels unstable or wobbly.	Legs or frame connections are loose.	Ensure all legs are tightly screwed in. Check and re-secure all frame connections.
Cushions appear flat or misshapen.	Normal compression from use.	Fluff and rotate cushions regularly. The high-resilience foam should regain shape.
USB port is not charging devices.	Sofa not connected to power, or device/cable issue.	Ensure the sofa's power cord (if applicable) is plugged into a working outlet. Test with a different USB cable or device.

Problem	Possible Cause	Solution
Armrest storage lid does not close properly.	Obstruction or hinge misalignment.	Check for items blocking the lid. Ensure hinges are properly aligned and not damaged.

7. PRODUCT SPECIFICATIONS

Brand: Auvsoce

Model: B0FXPRF6Q7

Color: Beige

Material Type: Corduroy Fabric, Solid Wood Frame

Product Dimensions (D x W x H): 33.1"D x 71"W x 33.5"H

Seat Height: 19 Inches

Item Weight: 97 Pounds

Seating Capacity: 2

Assembly Required: Yes (Minimal, tool-free)

Included Components: Installation accessories, USB Charging Port

8. WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation included with your purchase or contact the retailer. If you encounter any issues or have questions regarding your Auvsoce loveseat sofa, please reach out to Auvsoce customer support for assistance.

Contact information can typically be found on the product packaging or the official Auvsoce website.