

Yeichen Walnut 59" Sideboard Buffet Cabinet

Yeichen Walnut 59" Sideboard Buffet Cabinet - Instruction Manual

Model: Walnut 59" Sideboard Buffet Cabinet

1. INTRODUCTION

Thank you for choosing the Yeichen Walnut 59" Sideboard Buffet Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

This versatile cabinet features 3D geometric pattern doors, adjustable shelves, and a durable walnut finish, designed to complement various living spaces including living rooms, dining rooms, kitchens, and entryways.

2. SAFETY INFORMATION

To ensure safe assembly and use of this product, please observe the following guidelines:

- **Two-Person Assembly:** It is highly recommended that two adults assemble this cabinet to prevent injury and ensure proper construction.
- **Clear Workspace:** Assemble the unit in a spacious, clear area to avoid tripping hazards and damage to components.
- **Tool Use:** Use appropriate tools as specified in the assembly instructions. Do not overtighten screws, as this may damage the material.
- **Wall Anchoring:** For stability and safety, especially in households with children or pets, secure the cabinet to a wall using the provided anti-tip hardware. Failure to do so may result in serious injury.
- **Weight Limits:** Do not exceed the specified weight limits for the top panel, shelves, and bottom panel. Overloading can cause structural failure.
- **Level Surface:** Place the assembled cabinet on a flat, level surface to prevent wobbling and ensure stability.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware listed below are present and undamaged. If any items are missing or damaged, please contact customer support.

Parts List

- 1. Top Panel (1)
- 2. Side Panels (2, 3)
- 3. Bottom Panel (4)
- 4. Middle Panel (5)
- 5. Base Rails (6x2, 7x2, 8x2)
- 6. Adjustable Shelves (9x2)
- 7. Left Doors (10, 11)
- 8. Right Doors (12, 13)
- 9. Back Panels (14x4)

Hardware List

- 1. A: Cam Bolts (x28+2)
- 2. B: Cam Locks (x28+2)
- 3. C: Wooden Dowels (x24+2)
- 4. D: Screws (x16+2)
- 5. E: Screws (x16+2)
- 6. F: Gold Handles (x4)
- 7. G: Door Bumpers (x16+2)
- 8. H: Anti-Tip Kit (x2)
- 9. I: Screws (x24+2)
- 10. J: Screws (x48+2)
- 11. K: Magnetic Catches (x4)
- 12. L: Metal Plates for Magnetic Catches (x8)
- 13. M: Hinges (x4)
- 14. N: Hinges (x4)
- 15. O: Shelf Pins (x4)



Image: Overview of all cabinet parts and hardware.

4. ASSEMBLY INSTRUCTIONS

Before You Begin

- Ensure you have a Phillips head screwdriver and a power drill (optional, for faster assembly).
- Clear a large, flat area for assembly.
- Separate and identify all parts and hardware using the provided lists.

Step-by-Step Assembly

For a visual guide, please refer to the assembly video below.

Video: Detailed assembly guide for the Yechen Accent Sideboard Buffet Cabinet.

1. **Prepare Base Panels:** Attach magnetic catches (K) and cam bolts (A) to the bottom panel (4) and base rails (6).
2. **Prepare Side Panels:** Insert cam bolts (A) into side panels (2, 3, 5).
3. **Assemble Base Frame:** Connect base rails (6) and support pieces (7) using cam locks (B) to form the rectangular base frame.
4. **Attach Support Rails:** Secure support rails (8) to the middle panel (5) using cam locks (B).
5. **Connect Side Panels to Base:** Attach side panels (2, 3) to the support rails (8) and middle panel (5) using cam locks (B).
6. **Install Back Panels:** Slide back panels (14) into the grooves of the assembled structure.
7. **Attach Top Panel:** Insert wooden dowels (C) into the top edges of the side and middle panels. Place the top panel (1) onto the dowels and secure with screws (D).
8. **Secure Top Frame:** Place the assembled base frame (from Step 3) onto the top panel and secure it using cam locks (B).
9. **Install Adjustable Shelves:** Insert shelf pins (O) into the desired holes inside the cabinet compartments. Place adjustable shelves (9) onto the pins.
10. **Prepare Doors:** Attach hinges (M, N) to doors (10, 11, 12, 13) using screws (J). Attach gold handles (F) using screws (E) and metal plates (L).
11. **Install Doors:** Mount the prepared doors (10, 11, 12, 13) to the cabinet frame by screwing the hinges into the pre-drilled holes.
12. **Adjust Hinges:** Fine-tune door alignment using the adjustment screws on the hinges.
13. **Install Door Bumpers:** Apply door bumpers (G) to the inside corners of the cabinet frame where the doors close.
14. **Install Anti-Tip Kit:** Secure the anti-tip kit (H) to the back of the cabinet and to a wall stud as per the instructions provided with the kit.

5. OPERATING INSTRUCTIONS

Opening and Closing Doors

The cabinet doors are equipped with soft-closing hinges for quiet and smooth operation. Gently push or pull the gold handles to open and close the doors. Avoid forcing the doors to prevent damage to the hinges.



SOFT-CLOSING HINGES

Doors close silently and safely every time. No more slamming—just peaceful, lasting quality.



SCRATCH & WATER RESISTANT TOP

Beautiful woodgrain texture, built for real life. Worry-free from spills, stains, and daily wear.



SLEEK & MODERN GOLD HANDLES

Featuring clean lines and a smooth, refined touch that elevates your space



Image: Soft-closing hinges and sleek gold handles for smooth door operation.

Adjusting Shelves

The internal shelves are adjustable, allowing you to customize storage space to fit items of various heights. To adjust a shelf:

1. Empty the shelf of all contents.
2. Carefully lift the shelf to remove it from the shelf pins.
3. Relocate the shelf pins to the desired height in the pre-drilled holes.
4. Place the shelf back onto the pins, ensuring it is level and secure.

SPACIOUS SPACE & ADJUSTABLE SHELVES

Organize Dishes, Glassware, and Kitchen essentials While Keeping Your Dining Area Neat and Stylish
Adjustable Shelves for Your Evolving Needs.



Image: Adjustable shelves provide flexible storage options within the cabinet.

6. MAINTENANCE

Proper care will extend the life and appearance of your Yechen Sideboard:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage or staining. The surface is scratch and water-resistant, but prolonged exposure to liquids should be avoided.
- **Sunlight:** Avoid placing the cabinet in direct sunlight for extended periods, as this can cause fading or discoloration of the wood finish.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.

- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your cabinet, refer to the following common problems and solutions:

- **Wobbly Cabinet:**
 - Ensure the cabinet is placed on a level surface.
 - Check that all cam locks and screws are fully tightened.
 - Verify that the anti-tip kit is securely installed.
- **Doors Not Closing Properly:**
 - Adjust the hinges using a Phillips head screwdriver. There are typically screws for horizontal, vertical, and depth adjustments.
 - Ensure the magnetic catches are properly aligned with the metal plates on the doors.
- **Shelves Not Level:**
 - Ensure shelf pins are fully inserted into the corresponding holes on both sides.
 - Verify that the shelf itself is not warped.
- **Missing Parts:**
 - Double-check the packaging. If parts are genuinely missing, contact customer support with your product model and the specific part number.

8. SPECIFICATIONS

Feature	Detail
Brand	Yechen
Color	Walnut
Product Dimensions	15.8"D x 59"W x 31.5"H
Material	Engineered Wood (P2 certified MDF)
Finish Type	Wooden Finished (3D Wood Grain)
Special Features	3D Geometric Textured Doors, Adjustable Shelves, Soft-Close Hinges, Scratch & Water Resistant Top
Mounting Type	Floor Mount

Weight Limit (Top Panel)	150 Pounds
Weight Limit (Each Shelf)	30 Pounds
Number of Shelves	3 (adjustable)
Assembly Required	Yes

PRODUCT DIMENSION

Combined Dimensions (Two Units): 118" W x 15.4" D x 31.5" H
Ideal for Large Wall Spaces. Each Sideboard Measures 59" W for Flexible Placement



150LBS
TOP PANEL



30LBS
EACH SHELF



150LBS
BOTTON PANEL

Image: Detailed product dimensions and weight capacities.

9. WARRANTY AND SUPPORT

For warranty information or assistance with your Yechen Walnut 59" Sideboard Buffet Cabinet, please refer to the purchase documentation or contact the seller directly. Our customer support team is available to help with any questions or concerns you may have regarding assembly, parts, or product functionality.

© 2025 Yechen. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question