

Manuals.plus /

› PIkm /

› PIkm Wireless Dog Fence System with Display Receiver and 360° Signal Coverage (Model 05FX-04-GP-AS01-B-1C) - Instruction Manual

PIkm 05FX-04-GP-AS01-B-1C

PIkm Wireless Dog Fence System

MODEL: 05FX-04-GP-AS01-B-1C

Introduction

The PIkm Wireless Dog Fence System provides a safe and reliable way to create an invisible boundary for your pet. Utilizing advanced radio signals, this system helps keep your dog within a designated play area without the need for physical fences. It features real-time battery monitoring, multiple correction modes, and a static-free reentry system to ensure your pet's safety and comfort.

Package Contents

Before you begin, please ensure all items are present in your package:

- Transmitter Unit
- Collar Receiver
- Adjustable Fabric Collar
- USB Charger
- USB Charge Cable
- Contact Points (short and long pairs)
- Test Light
- Boundary Flags (for training)



HIGH DENSITY WATERPROOF RECEIVER

Image: All components included in the Plkm Wireless Dog Fence System package.

Setup

1. Transmitter Placement

Place the transmitter unit in a central location within your desired containment area. The transmitter establishes an invisible circular boundary using radio signals. Ensure the transmitter is placed where its signal will not be significantly obstructed by large metal objects or dense foliage for optimal coverage. The system offers 360° strong signal penetration, meaning walls, houses, or neighboring trees will not significantly affect the signal range.



THE TRANSMITTER CONSTITUTES AN INVISIBLE BOUNDARY LINE BY MEANS OF RADIO SIGNAL, THE TRANSMITTER AI ALARMS WHEN DOG WEARING RECEIVER APPROACHES THIS LINE.



Image: Proper placement of the transmitter unit within a home to establish a circular boundary.

2. Collar Receiver Assembly

Attach the appropriate contact points to the collar receiver. Choose between the long or short contact points based on your dog's fur length to ensure proper contact with the skin. For dogs with longer fur, use the longer contact points. For dogs with shorter fur, use the shorter contact points.

3. Collar Fit

Adjust the fabric collar to ensure a snug but comfortable fit around your dog's neck. The contact points should touch your dog's skin. You should be able to fit one or two fingers comfortably between the collar and your dog's neck. Avoid overtightening, which can cause discomfort, or leaving it too loose, which may prevent effective correction.

Operating Instructions

1. Power On/Off

To power on the transmitter or receiver, long-press the power button until the display illuminates. To power off, long-press the power button again until the device shuts down.

2. Setting the Boundary Range

The wireless dog fence allows you to set a circular invisible boundary for your dog's play area. The radius can be adjusted from 140 to 360 feet, corresponding to 1-9 acres, across 5 distinct levels. Use the signal range set buttons on the transmitter to adjust the desired radius. A simple operation allows you to establish a safe and free play area for your dog.



Image: Visual representation of adjustable boundary levels and their corresponding acreage.

3. Correction Modes and AI Alarm

The system provides multiple correction modes: sound, vibration, and electrostatic shock stimulation. The transmitter features an AI alarm system that activates when the collar receiver's battery is low, or when the dog approaches or crosses the boundary. This alarm light flashes to notify the owner.



Image: Transmitter display showing receiver battery level and AI alarm in action.

4. Static-Free Reentry

A unique feature of this system is static-free reentry. If your pet crosses the boundary, they can return to the safe area without receiving further correction. This design reduces fear and confusion, encouraging your dog to return to the designated safe zone.



Image: Static-free reentry allows pets to return to the safe area without further correction.

Training Your Dog

Effective training is crucial for your dog to understand the wireless fence system. Use the provided boundary flags to visually mark the perimeter during the initial training phase. Guide your dog towards the boundary, allowing them to experience the sound and vibration correction. Immediately call them back to the safe zone and reward them. Repeat this drill 2-3 times a day for 1-2 weeks until your dog understands the boundaries and learns to stop or turn back when they hear the collar's warning.

Video: Instructions on how to train your dog effectively with the wireless fence collar, demonstrating the use of markers and positive reinforcement.

Features

360° Strong Signal Coverage

The system boasts strong signal penetration, ensuring consistent coverage even in complex environments. The signal can turn and change direction, allowing it to be received at every angle, providing reliable containment for your pet.

Waterproof Receiver

The collar receiver is designed to be highly waterproof, allowing your dog to play in various weather conditions or near water without damaging the device.



Image: The waterproof design of the collar receiver ensures durability in various conditions.

Maintenance

Charging

The system requires 1 Lithium Ion battery (included). Ensure both the transmitter and receiver are fully charged before initial use. The transmitter typically requires 4-5 hours for a full charge, while the receiver collar takes approximately 1-2 hours. Flashing lights on the receiver indicate charging status.

Cleaning

Regularly clean the collar receiver and contact points to prevent skin irritation and ensure proper function. Use a damp cloth to wipe down the devices. Avoid using harsh chemicals.

Troubleshooting

If your system is not functioning as expected, please check the following:

- **No Correction:** Ensure the collar is properly fitted with contact points touching the skin. Check battery levels of both transmitter and receiver.
- **Inconsistent Signal:** Verify the transmitter's placement is central and free from major obstructions. Adjust the boundary range settings.
- **AI Alarm:** If the AI alarm is constantly active, check the receiver's battery level or ensure the dog is within the set boundary.

Specifications

Feature	Detail
Item Weight	1.72 pounds
Item Model Number	05FX-04-GP-AS01-B-1C
Batteries	1 Lithium Ion batteries required (included)
Item Package Dimensions L x W x H	11.97 x 6.73 x 3.82 inches
Color	Black
Included Components	Dog fence system (Transmitter, Receiver, Collar, Charger, Contact Points, Test Light, Flags)

Warranty and Support

For any questions, concerns, or warranty information regarding your Plkm Wireless Dog Fence System, please refer to the contact information provided with your purchase or visit the official Plkm website for customer support. Our team is dedicated to providing assistance and ensuring your satisfaction.