

[Manuals.plus](#) /

› [PaiPaitek](#) /

› PaiPaitek PD 526-TIO Collar Receiver Instruction Manual

PaiPaitek PD 526-TIO

PaiPaitek PD 526-TIO Collar Receiver Instruction Manual

For Remote Dog Training Collar Replacement with Auto Bark Mode

INTRODUCTION

This manual provides detailed instructions for the PaiPaitek PD 526-TIO Collar Receiver, designed for use with the corresponding remote dog training system. It combines automatic bark detection with remote training capabilities, offering sound, vibration, and static stimulation modes. This receiver is suitable for dogs weighing 4 to 120 pounds.

PACKAGE CONTENTS

- PaiPaitek PD 526-TIO Collar Receiver
- Adjustable Collar Strap
- Silicone Contact Points (various sizes)
- Anti-shock Pads
- Charging Cable
- Whistle

Safe and Effective Training

No Shock Training



Image: The PaiPaitek PD 526-TIO collar receiver, remote control, and included accessories.

SETUP

1. Initial Charging

Before first use, charge the receiver for at least 6 hours. Ensure the charging port is clean and dry before connecting the charging cable.

Super Easy To Use



Image: Close-up view of the PaiPaitek PD 526-TIO receiver, highlighting the charging port.

2. Pairing the Receiver with the Remote

To use the receiver, it must be paired with the remote control. You can pair multiple receivers to the same or different signal channels on the remote, depending on your training needs.

- **For training multiple dogs simultaneously on the same command:** Connect up to three receivers to the same signal channel on the remote. When you press a command button (e.g., beep), all paired receivers on that channel will respond.
- **For training individual dogs:** Connect each receiver to a different signal channel on the remote. Use the "CH" button on the remote to switch between channels and train each dog individually.

3. Attaching Contact Points and Anti-Shock Pads

The collar comes with silicone contact points of various sizes to accommodate both long-haired and short-haired dogs. Choose the appropriate length to ensure proper contact with your dog's skin. If you prefer not to use the static stimulation mode, install the provided anti-shock pads for enhanced comfort and skin protection.



Image: The collar receiver with short contact points, suitable for dogs with short hair.



Image: The collar receiver with long contact points, suitable for dogs with long hair.

4. Fitting the Collar

Ensure the collar is fitted snugly but comfortably. You should be able to insert one finger between the collar and your dog's neck. A collar that is too loose may not deliver effective stimulation, while a collar that is too tight can cause discomfort. If the collar strap is excessively long, trim it to an appropriate length. After trimming, you can use a lighter to carefully melt the frayed edges to prevent burring.

100% Waterproof

Adjustable Collar for
20-120 lbs of Dogs



Image: A dog wearing the PaiPaitek PD 526-TIO collar, demonstrating proper fit and adjustability for various neck sizes.

OPERATING INSTRUCTIONS

1. Powering On/Off

To power on or off the receiver, long-press the ON/OFF button located on the receiver unit. The remote control also has a power button.

Super Easy To Use



Image: The remote control and receiver, showing the ON/OFF buttons for both devices.

2. Training Modes

The system offers three primary training modes:

- **Sound (Beep) Mode:** Delivers an audible tone.
- **Vibration Mode:** Provides a tactile vibration. Levels 1-100 are adjustable.
- **Static Stimulation (Shock) Mode:** Delivers a static pulse. Levels 1-100 are adjustable.

Use the remote control to select and adjust the intensity levels for vibration and static stimulation modes. Always start with the lowest effective level and gradually increase if necessary.

Dog Bark and Training Collar 2 in 1



Image: The remote control interface, illustrating the Auto Mode, Beep, Vibration (1-100 Levels), and Safe Shock (1-100 Levels) options.

3. Automatic Bark Mode

The receiver features an automatic bark detection mode. To activate or deactivate this mode, long-press the ON/OFF button on the receiver. When active, the collar will automatically apply corrections (sound, vibration, or static stimulation, depending on settings) when it detects barking.

4. Multi-Dog Training

The remote can control up to three receivers simultaneously. Use the "CH" button on the remote to switch between channels (dogs) for individual training, or pair multiple receivers to the same channel for group commands.

5. Remote Control Functions

The remote control includes buttons for:

- **Level Adjustment:** To increase or decrease intensity for vibration and static stimulation.
- **Beep:** Activates the sound mode.
- **Vibrate:** Activates the vibration mode.
- **Safe Shock:** Activates the static stimulation mode.

- **CH (Channel Switching):** To select which dog (receiver) to train.
- **Flashlight:** For visibility in low-light conditions.

Super Easy To Use



Image: Detailed view of the remote control, with labels for Flashlight, Level Adjustment, Beep, ON/OFF, Vibrate, Channel Switching, and Safe Shock buttons.

MAINTENANCE AND CARE

1. Wearing Duration

It is recommended that your dog wear the collar for no more than 18 hours per day. For professional training sessions, check the collar's position every 1-2 hours to prevent skin irritation.

2. Waterproofing

The receiver is IPX7 waterproof, allowing your dog to swim or be exposed to rain without damage. Ensure the charging port cover is securely closed when not charging.

100% Waterproof

Adjustable Collar for
20-120 lbs of Dogs



Image: The collar receiver shown partially submerged in water, illustrating its IPX7 waterproof rating.

3. Battery Life

The receiver offers an extended battery life of up to 20 days on a single charge, depending on usage.

4. Cleaning

Regularly clean the receiver and contact points with a damp cloth to remove dirt and debris. Ensure the device is completely dry before charging or use.

TROUBLESHOOTING

- **Collar not responding:** Check battery levels of both receiver and remote. Ensure they are properly paired and on the correct channel. Verify the collar is fitted correctly and contact points are making proper contact.
- **Ineffective stimulation:** Adjust the collar fit to ensure contact points touch the dog's skin. Increase the intensity level gradually. For long-haired dogs, ensure the longer contact points are used.
- **Skin irritation:** Ensure the collar is not worn for more than 18 hours a day. Check the collar position frequently. If irritation occurs, remove the collar and consult a veterinarian. Consider using the anti-shock pads or alternative training modes.

- **Automatic bark mode not working:** Ensure the automatic bark mode is activated by long-pressing the ON/OFF button on the receiver.

SPECIFICATIONS

Model Name	PD 526-TIO
Brand	PaiPaitek
Target Audience	Dogs (4 to 120 lbs)
Training Modes	Sound, Vibration (1-100 levels), Static Stimulation (1-100 levels), Auto Bark Mode
Remote Range	Up to 3300 feet
Waterproof Rating	IPX7
Battery Life	Up to 20 days (receiver)
Color	Black
Closure Type	Buckle

WARRANTY AND SUPPORT

This product comes with a **1-year manufacturer's warranty**. For technical support, warranty claims, or further assistance, please contact PaiPaitek customer service. Refer to the product packaging or the official PaiPaitek website for contact information.