

Lyromix CDCF-001

Lyromix 27-inch Dog Crate Furniture Instruction Manual

Model: CDCF-001

INTRODUCTION

This manual provides detailed instructions for the assembly, setup, operation, and maintenance of your Lyromix 27-inch Dog Crate Furniture. This product is designed to serve as both a comfortable enclosure for your small dog and a functional end table, seamlessly blending into your home decor. It features a sturdy construction and a versatile three-door design.

SAFETY INFORMATION

- Ensure all parts are securely fastened before allowing your pet to use the crate.
- Do not allow children to climb on or play inside the crate.
- Place the crate on a flat, stable surface to prevent tipping.
- Regularly inspect the crate for any loose or damaged parts and address them immediately.
- This product is intended for indoor use only.
- Do not use harsh chemicals for cleaning; refer to the maintenance section.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

Component	Quantity
Wooden Panels (Top, Bottom, Sides)	Varies by design
Metal Bar Panels	Varies by design

Component	Quantity
Doors	3
Hardware (Screws, Bolts, Wrenches)	1 Set
Instruction Manual	1

ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your dog crate furniture. It is recommended to have a second person assist with assembly.

- Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Refer to the parts list in your manual to identify each piece.
- Assemble Side Panels:** Attach the metal bar panels to the wooden side panels using the provided screws and tools. Ensure all connections are snug but do not overtighten.
- Attach Bottom Panel:** Secure the bottom wooden panel to the assembled side panels.
- Install Doors:** Attach the three doors to their designated openings using the hinges and hardware. Ensure the doors swing freely and the latches align properly.
- Attach Top Panel:** Place the top wooden panel onto the assembled structure and secure it with the remaining hardware.
- Final Tightening:** Once fully assembled, gently tighten all screws and bolts to ensure stability. Do not overtighten to avoid damaging the wood.

Various Combination Choice

The middle partition can be removed after connection



Figure 1: Assembly diagram illustrating the components and step-by-step construction of the dog crate.

SETUP

Placement

Choose a suitable indoor location for your dog crate furniture. Its design allows it to function as an end table, so consider placing it next to a sofa, bed, or in a corner where it can serve a dual purpose.

Sizing for Your Dog

To ensure your dog is comfortable, measure your dog's length and height while standing. Add 4 inches to both measurements to determine the appropriate crate size. If your dog prefers to sprawl out, measure them in their natural sleeping position to ensure ample space.



Figure 2: Product dimensions for the 27-inch dog crate, including internal space.

OPERATING

Door Operation

The Lyromix dog crate features three doors for flexible access. Each door is equipped with a secure latch mechanism. To open, slide the latch bolt back and pull the door open. To close, push the door shut and slide the latch bolt forward until it clicks into place.



Figure 3: The dog crate functioning as an end table with a dog inside, demonstrating the three-door design.

Combination Options

This dog crate furniture is designed for modularity. Multiple units can be combined to create larger enclosures or stacked configurations:

- **54-inch Large Dog Crate:** Two units can be combined side-by-side to form a larger crate suitable for bigger dogs. The middle partition can be removed after connection.
- **Stacked Dog Crate:** Units can be stacked to create a double-decker crate, ideal for multiple pets or saving floor space.
- **L-shaped Corner Crate:** Arrange multiple units into an L-shaped configuration to utilize corner spaces efficiently.



Figure 4: Example of two units combined to create a larger dog crate.

MAINTENANCE

Cleaning

- For routine cleaning, wipe down wooden surfaces with a soft, damp cloth.
- For metal bars, use a mild soap solution and a soft cloth, then dry thoroughly to prevent rust.
- Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- Immediately clean up any spills or accidents to prevent staining or odor absorption.

Care

- Periodically check all screws and bolts and tighten them if necessary to maintain structural integrity.
- Keep the crate away from direct sunlight or extreme temperature changes to prevent warping or fading of the wood.

TROUBLESHOOTING

Loose Connections

If the crate feels wobbly, check all assembly points and tighten any loose screws or bolts. Ensure all components are correctly aligned according to the assembly instructions.

Door Malfunction

If a door does not open or close smoothly, inspect the hinges for any obstructions or damage. Ensure the latch mechanism is clean and free of debris. If necessary, slightly adjust the door's position or hinge screws.

SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	26.93" x 20.87" x 24.02"
Item Weight	39.68 Pounds
Model Number	CDCF-001
Material	Engineered Wood, Metal
Color	Walnut
Specific Uses	Indoor
Special Feature	Lockable, 3 Doors, Combination Options
Breed Recommendation	Small breeds
UPC	797417438853

WARRANTY AND SUPPORT

Warranty

This Lyromix dog crate furniture comes with a 3-month warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, assistance with assembly, or to report missing/damaged parts, please contact Lyromix customer support. Refer to the contact information provided with your purchase or visit the official Lyromix website.