

[Manuals.plus](#) /

› [EasyCom](#) /

› Easycom 41-inch Foldable Dog Crate Furniture Instruction Manual (Model PS-DC108-41-OC)

## EasyCom PS-DC108-41-OC

# Easycom 41-inch Foldable Dog Crate Furniture Instruction Manual

Model: PS-DC108-41-OC

## INTRODUCTION

---

Thank you for choosing the Easycom 41-inch Foldable Dog Crate Furniture. This product is designed to provide a comfortable and secure space for your dog while seamlessly blending with your home decor as a functional piece of furniture. This manual provides essential information for setup, operation, maintenance, and specifications to ensure optimal use and longevity of your dog crate.

## Loving Time with Your Puppy



*Image: The Easycom dog crate furniture in a living room setting, showcasing its dual functionality as a pet enclosure and an end table.*

### SAFETY INFORMATION

- This dog crate is intended for **indoor use only**.
- Recommended for dogs weighing **35-60 pounds**. Ensure your dog's size is appropriate for the crate dimensions to prevent discomfort or injury.
- Regularly inspect the crate for any signs of wear or damage. Do not use if any parts are broken or missing.
- Ensure all latches are securely fastened when your dog is inside the crate.
- Keep small children away from the crate during assembly and when a pet is inside.

### PACKAGE CONTENTS

Your Easycom dog crate furniture comes pre-assembled and includes the following items:


- 1 x Foldable Dog Crate Furniture Unit

- 2 x Stainless Steel Adjustable Bowls
- 1 x Bone-shaped Name Tag
- 4 x Paw Print Magnets
- Chalk (for name tag personalization)

## SETUP

The Easycom dog crate features a no-assembly design and unfolds in approximately 30 seconds.

1. **Unpack the Crate:** Carefully remove the folded crate from its packaging.
2. **Unfold the Sides:** Gently pull the side panels outwards until the crate forms its rectangular shape.
3. **Secure the Top:** Lower the wooden top panel into place, ensuring it aligns with the frame. The top is designed to sit securely without additional fasteners.
4. **Install Bowls:** Attach the stainless steel bowls to the designated rotatable holders on the front door.



### Within 30s



*Image: Visual guide demonstrating the quick and easy unfolding process of the dog crate from its compact, flat-packed state to a fully functional unit.*

## OPERATING INSTRUCTIONS

### Using the Doors

- The crate features a double-door setup for flexible placement and easy access.
- To open, slide the latch mechanism on the door. Ensure it is fully engaged when closing to secure your pet.

### Adjustable Feeding Bowls

The integrated feeding station allows for convenient feeding without opening the main door.

1. **Rotate Bowls:** The stainless steel bowls are held in a swivel door. Pull the small pin to rotate the bowls inwards for your dog to access food and water.
2. **Adjust Height:** The bowls can be adjusted to two different heights to suit dogs of various sizes. Refer to the image below for visual guidance.
3. **Secure After Feeding:** After your dog has finished, rotate the bowls back outwards and secure the pin to prevent spills and keep the crate tidy.

## No Mess, Meal Bliss



**Rotatable Bowl**



**Custom Height**

*Image: Detailed view of the innovative rotatable and height-adjustable feeding bowls, designed for ease of use*

and pet comfort.

## Personalizing the Name Tag

Use the provided chalk to write your dog's name or a special message on the bone-shaped name tag. The paw print magnets can be used to attach photos or other small decorations.



*Image: Instructions for customizing the dog crate's name tag, including writing with chalk and using magnets for photos.*

## MAINTENANCE

### Cleaning the Crate

- Wipe down the wooden surfaces and metal bars with a damp cloth and mild detergent as needed. Avoid abrasive cleaners.
- The stainless steel bowls are dishwasher safe for easy cleaning.
- Ensure the crate is completely dry before allowing your pet back inside.

### Storage

When not in use or for transport, the crate can be folded flat for compact storage. Follow the setup instructions in reverse to fold the unit.

## SPECIFICATIONS

Feature	Detail
Model Name	PS-DC108-41-OC
Brand	EasyCom
Color	White & Beech
External Dimensions (L x W x H)	41.34" x 25.59" x 27.56"
Item Weight	50.26 Pounds
Material	Wood (Fsc-Certified) and Metal (0.47-inch diameter steel tubes)
Weight Capacity	Supports dogs up to 100 lbs
Recommended Dog Weight	35-60 pounds
Special Feature	Foldable, No Assembly Required, Adjustable Bowls, Name Tag, Multi-functional (End Table)

Recommended for dogs 35-60 lb



**Tip:** Measure your dog & space for the best fit






Image: Detailed dimensions of the crate and guidance on selecting the correct size for your dog.



**Sturdy Steel Frame**



**Reinforced Bottom**



**Safe Lock**



**Anti-scratch & Quiet Feet**

*Image: Close-up views highlighting the sturdy construction, reinforced base, secure locking mechanism, and protective feet of the crate.*

## WARRANTY AND SUPPORT

### Warranty

This product comes with a **1-year warranty** from the date of purchase.

### Customer Support

For any questions, concerns, or assistance with your Easycom dog crate, please contact our customer support team. We aim to respond within 24 hours on weekdays and 48 hours on weekends to ensure a smooth experience.

For faster processing of returns or damaged parts, please contact EasyCom Support Team directly.

