



Manuals.plus /

› Globber /

› GLOBBER Flow Element Junior Kick Scooter Instruction Manual WLGB728102

Globber Flow Element

GLOBBER Flow Element Junior Kick Scooter Instruction Manual

Model: Flow Element (WLGB728102)

1. INTRODUCTION

Thank you for choosing the GLOBBER Flow Element Junior Kick Scooter. This manual provides essential information for the safe assembly, operation, and maintenance of your scooter. Designed for children aged 3 years and up, with a maximum weight capacity of 50 kg, this scooter features a compact, foldable design and a hand brake for enhanced control. Please read this manual thoroughly before first use and retain it for future reference.

2. SAFETY INFORMATION

Your safety and the safety of others are paramount. Adhere to the following guidelines to prevent accidents and injuries:

- **Read the Manual:** Always read the entire instruction manual before using the product.
- **Intended Use:** Use this product only for its intended purpose as a kick scooter.
- **Traffic Laws:** Always comply with local traffic laws and regulations, including road traffic laws.
- **Single Rider:** This scooter is designed for one rider only. Do not allow more than one person to ride it at a time.
- **Avoid Crowds and Traffic:** Do not use the scooter in crowded areas or places with heavy vehicle traffic.
- **Avoid Hazardous Terrain:** Do not use the scooter on slopes, stairs, uneven surfaces, or other dangerous locations.
- **Wear Protective Gear:** Always wear a helmet, gloves, knee pads, and elbow pads. Always wear sneakers. For additional protection against injuries from falls, wearing long sleeves and long pants is strongly recommended.
- **Regular Inspection:** Periodically check the product for looseness, damage, or deformation. Discontinue use if any issues are found.

3. SETUP AND ASSEMBLY

The GLOBBER Flow Element Junior Kick Scooter comes partially assembled. Follow these steps to prepare your scooter for use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Unfold the Scooter:** Locate the folding mechanism near the base of the handlebar stem. Release the latch and unfold the scooter until the handlebar stem locks securely into the upright position. Ensure all locking mechanisms are fully engaged.
3. **Adjust Handlebar Height:** Loosen the quick-release clamp on the handlebar stem. Adjust the handlebar to a comfortable height for the rider, ensuring it is not above the rider's chest. Tighten the quick-release clamp firmly.
4. **Check Connections:** Verify that all nuts, bolts, and connections are tight and secure before riding.





Figure 3.1: The GLOBBER Flow Element Junior Kick Scooter in its fully assembled, upright position.

4. OPERATING INSTRUCTIONS

Once the scooter is properly set up and all safety precautions are observed, you can begin riding.

4.1 Riding the Scooter

- Place one foot firmly on the deck of the scooter.
- Use the other foot to push off the ground, propelling the scooter forward.
- Maintain balance by holding the handlebars with both hands.
- To turn, gently lean in the desired direction and steer the handlebars.

4.2 Using the Hand Brake

- The scooter is equipped with a front hand brake for effective stopping.
- To slow down or stop, gently squeeze the brake lever located on the handlebar.
- Apply the brake smoothly to avoid sudden stops, which can lead to loss of balance.





Figure 4.1: Detail of the handlebar with the hand brake lever.

4.3 Folding and Unfolding

The scooter features a compact folding mechanism for easy storage and transport.

- **To Fold:** Locate the folding latch at the base of the handlebar stem. Release the latch and carefully fold the handlebar stem down towards the deck until it clicks into the folded position.
- **To Unfold:** Release the folding latch and lift the handlebar stem until it locks securely into the upright riding

position. Ensure the latch is fully engaged before riding.



Figure 4.2: The scooter's folding mechanism in action.



Figure 4.3: The scooter in its folded, compact configuration.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your scooter.

- **Cleaning:** If the scooter becomes dirty, wipe it with a dry cloth or a cloth dampened with water and wrung out thoroughly. Ensure the scooter is completely dry before storing or using it again.
- **Check Nuts and Axles:** Continuous use may cause nuts and axles to loosen. Periodically inspect these components and tighten them if necessary.
- **Storage:** Store the scooter in a dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your scooter, refer to these common troubleshooting tips:

- **Loose Parts:** If any part feels loose, inspect the corresponding nuts and bolts and tighten them securely.
- **Brake Issues:** If the hand brake feels unresponsive or too tight, check the brake cable for proper tension and ensure it is not frayed or damaged. Adjust as needed or consult a professional.
- **Difficulty Folding/Unfolding:** Ensure the folding mechanism is clean and free of debris. Apply a small amount of lubricant if movement is stiff.
- **Unusual Noises:** If you hear unusual noises, stop using the scooter immediately and inspect all components for damage or loose parts.

7. SPECIFICATIONS

Key specifications for the GLOBBER Flow Element Junior Kick Scooter:

Feature	Specification
Brand	Globber
Model Name	Flow Element
Product Type	Kick Scooter
Color	Black Red
Target Age	3 years and up
Target Height	95 cm and up
Maximum Load Weight	50 kg
Wheel Size	5 inches
Wheel Type	Caster
Brake Style	Front Brake
Product Dimensions (W x D x H)	79.50 cm x 34.80 cm x 79.50 cm
Country of Origin	China



Figure 7.1: Side profile of the scooter, illustrating its design and proportions.

8. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official Globber website. Keep your proof of purchase for any warranty claims.

Globber continuously improves its products based on customer feedback. Product colors and designs are subject to change without prior notice.