

[manuals.plus](#) /› [Oraimo](#) /› [Oraimo NutriFry Max Air Fryer OAF-501A User Manual](#)

Oraimo OAF-501A

Oraimo NutriFry Max Air Fryer OAF-501A User Manual

Model: OAF-501A | Brand: Oraimo

1. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before operating the Oraimo NutriFry Max Air Fryer.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.

2. PRODUCT OVERVIEW

The Oraimo NutriFry Max Air Fryer OAF-501A is designed for efficient and versatile cooking. It features an 8-liter capacity, 2000W power, 3D surrounding heat technology, and a built-in steam function.



Image: Front view of the Oraimo NutriFry Max Air Fryer OAF-501A, showcasing its sleek design and digital control panel.

2.1 What's in the Box



Image: Contents of the product packaging, including the Air Fryer unit, a cooking tray, and the Welcome Guide.

- Oraimo NutriFry Max Air Fryer Unit (x1)
- Cooking Tray (x1)
- Welcome Guide (x1)

3. SETUP AND FIRST USE

Before using your air fryer for the first time, follow these steps:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Clean the cooking tray and the interior of the air fryer with a damp cloth and mild detergent. Wipe dry thoroughly.
3. Place the air fryer on a stable, level, and heat-resistant surface, away from walls or other appliances to allow for proper ventilation.
4. Plug the power cord into a grounded electrical outlet.
5. It is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) during the first use to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal.

4. OPERATING INSTRUCTIONS

4.1 Basic Operation

The Oraimo NutriFry Max features a digital display and intuitive controls for easy operation.

- **Power On/Off:** Plug in the appliance. The display will illuminate. Press the power button to turn the unit on or off.
- **Temperature and Time Adjustment:** Use the control knob or dedicated buttons to set the desired cooking temperature and time.
- **Pre-set Functions:** Select from various pre-set cooking programs for common dishes.

4.2 Cooking Features



Image: The Oraimo NutriFry Max Air Fryer shown with various cooked foods, emphasizing its steam air frying capability and 8L capacity.

- **8L Large Capacity:** The 8-liter cooking chamber is suitable for preparing meals for families, accommodating items like a whole chicken or multiple servings of sides.
- **2000W 3D Surrounding Heat:** This technology ensures rapid and even heat distribution, cooking food thoroughly without the need for manual flipping.
- **Built-in Steam Function:** Incorporates steam during cooking to help maintain food moisture, resulting in tender interiors and crispy exteriors.
- **Large Viewing Window:** Allows monitoring of the cooking process without opening the drawer, preserving heat and cooking efficiency.



Image: Diagram illustrating the 2000W 3D Surrounding Heat technology, showing even heat distribution around food for consistent cooking.



Image: Diagram illustrating the Built-in Steam function, showing steam circulating to ensure tender and juicy results while maintaining a crispy skin.



Image: The air fryer basket filled with a whole chicken, surrounded by other cooked items like pizza, fries, steaks, and tarts, demonstrating its 8L large capacity.



Image: The Oraimo Air Fryer in a kitchen setting, highlighting its large transparent viewing window, allowing users to monitor cooking progress.

4.3 Cooking Steps

For optimal results, especially when utilizing the steam function, follow these general steps:



Image: A three-step visual guide showing how to use the air fryer: Step 1: Remove water tank and fill with water. Step 2: Turn knob to desired setting. Step 3: Select function and start cooking.

- 1. Step 1: Prepare Water Tank (if using steam function).** Remove the water tank from the unit and fill it with clean water. Reinsert the water tank securely.
- 2. Step 2: Place Food and Set Temperature/Time.** Place your food in the cooking tray. Close the drawer. Turn the control knob to select the desired temperature and cooking time.
- 3. Step 3: Select Function and Start.** Choose the appropriate cooking function (e.g., Air Fry, Steam, Roast) and press the start button to begin the cooking process.

5. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and optimal performance of your air fryer.

- Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
- Cleaning the Cooking Tray:** The cooking tray features a fluorine-free ceramic coating, making it heat-resistant, non-toxic, durable, scratch-resistant, and easy to clean. Wash the tray with warm soapy water and a non-abrasive sponge. Rinse thoroughly and dry.
- Cleaning the Interior:** Wipe the interior of the air fryer with a damp cloth. For stubborn residue, use a mild detergent. Avoid abrasive cleaners or metal scouring pads.
- Cleaning the Exterior:** Wipe the exterior with a soft, damp cloth. Do not immerse the main unit in water.
- Water Tank:** Empty and clean the water tank after each use, especially if using the steam function, to prevent mineral buildup.



Image: Details about the fluorine-free ceramic coating, highlighting its heat resistance up to 250°C, non-toxic properties, durability, scratch resistance, and non-stick surface for easy cleaning.

6. TROUBLESHOOTING

If you encounter issues with your Oraimo NutriFry Max Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on	Not plugged in; Power outlet malfunction; Unit not properly assembled.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. Ensure the cooking drawer is fully closed.
Food is not cooked evenly	Overcrowding the basket; Incorrect temperature/time settings.	Do not overcrowd the basket; cook in smaller batches if necessary. Adjust temperature and time according to recipe or food type.
White smoke coming from the appliance	Grease residue from previous use; Fatty ingredients.	Clean the cooking tray and interior thoroughly after each use. For fatty foods, drain excess oil during cooking.
Food is not crispy	Too much moisture; Not enough oil; Incorrect temperature.	Pat food dry before air frying. Lightly brush or spray with oil. Increase temperature or cooking time slightly.
Steam function not working	Water tank empty; Water tank not properly inserted.	Fill the water tank. Ensure the water tank is securely in place.

If the problem persists, please contact customer support.

7. TECHNICAL SPECIFICATIONS

Feature	Specification

Feature	Specification
Model	OAF-501A
Brand	Oraimo
Capacity	8 Liters
Power / Wattage	2000 Watts
Voltage	220 Volts
Material	Ceramic, Plastic
Product Dimensions (D x W x H)	35 x 30 x 32 cm
Item Weight	5.2 Kilograms
Special Features	2000W Power, 8L Large Capacity, Built-in Steam, No-flip Cooking, Steam Function, Large Viewing Window
Recommended Uses	Air Frying, Baking, Grilling, Roasting

8. WARRANTY AND SUPPORT

Oraimo products are manufactured to high-quality standards. For warranty information, product registration, or technical support, please refer to the official Oraimo website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, please visit the [Oraimo Official Website](#) or contact their authorized service centers.