

[Manuals.plus](#) /

> [Roku](#) /

> Roku 50-Inch Select Series 4K QLED TV User Manual

Roku 50R5D5

Roku 50-Inch Select Series 4K QLED TV User Manual

Model: 50R5D5

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Roku 50-Inch Select Series 4K QLED TV. The Roku Select Series 4K QLED TV is designed to enhance your entertainment experience with its 4K QLED display, smart features, and integrated Roku operating system. Please read this manual thoroughly before using your television.



Image: Front view of the Roku 50-Inch Select Series 4K QLED TV on its stands.

2. WHAT'S IN THE BOX

Verify that all items listed below are included in your package:

- Roku Select Series 50" 4K TV
- Stands and screws
- Remote Control
- User Manual (this document)

A perfect fit for any smart home

Sports

Search

Streaming Store

Settings

"Alexa, show me comedies on living room Roku."



Roku, the Roku logo, Roku Smart Home, and the Roku Smart Home logo are the trademarks or registered trademarks of Roku, Inc. Only supports English language. Apple, Apple Home, AirPlay, and Siri are trademarks of Apple Inc., registered in the U.S. and other countries and regions. The Works with Apple Home badge is a trademark of Apple Inc. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates. Alexa enabled device is required to work with Alexa. Google and Google Home are trademarks of Google LLC. Third party features and services may be subject to change or removal without notice.

Image: Diagram illustrating the Roku Select Series TV, Roku TV remote, stand screws, and TV stands included in the box.

3. SETUP

3.1 Attaching the TV Stands

Carefully place the TV screen-down on a soft, clean surface. Align the TV stands with the designated slots on the bottom of the TV. Secure the stands using the provided screws. Ensure the stands are firmly attached before placing the TV upright.

3.2 Wall Mounting (Optional)

This TV supports VESA mount standard 200 x 100 mm. For wall mounting, use a compatible wall mount bracket (sold separately) and follow the instructions provided with the wall mount. Professional installation is recommended for wall mounting.

3.3 Connecting Devices

Your Roku TV features multiple connectivity options:

- **HDMI Ports (3 Total):** Connect gaming consoles, Blu-ray players, cable boxes, and other HDMI-enabled devices.

- **USB Port (1 Total):** Connect USB storage devices for media playback.
- **Ethernet Port:** For a wired internet connection.
- **Optical (S/PDIF) Output:** For digital audio output to soundbars or home theater systems.
- **Antenna/Cable Input:** Connect an antenna for over-the-air broadcasts or a cable TV connection.



Image: Rear view of the Roku TV displaying HDMI, USB, Ethernet, and other input/output ports.

3.4 Powering On and Initial Setup


After connecting all desired devices and power, plug the TV into an electrical outlet. Press the power button on the remote control. Follow the on-screen instructions to complete the initial setup, including connecting to your Wi-Fi network and activating your Roku account.

4. OPERATING YOUR TV

4.1 Remote Control Functions

The enhanced voice remote allows for easy navigation and control. It requires 2 AAA batteries.

- **Power Button:** Turns the TV on or off.
- **Voice Button:** Activates voice search and control.
- **Directional Pad (D-Pad):** Navigates menus and selects items.
- **OK Button:** Confirms selections.
- **Home Button:** Returns to the Roku home screen.
- **Volume Up/Down:** Adjusts TV volume.
- **Mute Button:** Mutes or unmutes TV audio.
- **Instant Replay:** Jumps back a few seconds in video playback.
- **Live TV Button:** Accesses live television channels.
- **Quick Launch Buttons:** Dedicated buttons for popular streaming apps. These can be customized.
- **Lost Remote Finder:** Use the Roku mobile app to locate a misplaced remote.



What's in the box

- Roku Select Series 50" 4K QLED TV
- Stands and screws
- Roku Enhanced Voice Remote with batteries
- Quick Start Guide
- TV power cord

Image: Detailed diagram of the Roku TV remote control, highlighting the function of each button including power, volume, voice control, and app shortcuts.

4.2 Navigating the Home Screen

The Roku home screen provides access to all your streaming channels, inputs, and settings. You can customize the order of your channels for quick access to your favorites.




Image: The Roku TV home screen, showing a grid of streaming application icons and navigation options on the left.

4.3 Streaming Content

Access thousands of streaming channels, including Netflix, Disney+, Hulu, Prime Video, and more. Use the search function to find specific movies, shows, or actors across multiple services.

4.4 Voice Control

Press the voice button on your remote and speak commands to search for content, launch apps, or control playback. The TV is compatible with Roku Voice, Siri, Alexa, and Google Assistant.

4.5 Bluetooth Headphone Mode

Connect your Bluetooth headphones to the TV for private listening. This feature allows you to enjoy audio without disturbing others.

5. FEATURES

- **4K QLED Display:** Experience vibrant colors and sharp details with 4K resolution and Quantum Dot LED technology. HDR10, HDR10+, and HLG formats are supported for enhanced contrast and color.
- **Roku Smart Picture:** This technology automatically optimizes incoming TV signals and selects the appropriate picture mode for optimal viewing.
- **Seamless Streaming:** Fast Wi-Fi connectivity ensures quick app launches and smooth streaming.
- **Free Live TV:** Access over 500 free TV channels, including live news, sports, and movies, directly from the Roku home screen.
- **Automatic Software Updates:** Your TV receives automatic updates to ensure you have the latest features and security enhancements.
- **Smart Home Integration:** Compatible with Apple AirPlay for sharing content from Apple devices. Voice control works with Roku Voice, Siri, Alexa, or Google Assistant.
- **Dolby Audio:** Designed for clear speech and louder sound output.
- **Game Mode:** Reduces input lag for a more responsive gaming experience.
- **Art Mode:** Transform your TV into a digital art display.

6. MAINTENANCE

6.1 Cleaning the Screen

Gently wipe the screen with a soft, dry microfiber cloth. For stubborn smudges, lightly dampen the cloth with water or a screen-cleaning solution specifically designed for electronics. Avoid using harsh chemicals, abrasive materials, or direct spraying onto the screen.

6.2 Cleaning the TV Body

Wipe the TV frame and back panel with a soft, dry cloth. Do not use liquid cleaners directly on the TV.

6.3 Ventilation

Ensure adequate ventilation around the TV to prevent overheating. Do not block the ventilation openings on the back of the TV.

7. TROUBLESHOOTING

If you encounter issues with your Roku TV, refer to the following common solutions:

Problem	Solution
No power	Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Try a different outlet.
No picture, but sound is present	Check the input source. Ensure all cables (HDMI, etc.) are securely connected. Try a different HDMI port.
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Verify audio settings and external audio device connections.
Remote control not working	Replace the batteries in the remote. Ensure there are no obstructions between the remote and the TV. Re-pair the remote if necessary (refer to the Roku support site for instructions).

Problem	Solution
Cannot connect to Wi-Fi	Check your network settings. Ensure your Wi-Fi router is on and within range. Restart your router and TV.
Picture quality issues (e.g., blurry, distorted)	Check the source resolution. Adjust picture settings (brightness, contrast, sharpness) in the TV menu. Ensure cables are properly connected.

8. SPECIFICATIONS

Feature	Detail
Model Name	Roku 50" Select Series 4K
Model Number	50R5D5
Screen Size	50 Inches
Display Technology	4K UHD, QLED, LED
Resolution	4K (3840 x 2160)
Refresh Rate	60 Hz
HDR Format Supported	HDR10, HDR10+, HLG
Connectivity Technology	Bluetooth, Ethernet, USB, Wi-Fi
Total HDMI Ports	3
Total USB Ports	1 (USB 2.0)
Operating System	Roku OS
Audio Output Power	20 Watts (Dolby Audio)
Product Dimensions (DxWxH)	12.7"D x 43.7"W x 27.9"H
Item Weight	16.8 Pounds (with stand), 16.3 Pounds (without stand)
VESA Mount Standard	200 x 100 mm
Power Consumption	120 Watts
Languages Supported	English, Spanish, French, Portuguese

9. WARRANTY AND SUPPORT

9.1 Limited Warranty

Roku warrants the hardware against defects in materials and workmanship under normal use for a period of one (1) year from the date of purchase ("Warranty Period"). If Roku determines that the device's hardware is defective during the Warranty Period, Roku's sole obligation, and your exclusive remedy, will be to either repair or replace the unit with either a new or rebuilt device, at its option. This warranty is valid if used in accordance with the provided documentation.

9.2 Returns and Replacements

You may return a device for any reason, subject to the terms of the applicable return policy:

- Within thirty (30) days from the date of purchase from Roku.
- Within the applicable return period if purchased from an authorized reseller or distributor.

Important information about warranty returns and replacements, along with additional details regarding product returns, can be found on the official Roku support site.

9.3 Further Assistance

For additional support, troubleshooting guides, or to access the full PDF user manual, please visit the official Roku support website. You can also find contact information for customer service there.

A digital version of this user manual is available for download:[Download User Manual \(PDF\)](#)