

[Manuals.plus](#) /

› [LCAOPC](#) /

› LCAOPC 71" Tall Metal Wardrobe Closet with Adjustable Shelves and Hanging Rod, Peacock Blue (Model LCA-MZ11BG02)

LCAOPC LCA-MZ11BG02

LCAOPC 71" Tall Metal Wardrobe Closet Instruction Manual

Model: LCA-MZ11BG02

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your LCAOPC 71" Tall Metal Wardrobe Closet. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.



Image: The LCAOPC 71" Tall Metal Wardrobe Closet in Peacock Blue, with its doors open, revealing adjustable shelves and a hanging rod. Various clothing items and storage boxes are visible inside.

SAFETY INFORMATION


To prevent injury or damage to the product, observe the following safety precautions:

- **Assembly:** Always assemble the wardrobe on a soft, clean surface to prevent scratches. Ensure all parts are securely fastened before use.
- **Stability:** This wardrobe is designed to be freestanding. For enhanced safety, especially in households with children, utilize the included anti-tipping device to secure the wardrobe to a wall.
- **Weight Capacity:** Do not exceed the maximum weight capacity for shelves (120 lbs per shelf) or the hanging rod. Distribute weight evenly.
- **Movement:** Do not attempt to move the wardrobe when it is fully loaded. Empty the wardrobe before relocating it.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the wardrobe.

ANTI-TIPPER: WALL ANCHOR



✓ OUR



✗ OTHER'S




Image: A diagram illustrating the importance of the anti-tipping device. It shows how to properly secure the wardrobe to a wall to prevent accidental tipping, especially when children are present.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

- Wardrobe Panels (sides, top, bottom, back, doors)
- Adjustable Shelves (2 included)
- Hanging Rod
- Adjustable Non-slip Feet
- Golden Handles
- Magnetic Door Closures
- Anti-tipping Device

- Assembly Hardware (screws, bolts, etc.)
- Assembly Instructions

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended that two people assemble the wardrobe. A tool is included for assembly.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Refer to the included parts list to identify each piece.
2. **Assemble Frame:** Connect the side panels to the base and top panels using the provided hardware. Ensure all connections are secure.
3. **Install Back Panel:** Attach the back panel to the assembled frame.
4. **Attach Doors:** Secure the two doors to the main frame using the hinges. Ensure they open and close smoothly.
5. **Install Handles and Magnetic Closures:** Attach the golden handles to the doors and install the magnetic closures to ensure the doors stay shut.
6. **Insert Shelves and Hanging Rod:** Place the adjustable shelves at your desired height. The hanging rod can be positioned at two different heights (upper or middle) to suit your needs.
7. **Attach Adjustable Feet:** Screw the adjustable non-slip feet into the base of the wardrobe. Adjust them to ensure the wardrobe is level on uneven floors.
8. **Secure Anti-Tipping Device:** For safety, attach the anti-tipping device to the top rear of the wardrobe and secure it to a wall stud using appropriate hardware.



Image: A visual representation of the wardrobe's dimensions (17.72"D x 31.5"W x 71"H) and the weight capacity of each shelf, indicating 120 lbs per shelf.

OPERATING INSTRUCTIONS

The LCAOPC Metal Wardrobe Closet offers versatile storage solutions for various items.

- **Adjusting Shelves:** The two included shelves are adjustable. To change their height, remove any items, lift the shelf, and reposition it into the desired slots along the side panels. Ensure the shelf is level and securely seated before placing items on it.
- **Hanging Rod:** The hanging rod can be adjusted to two positions (upper or middle) to accommodate different clothing lengths. To adjust, remove the rod, reposition its supports, and reinsert the rod.
- **Door Operation:** The doors feature golden handles for easy opening and magnetic closures to keep them securely shut. Gently pull the handles to open and push the doors until the magnets engage to close.
- **Storage Capacity:** Utilize the hanging rod for clothes, and the shelves for folded garments, bags, books, or other items. Distribute weight evenly across shelves and the hanging rod to maintain stability.



Image: The wardrobe interior demonstrating customizable storage space, with clothes hanging on the rod and various items neatly stacked on the adjustable shelves.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your wardrobe closet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the powder-coated finish.
- **Dusting:** Dust regularly with a dry, soft cloth.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary.
- **Scratch and Rust Resistance:** The metal construction is designed to be scratch and rust-resistant. However, avoid sharp objects that could scratch the finish and promptly clean any spills to prevent potential rust.

TROUBLESHOOTING

If you encounter issues with your wardrobe, refer to the following common solutions:

Problem	Possible Cause	Solution
Doors do not close properly	Wardrobe is not level; items inside are obstructing closure; magnetic closures are misaligned.	Adjust the non-slip feet to level the wardrobe. Rearrange items inside. Check and adjust magnetic closures.
Wardrobe feels unstable or wobbly	Not all screws are tightened; wardrobe is not level; anti-tipping device not installed or secured.	Ensure all assembly hardware is fully tightened. Adjust feet to level the unit. Install or properly secure the anti-tipping device to a wall stud.
Shelves sag or cannot hold weight	Exceeding weight capacity; shelf not properly seated.	Reduce the weight on the shelf. Redistribute items. Ensure the shelf is correctly inserted into all support slots.

SPECIFICATIONS

- **Brand:** LCAOPC
- **Model Name:** LCA-MZ11BG02

- **Color:** Peacock Blue
- **Material:** Metal
- **Product Dimensions:** 17.72"D x 31.5"W x 71"H
- **Item Weight:** 87 Pounds
- **Number of Shelves:** 2 (Adjustable)
- **Special Features:** Adjustable Feet, Adjustable Shelf, Anti-Tipping Device, Scratch Resistant, Stain Resistant
- **Mounting Type:** Freestanding
- **Door Style:** Barn Doors
- **Finish Type:** Powder Coated
- **Assembly Required:** Yes

WARRANTY AND SUPPORT

This product is offered with a 30-day easy return policy. For any questions, missing parts, or assistance with assembly or troubleshooting, please contact LCAOPC Direct customer support. Refer to your purchase documentation for specific contact details.

© 2026 LCAOPC. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question