

[Manuals.plus](#) /

› [Jocoevol](#) /

› Jocoevol Shoe Storage Cabinet with 3 Flip Drawers Instruction Manual

Jocoevol B0FY2JW4RZ

Jocoevol Shoe Storage Cabinet with 3 Flip Drawers

Instruction Manual

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Jocoevol Shoe Storage Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. This cabinet is designed to organize footwear efficiently in various spaces such as entryways, hallways, living rooms, or foyers.

Key features include a distinctive wavy grooved panel design, elegant gold metal handles, three space-saving flip drawers, and adjustable internal shelves to accommodate different shoe types. The cabinet also features a fenced top with side hooks for additional storage and display.

2. SAFETY INFORMATION

- **Anti-Tipping Device:** For your safety, it is crucial to install the included anti-tipping device. Securely attach the cabinet to a wall to prevent accidental tipping, especially in households with children or pets.
- **Weight Limits:** The top surface of the cabinet can support up to 11.3 kg (25 lbs). Each inner shelf within the flip drawers can support up to 5.4 kg (12 lbs). Do not exceed these weight limits to ensure stability and prevent damage.
- **Stable Placement:** Place the cabinet on a flat, level surface. Uneven surfaces can compromise stability.
- **Material Safety:** Constructed from high-quality MDF engineered wood, this cabinet is designed for durability. Avoid exposing it to excessive moisture or direct heat sources.

3. PACKAGE CONTENTS

Before beginning assembly, please ensure all parts and hardware are present and undamaged. Refer to the separate assembly instruction sheet for a detailed list of components and their corresponding labels.

- Cabinet panels (numbered)
- Flip drawer mechanisms
- Adjustable shelves
- Gold metal handles

- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tipping device
- Assembly instruction manual

4. SETUP AND ASSEMBLY

Assembly of this shoe cabinet typically requires 1-2 people and can be completed in approximately one hour. Follow the clear, step-by-step instructions provided in the separate assembly guide.

1. **Unpack and Inspect:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Verify that all parts listed in the package contents are present and undamaged.
2. **Identify Parts:** Match each part to its corresponding label or number as indicated in the assembly guide.
3. **Follow Instructions:** Assemble the cabinet frame first, ensuring all connections are secure. Then, install the flip drawer mechanisms and adjustable shelves according to the guide.
4. **Attach Handles:** Secure the gold metal handles to the flip drawers.
5. **Install Anti-Tipping Device:** This is a critical safety step. Using the provided hardware, attach the anti-tipping device to the top rear of the cabinet and then securely fasten it to a sturdy wall stud.




Image: Cabinet dimensions (130cm H x 80cm W x 24cm D) and a detailed view of the L-shaped screw for wall mounting the anti-tipping device.



Image: Detail of the adjustable panel within a flip drawer, illustrating how to change its position to accommodate different shoe heights.

5. OPERATING INSTRUCTIONS

This shoe cabinet is designed for convenient and discreet shoe storage.

- **Using the Flip Drawers:** Gently pull the gold metal handle on each drawer to open it. The drawer will flip down, revealing two tiers of storage. Push the drawer back up until it clicks into place to close it.
- **Adjusting Shelves:** Each flip drawer contains two tiers. The internal panel can be adjusted or removed to accommodate various shoe types, including flats, mid-calf boots, or heels, up to US size 10. To adjust, carefully unclip the panel from its current position and re-insert it into the desired slots. To remove, simply unclip and lift out.
- **Capacity:** The cabinet can hold approximately 24-36 pairs of shoes, depending on their size and style.
- **Top Surface and Hooks:** The fenced top surface is ideal for placing small decorative items, potted plants, or frequently used essentials like keys. The side hooks provide a convenient spot for hanging bags or umbrellas.



Image: The shoe cabinet with its three flip drawers open, showcasing the internal storage and how shoes are organized.



Image: Illustration of the adjustable shelf, showing how it can be removed or repositioned to accommodate various shoe types like high heels, slippers, casual shoes, leather shoes, sneakers, and sports shoes.

6. MAINTENANCE

Proper care will ensure the longevity and appearance of your Jocoevol Shoe Storage Cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent moisture damage, especially on the engineered wood surfaces. The top surface is waterproof and scratch-resistant, but prolonged exposure to liquids should be avoided.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain structural integrity.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the wood finish.



Image: Detail of the cabinet's thickened base, emphasizing its robust construction for enhanced stability and durability.

7. TROUBLESHOOTING

If you encounter any issues with your shoe cabinet, refer to the following common solutions:

- **Drawers Not Opening/Closing Smoothly:**
 - Check for any obstructions inside the drawer or along the mechanism.
 - Ensure all assembly screws for the drawer slides and mechanisms are securely tightened.
- **Cabinet Feels Unstable:**
 - Verify that the cabinet is placed on a completely level surface.
 - Confirm that the anti-tipping device is correctly installed and securely fastened to a wall stud.
- **Missing or Damaged Parts:**
 - If you discover any missing or damaged parts during unpacking or assembly, please contact customer support immediately.

8. SPECIFICATIONS

Brand	Jocoevol
Model	B0FY2JW4RZ
Material	Engineered Wood (MDF)
Color	Natural Wood
Product Dimensions (D x W x H)	24.1 cm x 80 cm x 130.3 cm (9.5"D x 31.5"L x 51.3"H)
Item Weight	32.21 kg
Number of Flip Drawers	3
Adjustable Shelves	Yes, within each flip drawer
Max Shoe Size	US Size 10
Top Surface Load Capacity	Up to 11.3 kg (25 lbs)

Inner Shelf Load Capacity	Up to 5.4 kg (12 lbs) per shelf
Special Features	Hidden Shoe Storage, Fluted Panel, Adjustable Shelves, Anti-Tipping Device, Fenced Top, Side Hooks
Assembly Required	Yes

9. WARRANTY AND SUPPORT

Jocoevol is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, we offer dedicated customer support for any inquiries or issues you may encounter.

If you have any questions about your shoe storage cabinet, require assistance with assembly, or need to report a problem, please do not hesitate to reach out to us via email. We aim to respond to all inquiries within 24 hours. Please refer to your purchase documentation or the retailer's website for specific contact information.

© 2026 Jocoevol. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FY2JW4RZ>

More documents and user manuals: <https://manuals.plus/>