

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw 18mm Quick Release Silicone Smart Watch Band User Manual for DR03, DR05, DR06

Lamshaw 18mm Quick Release Silicone Smart Watch Band

Lamshaw 18mm Quick Release Silicone Smart Watch Band User Manual

Model Compatibility: DR03, DR05, DR06 Smart Watches

1. INTRODUCTION

This manual provides instructions for the installation, adjustment, and care of your Lamshaw 18mm Quick Release Silicone Smart Watch Band. This band is designed for comfort and durability, featuring a breathable design and a secure magnetic clasp.

Compatibility: This band is compatible with DR03, DR05, and DR06 Smart Watches, as well as other watches requiring an 18mm quick-release strap.

2. PRODUCT FEATURES

- **Quick Release Design:** Equipped with quick-release spring bars for easy installation and removal without tools.
- **Breathable Silicone:** Made from high-quality silicone with perforations to enhance breathability and ventilation, reducing sweat accumulation.
- **Magnetic Clasp:** Features a secure and adjustable magnetic folding buckle for a comfortable and stable fit.
- **Adjustable Length:** The band can be easily adjusted to fit various wrist sizes.
- **Durable & Waterproof:** Designed to be sweatproof and waterproof, suitable for sports and daily wear.



Image: Lamshaw 18mm Quick Release Silicone Smart Watch Band on a compatible smart watch.

3. INSTALLATION GUIDE

Follow these steps to attach the band to your smart watch:

1. Locate the quick-release spring bar on one end of the watch band.
2. Insert one end of the spring bar into the lug hole on your watch casing.
3. Pull the quick-release lever to retract the other end of the spring bar.
4. Align the retracted end with the opposite lug hole and release the lever. The spring bar should snap into place.
5. Gently tug on the band to ensure it is securely attached.
6. Repeat the process for the other half of the watch band.

LOCKED IN ONE STEP

After Adjustment Length Fixed



Image: Band securely attached and locked on a wrist.


4. ADJUSTING THE BAND LENGTH

The magnetic clasp allows for easy adjustment to achieve a comfortable fit. The band is suitable for wrist sizes between 5.5" and 8.7".


1. **Lift the End of the Strap:** Gently lift the end of the silicone strap that passes through the magnetic buckle.
2. **Release the Buckle:** The magnetic buckle will release, allowing the strap to move freely.
3. **Adjust the Length:** Slide the strap through the buckle to your desired length. Ensure the watch sits comfortably on your wrist.
4. **Press Down the Buckle:** Once the desired length is achieved, press the magnetic buckle down firmly to secure the strap.

How to Adjust the Length?


❶ Lift the End of the Strap



❷ Release the Buckle



❸ Adjust the Length



❹ Press Down the Buckle




Image: Step-by-step guide on how to adjust the band length.



Magnetic Sport Band

Wrist Size: 5.5"-8.7"



Image: Wrist size compatibility diagram.

5. OPERATING AND WEARING THE BAND

Once installed and adjusted, the band is ready for use. The perforated design and silicone material are ideal for active lifestyles, providing comfort and breathability during exercise or daily activities.

Breathable Design

Strong magnetism can firmly fix the watch band



Image: Detail of the breathable design and magnetic clasp.



SWEATPROOF & WATERPROOF



Image: Sweatproof and waterproof feature.

Your browser does not support the video tag.

Video: Demonstration of various Lamshaw silicone magnetic buckle sport replacement straps, showing their colors and how they are worn.

6. CARE AND MAINTENANCE

To ensure the longevity and hygiene of your watch band, follow these cleaning instructions:

- **Cleaning:** Hand wash the band with mild soap and water. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow the band to air dry completely before reattaching it to your watch or wearing it.
- **Storage:** Store the band in a clean, dry place away from direct sunlight when not in use.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Brand	Lamshaw
Material	Silicone
Clasp Type	Magnetic Clasp
Band Width	18mm
Wrist Size Compatibility	5.5" - 8.7"
Compatibility	DR03, DR05, DR06 Smart Watches and other 18mm quick-release watches

8. TROUBLESHOOTING

Most issues with a watch band are related to installation or adjustment. If you encounter problems:

- **Band not attaching securely:** Ensure the quick-release spring bars are fully engaged in the watch lugs. Wiggle the band gently to confirm it's locked.
- **Band feels too loose or too tight:** Re-adjust the magnetic clasp following the instructions in Section 4.
- **Skin irritation:** Ensure the band is clean and dry. If irritation persists, discontinue use and consult a healthcare professional.

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Lamshaw watch band, please refer to the seller's contact information or the platform where the product was purchased. Specific warranty details may vary by retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FY2PV2FQ>

More documents and user manuals: <https://manuals.plus/>