

Cryfokt Cryfokt5gqhednbko

Cryfokt Barn Door Hardware Kit Instruction Manual

Model: Cryfokt5gqhednbko

[Introduction](#) [Safety Information](#) [Package Contents](#) [Specifications](#) [Setup & Installation](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your Cryfokt Barn Door Hardware Kit. This mini sliding door roller kit is designed for smooth, quiet operation in interior spaces, offering high load capacity and robust construction for reliable performance. Please read these instructions carefully before installation and retain them for future reference.

2. SAFETY INFORMATION

WARNING: Failure to follow these instructions may result in property damage or personal injury.

- Always wear appropriate safety gear, including eye protection, during installation.
- Ensure the mounting surface (wall, door frame) is structurally sound and capable of supporting the weight of the door and hardware.
- Use appropriate tools for installation.
- Keep children and pets away from the work area during installation.
- Do not exceed the maximum load capacity of the hardware.
- Regularly inspect the hardware for signs of wear or damage. Replace worn or damaged parts immediately.

3. PACKAGE CONTENTS

Verify that all components listed below are present in your package before beginning installation. If any parts are missing or damaged, please contact Cryfokt customer support.

- 2 x Hanging Rollers
- 2 x Stoppers
- 2 x Anti-Jump Blocks

- 4 x Bolts
- 10 x Screws (various sizes)



Image 3.1: All components included in the Cryfokt Barn Door Hardware Kit, showing two hanging rollers, two stoppers, two anti-jump blocks, bolts, and screws.



Image 3.2: A closer view of the hardware kit components, highlighting the rollers, stoppers, anti-jump blocks, and various fasteners.

4. SPECIFICATIONS

Feature	Detail
Model Number	Cryfokt5gqhednbko
Material	Carbon Steel, ABS
Product Dimensions (L x W x H)	14 x 9.98 x 5.99 cm (5.5 x 3.9 x 2.4 inches)
Item Weight	431 grams (15.2 oz)

Feature	Detail
Color	#511 (Black)
Load Capacity	Designed for heavy doors (specific weight not provided, refer to door manufacturer's guidelines for compatibility)
Origin	China



Image 4.1: Detailed technical dimensions of the barn door roller, showing measurements in millimeters and inches for installation planning.

5. SETUP & INSTALLATION

This kit is designed for easy DIY installation. While specific rail installation instructions are not provided with this roller kit, the general steps for installing barn door hardware are outlined below. Always refer to the instructions provided with your barn door rail for precise measurements and mounting procedures.

Tools Required (Not Included):

- Drill
- Measuring Tape
- Level
- Pencil
- Wrench/Socket Set
- Screwdriver

Installation Steps:

1. **Prepare the Door:** Attach the hanging rollers to the top edge of your barn door. Ensure they are evenly spaced and securely fastened using the provided bolts. Refer to Image 5.1 for roller attachment.



Image 5.1: A close-up view of the two hanging rollers, showing the attachment points for the door.

2. **Install the Rail:** (*Note: Rail sold separately or as part of a complete kit*) Mount the barn door rail to the wall above the door opening. Use a level to ensure the rail is perfectly horizontal. Mark and drill pilot holes according to your rail's instructions. Secure the rail firmly to wall studs or with appropriate anchors.
3. **Attach Stoppers:** Install the stoppers at both ends of the rail to prevent the door from sliding off. Adjust their position to control the door's travel distance.
4. **Install Anti-Jump Blocks:** Attach the anti-jump blocks to the top edge of the door, above the rollers. These prevent the door from lifting off the rail during operation.
5. **Hang the Door:** Carefully lift the door and place the rollers onto the rail.
6. **Test Operation:** Gently slide the door back and forth to ensure smooth movement and proper alignment. Adjust stoppers and anti-jump blocks as needed.

6. OPERATION

Once installed, your Cryfokt Barn Door Hardware Kit provides smooth and quiet operation for your sliding door. To open or close the door, simply apply gentle pressure to slide it along the rail. The high-quality rollers ensure minimal friction and noise, contributing to a serene indoor environment.

7. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your barn door hardware.

- **Cleaning:** Wipe the rollers and rail periodically with a soft, damp cloth to remove dust and debris. Avoid abrasive cleaners.
- **Lubrication:** If the door's movement becomes less smooth over time, apply a small amount of silicone-based lubricant to the roller bearings and the top edge of the rail. Do not use oil-based lubricants as they can attract dust.
- **Inspection:** Annually inspect all bolts, screws, and connections to ensure they are tight. Check for any signs of wear, rust, or damage on the rollers and other components. Tighten any loose fasteners.
- **Rust Prevention:** The carbon steel components are designed to be resistant to rust. However, in humid environments, ensure good ventilation and keep the hardware dry to prevent corrosion.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Door is difficult to slide or sticks.	Rail is not level; debris on rail; rollers need lubrication; loose fasteners.	Check rail with a level and adjust if necessary. Clean the rail and rollers. Apply silicone lubricant to rollers. Tighten all fasteners.
Excessive noise during operation.	Rollers need lubrication; loose components; debris in rollers.	Lubricate rollers. Check and tighten all bolts and screws. Clean rollers thoroughly.
Door lifts off the rail.	Anti-jump blocks are not installed or improperly adjusted.	Ensure anti-jump blocks are securely installed and positioned correctly to prevent the door from lifting.
Door does not stop at desired position.	Stoppers are loose or improperly positioned.	Adjust the position of the stoppers on the rail and tighten them securely.

9. WARRANTY & SUPPORT

Cryfokt products are manufactured to high-quality standards. For information regarding warranty coverage, returns, or technical support, please refer to the documentation provided with your purchase or contact Cryfokt customer service directly through the retailer where the product was purchased.

Manufacturer: Cryfokt

Model Number: Cryfokt5gqhednbko

© 2026 Cryfokt. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question