

[Manuals.plus](#) /

› [Premium-Plus](#) /

› Premium Plus Stove Protectors User Manual for KitchenAid Gas Stove Model KSGS430SPS

Premium-Plus KSGS430SPS

Premium Plus Stove Protectors User Manual for KitchenAid Gas Stove Model KSGS430SPS

Comprehensive instructions for installation, use, and maintenance.

INTRODUCTION

Thank you for choosing Premium Plus Stove Protectors. These custom-fit liners are designed to protect your KitchenAid Gas Stove Model KSGS430SPS, making cleanup easier and maintaining the pristine condition of your stovetop. Made in the USA, our liners are heat resistant up to 500°F (260°C), PFOA & BPA free, and are reusable.

IMPORTANT SAFETY INFORMATION

- Ensure stove burners are completely cool before installing or removing stove protectors.
- Do not place stove protectors directly over open flames or heating elements.
- The liners are heat resistant up to 500°F (260°C). Exceeding this temperature may cause damage.
- Keep out of reach of children.
- Always follow your stove manufacturer's safety guidelines.
- These liners are non-flammable and flame-retardant, designed to resist grease and stay flat.



Image: A Premium Plus Stoveline undergoing a heat resistance test with a torch, highlighting its fire-retardant material and ability to withstand high temperatures up to 500°F (260°C).

PACKAGE CONTENTS

Your Premium Plus Stove Protectors package for KitchenAid Gas Stove Model KSGS430SPS includes:

- Three (3) Piece Customized Stovetop Protector Liners
- Lifetime Warranty Card
- Detailed Care Instructions (this manual)

SETUP AND INSTALLATION

Follow these steps to properly install your Premium Plus Stove Protectors:

1. **Prepare the Stovetop:** Ensure your gas stovetop is completely cool and clean. Remove all grates and burner caps

from the stovetop surface.

2. **Position the Liners:** The liners come in three custom-cut pieces. Carefully align the middle section first, followed by the two side sections. Ensure all pieces overlap slightly to provide complete coverage and protection for your stovetop. The custom design ensures a perfect fit around your burners.
3. **Reassemble:** Once the liners are correctly positioned, replace the burner caps and then the grates onto your stovetop.



Image: A KitchenAid gas stove before the installation of stove protectors, showing the original grates and burner caps.

Perfect Fit

STOVE PROTECTORS



Image: The KitchenAid gas stove after the installation of Premium Plus Stove Protectors, with grates and burner caps removed, showcasing the custom fit.

Your browser does not support the video tag.

Video: A demonstration of how to install the Premium Plus Stove Protectors on a gas stovetop, showing the removal of grates, placement of liners, and reassembly.

OPERATING AND USE

Once installed, your Premium Plus Stove Protectors are ready for use. They are designed to catch spills and splatters, keeping your stovetop clean underneath.

- Cook as you normally would. The liners are designed to withstand typical cooking temperatures up to 500°F (260°C).
- In case of spills, the liners will contain the mess, preventing it from reaching the stovetop surface.

PROTECT YOUR STOVE SIMPLIFY YOUR CLEANUP WITH PREMIUM PLUS STOVELINERS



Image: A visual comparison demonstrating the effectiveness of Premium Plus Stove Protectors in maintaining a clean stovetop, showing a "before" image with spills and an "after" image with the clean protectors installed.

MAINTENANCE AND CLEANING

Cleaning your Premium Plus Stove Protectors is simple and convenient:

1. **Removal:** Ensure the stovetop is cool. Remove the grates and burner caps, then carefully lift the stove protector liners.
2. **Cleaning Options:**
 - **Dishwasher Safe:** Place the liners on the top rack of your dishwasher for easy cleaning.
 - **Hand Wash:** For localized spills or general cleaning, simply wipe away spills and grease with a damp sponge and mild soap. Rinse thoroughly.
3. **Reinstallation:** Once clean and dry, follow the "Setup and Installation" steps to place the liners back on your stovetop.

For localized spills, you can remove only the affected liner piece, clean it, and replace it, leaving the other pieces in place.

DISHWASHER SAFE

Premium Plus
Stoveliners can be
removed and simply
placed in your
dishwasher for
easy cleaning
and convenience.



DISHWASHER SAFE



Image: Premium Plus Stove Protectors arranged on the top rack of a dishwasher, illustrating their dishwasher-safe feature for convenient cleaning.



KEEP YOUR KITCHEN CLEAN & PROTECTED

Premium Plus Stoveliners are designed for convenience — easy to hand wash or toss right into the dishwasher. Durable, mess-resistant, and effortless to clean, they help protect your stovetop from everyday spills and spatters so your kitchen stays spotless with less effort.

Image: A person demonstrating hand-washing a Premium Plus Stove Protector in a kitchen sink, emphasizing ease of cleaning.



Image: A collage illustrating various cleaning methods for the stove protectors, including handwashing, dishwasher use, and the simple process of removing them from the stovetop for cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Liners do not fit correctly.	Incorrect model number or improper alignment.	Ensure you have the correct liners for KitchenAid Model KSGS430SPS. Re-align the three pieces carefully, ensuring they overlap as instructed.
Liners appear warped or damaged.	Exposure to temperatures exceeding 500°F (260°C) or direct flame contact.	Ensure liners are not directly exposed to open flames. Replace damaged liners.

Problem	Possible Cause	Solution
Stains are difficult to remove.	Stubborn, baked-on food residue.	Soak liners in warm, soapy water before washing. For dishwasher cleaning, ensure they are placed on the top rack.

SPECIFICATIONS

- **Product Name:** Premium Plus Stove Protectors
- **Model Compatibility:** KitchenAid Gas Stove Model KSGS430SPS
- **Material:** PTFE Fire-Retardant Material
- **Heat Resistance:** Up to 500°F (260°C)
- **Safety Features:** PFOA Free, BPA Free, Non-Toxic, Non-Flammable, Flame-Retardant
- **Cleaning:** Dishwasher Safe (top rack), Hand Washable
- **Color:** Black
- **Shape:** Rectangular (custom-cut three-piece design)
- **Manufacturer:** Premium Plus Inc
- **Part Number:** KAT82A102825-905



Image: A visual comparison illustrating the thickness and durability of Premium Plus Stove Protectors (.40mm) compared to thinner, inferior competing products (.10mm).

WARRANTY AND SUPPORT

Lifetime Warranty: Premium Plus Inc. stands behind the quality of its products. Your Premium Plus Stove Protectors come with a Lifetime Warranty, ensuring your satisfaction. Please refer to the included Lifetime Warranty Card for full details and registration information.

Customer Support: For any questions, concerns, or support needs regarding your stove protectors, please contact Premium Plus Inc. customer service. Contact details can be found on your warranty card or by visiting the [Premium-Plus Store on Amazon](#).

