

THOMSON B210

THOMSON B210 Bluetooth 5.3 Sound Bar User Manual

Model: B210

INTRODUCTION

Thank you for choosing the THOMSON B210 Bluetooth 5.3 Sound Bar. This sound bar is designed to enhance your audio experience for TV, PC, gaming, and projectors, offering versatile connectivity and immersive sound. Please read this manual carefully before use to ensure proper setup and operation.

PACKAGE CONTENTS

Verify that all items are present in the package:

- THOMSON B210 Sound Bar
- Remote Control
- Power Adapter
- Optical Cable (may vary by region)
- AUX Cable (may vary by region)
- Wall Mount Kit (screws, anchors)
- User Manual

SETUP

1. Placement

Place the sound bar on a stable, flat surface in front of your TV or mount it on the wall below your TV. Ensure there are no obstructions blocking the sound output.

2. Connections

The sound bar offers multiple connection options. Choose the method that best suits your device.



Image: THOMSON B210 Sound Bar, showcasing its sleek design and included remote control. The sound bar features a dark finish with visible speaker grilles and control buttons on the top surface.

- **ARC (Audio Return Channel):** Connect an HDMI cable (not included) from the sound bar's ARC port to your TV's HDMI ARC port. This allows you to control the sound bar volume with your TV remote.
- **Optical:** Connect an optical cable from the sound bar's OPTICAL port to your TV's optical output.
- **AUX:** Connect a 3.5mm AUX cable from the sound bar's AUX port to your device's audio output.
- **USB:** Insert a USB drive into the sound bar's USB port to play audio files directly.
- **Bluetooth:** For wireless connection, refer to the 'Bluetooth Pairing' section under Operating Instructions.

3. Power Connection

Connect the power adapter to the DC IN port on the sound bar, then plug the adapter into a wall outlet.

OPERATING INSTRUCTIONS

1. Power On/Off

Press the Power button on the sound bar or the remote control to turn the unit on or off.

2. Input Source Selection

Press the 'Input' or 'Source' button on the remote control or the sound bar to cycle through available input modes: Bluetooth, USB, AUX, Optical, and ARC.

3. Bluetooth Pairing

1. Select Bluetooth mode on the sound bar. The indicator light will flash.
2. Enable Bluetooth on your device (smartphone, tablet, PC).
3. Search for 'THOMSON B210' in your device's Bluetooth list and select it to pair.
4. Once connected, the indicator light will stop flashing, and you will hear a confirmation tone.

4. EQ Modes

The sound bar features three equalizer (EQ) modes to optimize your listening experience:

- **Music Mode:** Enhances musical clarity and balance.
- **Movie Mode:** Provides immersive 3D surround sound for cinematic effects.
- **Game Mode:** Optimizes audio for gaming, highlighting in-game sounds.

Press the corresponding EQ button (Music, Movie, Game) on the remote control to switch between modes.

5. Volume Control

Adjust the volume using the 'Volume +' and 'Volume -' buttons on the remote control or the physical touch controls on the sound bar. In ARC mode, your TV remote may also control the sound bar volume.

6. Mute Function

Press the 'Mute' button on the remote control to instantly silence the sound bar. Press it again to restore audio. This can also silence loud prompt tones.

MAINTENANCE

1. Cleaning

Wipe the sound bar with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface.

2. Storage

If storing the sound bar for an extended period, disconnect it from power and store it in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
No sound from the sound bar.	<ul style="list-style-type: none"> • Ensure the sound bar is powered on. • Check all cable connections (ARC, Optical, AUX). • Verify the correct input source is selected on the sound bar. • Increase the volume on both the sound bar and the connected device. • If using ARC, ensure your TV's audio output is set to external speakers.
Bluetooth device cannot pair.	<ul style="list-style-type: none"> • Ensure the sound bar is in Bluetooth pairing mode. • Make sure the device is within range (typically 10 meters). • Disable and re-enable Bluetooth on your device. • Forget 'THOMSON B210' from your device's Bluetooth list and try pairing again.
Remote control not working.	<ul style="list-style-type: none"> • Check if the batteries are correctly inserted and not depleted. • Ensure there are no obstructions between the remote and the sound bar. • Point the remote directly at the sound bar's sensor.

SPECIFICATIONS

Feature	Detail
Model Name	B210
Speaker Type	Sound Bar with Subwoofer (integrated bass diaphragms)
Connectivity Technology	Bluetooth 5.3, ARC, Optical, AUX, USB
Speaker Maximum Output Power	50 Watts (RMS)
Product Dimensions	36.5"D x 4.7"W x 2.9"H
Item Weight	11 pounds
Mounting Type	Wall Mount, Tabletop
Included Components	Remote

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or contact THOMSON customer support. If you encounter any issues not covered in this manual, please reach out to our customer service team for assistance.

For support, please visit the official THOMSON website or contact your retailer.

