

TAGRY X88

TAGRY X88 Hybrid Active Noise Cancelling Wireless Earbuds Instruction Manual

1. INTRODUCTION

Thank you for choosing the TAGRY X88 Hybrid Active Noise Cancelling Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced noise cancellation, transparency modes, and a secure fit for various activities. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

Active Noise Cancelling Earbuds

— TAGRY X88 —



Image: A single black TAGRY X88 earbud with an earhook, illustrating the Active Noise Cancelling Mode with a graphic showing over 90% noise reduction.

2. WHAT'S IN THE BOX

- X88 Active Noise Cancelling Earbuds (1 pair)
- X88 Earbuds Charging Case (1)
- Eartips (S/M/L sizes)
- User Manual (1)
- TAGRY Charging Cable (USB Type-C) (1)

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. Connect the provided USB Type-C cable to the charging port on the case and a power source. The LED display on the front of the case will show the battery level of the case and the charging status of each earbud.




Image: The TAGRY X88 charging case open, displaying the earbuds inside and an LED screen indicating '80 Hrs Playtime' and '10 Hrs Per Charge'.

3.2 Wearing the Earbuds

Select the appropriate eartip size (S/M/L) for a comfortable and secure fit. The earhook design ensures stability during physical activity. Gently place the earbud into your ear canal and adjust the earhook over your ear until it feels snug and comfortable.

80 Hrs Playtime

80

Hrs with Case

10

Hrs Per Charge



Image: A woman running outdoors, wearing the black TAGRY X88 earbuds with earhooks, demonstrating a secure fit during exercise.

3.3 Pairing with Your Device

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "X88" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear an audio prompt, and the earbuds will be ready for use.



Image: A smartphone displaying its Bluetooth settings, with the TAGRY X88 earbuds shown as an available device for one-step pairing.

4. OPERATING THE EARBUDS

4.1 Button Controls

The TAGRY X88 earbuds feature multi-function buttons for easy control:

- **Single Click:** Play/Pause music, Answer/End calls.
- **Double Click (Left Earbud):** Previous track.
- **Double Click (Right Earbud):** Next track.
- **Triple Click (Left Earbud):** Switch between ANC, Transparency, and Normal modes.
- **Triple Click (Right Earbud):** Activate Voice Assistant.
- **Long Press (Left Earbud):** Volume Down.
- **Long Press (Right Earbud):** Volume Up.



Image: A visual guide to the single button controls on the TAGRY X88 earbuds, detailing actions for single, double, and triple clicks, as well as long presses.

4.2 Active Noise Cancelling (ANC) and Transparency Modes

The earbuds feature Hybrid Active Noise Cancelling to reduce ambient noise and a Transparency Mode to allow you to hear your surroundings.

- **ANC Mode:** Blocks out external noise, ideal for travel or focused work.
- **Transparency Mode:** Amplifies ambient sounds, allowing you to stay aware of your environment without removing the earbuds.
- **Normal Mode:** Standard audio playback without noise cancellation or transparency.

To switch between these modes, triple-click the button on the left earbud.



**Unleash the Power of
Pristine Sound**



Image: A flowchart showing how to cycle through ANC Mode, Transparency Mode, and Normal Mode by triple-clicking the left earbud.

Video: This video demonstrates the Hybrid Active Noise Cancelling feature of the X88 earbuds, showcasing how they effectively reduce ambient sound for an immersive audio experience.

Video: This video illustrates the functionality of the X88 earbuds' ANC and Transparency Modes, highlighting how users can switch between blocking out noise and staying aware of their surroundings.

5. MAINTENANCE

5.1 Waterproofing

The TAGRY X88 earbuds are IPX7 waterproof, making them resistant to sweat and rain. They are suitable for workouts and outdoor activities. However, they are not designed for swimming or prolonged submersion in water.




Image: The TAGRY X88 earbuds are shown with water droplets on them, emphasizing their IPX7 waterproof feature.

5.2 Cleaning and Storage

Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials. Store the earbuds in their charging case when not in use to protect them and ensure they remain charged.

6. TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, then open the lid to activate pairing mode. Check your device's Bluetooth settings and try reconnecting.
- **No sound from one earbud:** Place both earbuds back in the case, close the lid, and then reopen to reset. Re-pair with your device if necessary.
- **Charging issues:** Ensure the charging cable is securely connected to both the case and the power source. Check the LED display for charging indicators.
- **Poor sound quality:** Ensure the eartips provide a good seal in your ear canal. Try different eartip sizes. Clean any debris from the earbud nozzles.

7. SPECIFICATIONS

Feature	Detail
Model Name	X88
Noise Control	Hybrid Active Noise Cancellation
Connectivity Technology	Bluetooth 5.4
Wireless Range	Up to 10 meters (33 feet)
Total Playtime	Up to 80 hours (with charging case)
Single Charge Playtime	Up to 10 hours
Charging Time	Approximately 1 hour (for full charge via Type-C)
Water Resistance Level	IPX7 (Waterproof)
Audio Driver Size	13mm Dynamic Drivers
Control Type	Button Control
Included Components	Earbuds, Charging Case, Eartips (S/M/L), User Manual, USB-C Charging Cable

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided in the packaging or visit the official TAGRY website. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question