

LICAEEVEY LICAEEVEYbcnuvaxdp2

LICAEEVEY Portable 4G/5G WiFi Hotspot User Manual

Model: LICAEEVEYbcnuvaxdp2

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your LICAEEVEY Portable 4G/5G WiFi Hotspot. Please read this manual thoroughly before using the device to ensure optimal performance and safety.

PRODUCT OVERVIEW

The LICAEEVEY Portable 4G/5G WiFi Hotspot is designed to provide high-speed internet access on the go. It supports 4G and 5G networks, offering speeds up to 300Mbps, and can connect up to 10 devices simultaneously. Its compact design and built-in 2100mAh battery make it ideal for travel, business, and shared internet access.

Key Features:

- **4G/5G Connectivity:** Access high-speed internet by simply inserting a compatible SIM card.
- **High-Speed Network:** Supports LTE CAT4 standard, delivering speeds up to 300Mbps.
- **Portable Design:** Compact and lightweight with a built-in 2100mAh battery for over 10 hours of continuous use.
- **Multi-Device Support:** Connect up to 10 devices simultaneously, including smartphones, tablets, and laptops.
- **Plug and Play:** Easy setup with USB-C power supply and SIM card insertion.
- **Indicator Display:** Colorful display shows battery level and connection status.

WIRELESS Mobile WiFi



Type-c interface



4G High-Speed Internet



3000mAh Battery



Image: LICAEEVEY Portable WiFi Hotspot devices, showcasing Type-C interface, 4G High-Speed Internet, and battery capacity.

SETUP INSTRUCTIONS

1. **Charge the Device:** Before first use, fully charge the hotspot using the provided USB-C cable and a compatible power adapter (not included). The indicator display will show the battery level.
2. **Insert SIM Card:** Locate the SIM card slot. This device uses a **Micro SIM card**. Carefully insert your activated 4G/5G Micro SIM card into the slot until it clicks into place. Ensure the SIM card is inserted correctly according to the diagram on the device or in the quick start guide.
3. **Power On:** Press and hold the power button for a few seconds until the device powers on and the indicator lights illuminate.
4. **Connect to Power (Optional):** For extended usage, connect the device to a USB power source using the USB-C cable.
5. **Initial Configuration (if needed):**
 - The device is designed for plug-and-play operation. However, if you experience connection issues, you may need to manually configure the Access Point Name (APN) settings.
 - Refer to your mobile network provider for the correct APN settings.
 - Access the device's web interface (usually by connecting to its Wi-Fi and navigating to a specific IP address like 192.168.0.1 or 192.168.1.1 in a web browser) to enter the APN details. Consult the device's quick start guide for the exact IP address and default login credentials.



Image: LICAEVEY Portable WiFi Hotspot with USB-C charging cable, showing LED indicators.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Press and hold the power button for approximately 3 seconds to turn the device on or off.
2. **Connect Devices:**
 - On your smartphone, tablet, or laptop, search for available Wi-Fi networks.
 - Select the network name (SSID) displayed on the hotspot's screen or on a sticker inside the battery compartment.
 - Enter the Wi-Fi password (Key) shown on the hotspot's screen or sticker.
 - Up to 10 devices can connect simultaneously.
3. **Monitor Status:** The colorful indicator display provides real-time information:
 - **Signal Strength:** Indicates the strength of the 4G/5G cellular signal.
 - **Wi-Fi Status:** Shows if Wi-Fi is active.
 - **Battery Level:** Displays the current battery charge.
 - **SMS/Notifications:** May indicate new messages or system alerts.

MULTI DEVICE SHARING NOT LAGGING

10 devices can be connected at the same time
Stable connection, not easy to drop
the equipment will not heat



Image: Illustration of multiple devices connected to the hotspot, demonstrating multi-device sharing without lag.

Multi Users



Monitor



Desktop PC



Laptop



Phone

10 devices can be
connected at the same time

Stable connection,
not easy to drop,
the equipment will not heat



Image: Diagram illustrating up to 10 users connecting to the hotspot simultaneously.

MAINTENANCE

- **Charging:** Recharge the device when the battery indicator is low. Use only the provided USB-C cable or a certified equivalent.

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. If storing for a long period, charge the battery to about 50% every few months.

High Performance

High Efficiency, Environmental Protection And
Low Power Consumption 2100mAh Battery,
It can be used continuously for more than 10 hours



Image: Visual representation of the hotspot's 2100mAh battery providing over 10 hours of continuous use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No internet connection	• SIM card not inserted correctly or not activated. • Incorrect APN settings. • No cellular signal in the area. • Data plan exhausted.	• Ensure SIM card is properly inserted and activated with your carrier. • Verify and configure APN settings via the device's web interface (refer to your carrier for correct settings). • Move to an area with better cellular coverage. • Check your data plan status with your carrier.
Slow internet speeds	• Weak cellular signal. • Network congestion. • Too many devices connected.	• Relocate to an area with stronger signal. • Reduce the number of connected devices. • Check with your carrier for network status in your area.
Short battery life	• Battery not fully charged. • High usage (many connected devices, continuous streaming). • Aging battery.	• Ensure the device is fully charged before use. • Reduce the number of connected devices or usage intensity. • Consider replacing the device if battery degradation is significant and it's outside the warranty period.

Problem	Possible Cause	Solution
Device not powering on	- Battery completely drained. - Faulty charging cable or adapter.	- Connect to a power source and allow it to charge for at least 30 minutes before attempting to power on. - Try a different USB-C cable and power adapter.

SPECIFICATIONS

Model Number	LICAEVEYbcnuvaxdp2
Dimensions	11 x 7 x 3 cm
Weight	109 g
Brand	LICAEVEY
Connectivity Technology	5G, LTE, Wi-Fi (4G, 5G protocols)
Data Transfer Rate	Up to 300 Mbps
Wi-Fi Standard	802.11b, 802.11g, 802.11n (Wi-Fi 4)
Frequency Band Class	Dual-Band
Battery Capacity	2100mAh
Supported Devices	Up to 10 (Laptop, Smartphone, Tablet, etc.)
Security Protocol	WPA2-PSK
Operating System	Linux
Recommended Use	Travel/Outdoor
Country of Origin	China

WARRANTY AND SUPPORT

This LICAEVEY Portable 4G/5G WiFi Hotspot comes with a manufacturer warranty of **90 days** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support or warranty inquiries, please contact your retailer or refer to the contact information provided with your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FY9ZMXS5>

More documents and user manuals: <https://manuals.plus/>