

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [XIAOMI](#) /
- › [XIAOMI TV Stick 4K \(2nd Generation\) User Manual](#)

## XIAOMI MDZ-33-AA

# XIAOMI TV Stick 4K (2nd Generation) User Manual

Model: MDZ-33-AA

## INTRODUCTION

The XIAOMI TV Stick 4K (2nd Generation) is a compact streaming media player designed to transform any display with an HDMI port into a smart TV. It offers 4K Ultra HD resolution, Google TV integration, Dolby Vision and Dolby Atmos support, dual-band Wi-Fi 6, and built-in Chromecast for a comprehensive entertainment experience. This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal use of your device.



Image: The XIAOMI TV Stick 4K (2nd Generation) device, showcasing its compact design.

## WHAT'S IN THE BOX

---

Before you begin, please ensure all the following items are present in your package:

- XIAOMI TV Stick 4K (2nd Generation)
- Bluetooth remote control with voice commands
- Power Supply
- USB-C power cable
- HDMI extender

## SETUP GUIDE

---

Follow these steps to set up your XIAOMI TV Stick 4K (2nd Generation):

1. **Connect the TV Stick:** Plug the XIAOMI TV Stick directly into an available HDMI port on your television or display. If space is limited, use the provided HDMI extender.
2. **Connect Power:** Connect the USB-C power cable to the TV Stick and then plug the power supply into a wall outlet. The device will power on automatically.
3. **Pair the Remote Control:** Insert batteries into the Bluetooth remote control. Follow the on-screen instructions to pair the remote with your TV Stick. This usually involves holding down specific buttons on the remote.
4. **Initial Setup:** Your TV will display the Google TV setup screen. Follow the prompts to:
  - Select your language.
  - Connect to your Wi-Fi network. Enter your Wi-Fi password when prompted.
  - Sign in with your Google account. This is required to access Google TV features and download apps.
  - Accept terms and conditions.
5. **Complete Setup:** Once the initial setup is complete, the Google TV home screen will appear, and you can begin installing your favorite streaming applications.




Image: The XIAOMI TV Stick 4K (2nd Generation) plugged into the HDMI port of a television, illustrating its discreet installation.

## OPERATING INSTRUCTIONS

### Navigating Google TV

The Google TV interface organizes all your movies and shows from various apps and subscriptions into one central location. Use the directional pad on your remote to navigate through menus and select content.

### Voice Control with Google Assistant

Your Bluetooth voice remote features a dedicated Google Assistant button. Press this button and speak your commands to find content, launch apps, control smart home devices, or get information. For example, say "Play [Movie Title] on Netflix" or "Show me action movies."




Image: Screenshot of the Google TV interface demonstrating voice search functionality with "action shows" as an example query.

### 4K Ultra HD Streaming

The TV Stick supports 4K decoding, Dolby Vision, and HDR10+ for stunning picture quality. Ensure your TV and streaming content support 4K resolution and HDR technologies for the best viewing experience.

## 4K decoding Ultra-clear visuals

4K decoding provides stunningly clear picture quality for an unbelievable viewing experience.



\*Requires Video streaming content and devices that support 4K.

*Image: A visual comparison demonstrating the clarity of 4K decoding versus Full HD (FHD) for an enhanced viewing experience.*

### **Dolby Atmos and DTS:X Audio**

For an immersive audio experience, the device supports Dolby Atmos and DTS:X panoramic surround sound. Connect your TV Stick to an audio system compatible with these technologies.

### **Integrated Chromecast**

Use the built-in Chromecast to cast content directly from your compatible smartphone, tablet, or computer to your TV. Look for the Cast icon within supported applications.

### **Wi-Fi 6 Connectivity**

The TV Stick features dual-band Wi-Fi 6 for increased bandwidth and faster transmission speeds. For optimal performance, connect to a Wi-Fi 6 compatible router.



## Dual-band Wi-Fi 6

### A high-speed experience

Wi-Fi 6, the latest wireless standard, supports technologies such as OFDMA and MU-MIMO, delivering increased network bandwidth, significantly faster transmission speeds, and seamless instant playback of online videos.

\*Requires connection to a router supporting Wi-Fi 6.

*Image: Graphic illustrating the "Dual-band Wi-Fi 6" feature, highlighting its high-speed capabilities.*

## MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the device. Do not use liquid cleaners or aerosols.
- **Environment:** Keep the TV Stick in a dry environment, away from direct sunlight, high temperatures, and humidity.
- **Software Updates:** Ensure your device's software is up to date. Google TV will typically prompt you for updates, or you can check manually in the settings menu.
- **Power Cycle:** If the device becomes unresponsive, disconnect the power cable, wait 10 seconds, and then reconnect it.

## TROUBLESHOOTING

---

If you encounter issues with your XIAOMI TV Stick 4K (2nd Generation), refer to the following common problems and solutions:

- **No Power/Device Not Turning On:**
  - Ensure the USB-C power cable is securely connected to both the TV Stick and the power adapter.
  - Verify the power adapter is plugged into a working electrical outlet.
  - Try a different power outlet.
- **No Signal/Blank Screen:**
  - Confirm the TV Stick is fully inserted into the HDMI port.
  - Check that your TV is set to the correct HDMI input source.
  - Try a different HDMI port on your TV.
  - If using the HDMI extender, ensure it is securely connected.
- **Remote Control Not Responding:**
  - Replace the batteries in the remote control.

- Ensure there are no obstructions between the remote and the TV Stick.
- Re-pair the remote control by following the instructions in the "Setup Guide" or your device's settings menu.
- **Buffering or Poor Streaming Quality:**
  - Check your internet connection speed.
  - Ensure the TV Stick is within range of your Wi-Fi router.
  - Restart your Wi-Fi router and modem.
  - Close other applications running on the TV Stick that might be consuming bandwidth.
- **Device Shuts Off Immediately After Turning On / Blinking Light:**
  - This can indicate a power issue. Ensure you are using the original power adapter and cable provided with the device.
  - Try plugging the power adapter into a different wall outlet directly, bypassing any power strips or surge protectors.
  - Perform a factory reset if possible (refer to Google TV settings for this option), but only as a last resort as it will erase all data.

## SPECIFICATIONS




Image: Graphic illustrating the 6nm high-performance platform, emphasizing improved CPU and GPU performance.

Feature	Detail
Model Name	MDZ-33-AA
Brand	XIAOMI
Resolution	4K Ultra HD
Operating System	Google TV

Feature	Detail
Processor	2.5GHz quad-core CPU (6nm high-performance platform)
Audio Support	Dolby Atmos, DTS:X
Video Support	Dolby Vision, HDR10+
Connectivity	Dual-band Wi-Fi 6, Bluetooth, HDMI, USB (for power)
Special Features	Integrated Chromecast, Google Assistant Voice Control, Parental Controls
Dimensions	4.2 x 1.16 x 0.66 inches
Weight	0.988 ounces
Color	Black

## WARRANTY INFORMATION

---

XIAOMI products typically come with a limited manufacturer's warranty. For specific details regarding the warranty period, coverage, and terms for your XIAOMI TV Stick 4K (2nd Generation), please refer to the warranty card included in your product packaging or visit the official XIAOMI support website. Keep your proof of purchase for warranty claims.

## CUSTOMER SUPPORT

---

For further assistance, technical support, or service inquiries, please visit the official XIAOMI support website or contact their customer service department. You can usually find contact information on the XIAOMI official website or in your product documentation.

**Online Resources:** <https://www.mi.com/global/support>

When contacting support, please have your product model number (MDZ-33-AA) and serial number ready.