

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HOMCOM](#) /

› [HOMCOM 31.5" Pendant Light Instruction Manual - Model B31-606V80BK](#)

## HOMCOM B31-606V80BK

# HOMCOM 31.5" Pendant Light Instruction Manual

MODEL: B31-606V80BK

## 1. Product Overview

This HOMCOM 31.5" pendant light fixture features a classic steel and wood frame, designed to provide a warm and inviting ambiance. It is suitable for various indoor spaces such as kitchen islands, dining areas, and living rooms.

The fixture includes four independently rotating wood frames and adjustable chains, allowing for customizable height and light patterns.






Image 1.1: HOMCOM 31.5" Pendant Light installed above a kitchen island.

Video 1.1: Product showcase of the HOMCOM B31-606V80ND Pendant Light, highlighting its design and application in various room settings.

## 2. Safety Information

---

- Always turn off the main power supply at the circuit breaker before beginning installation, maintenance, or bulb replacement.
- Ensure all electrical connections are made in accordance with local codes and ordinances. If you are unsure, consult a qualified electrician.
- Do not exceed the maximum wattage specified for the bulbs (40W per E26 socket).
- Handle glass components with care to prevent breakage.
- Keep the fixture away from water and moisture.

## 3. Components List

---

Please ensure all parts are present before beginning assembly.

- Mounting Plate/Canopy
- Adjustable Chains/Rods
- Fixture Body with 4 Rotatable Wood Frames

- E26 Sockets (4x)
- Mounting Hardware (screws, wire nuts, etc.)
- Bulbs (not included)

## 4. Installation Instructions

---

Professional installation is recommended. Follow these steps carefully:

1. **Prepare for Installation:** Turn off power at the circuit breaker. Unpack all components and inspect for any damage.
2. **Attach Mounting Plate:** Secure the mounting plate to the ceiling junction box using the provided screws. Ensure it is firmly attached.



Image 4.1: Illustration of attaching the mounting plate to the ceiling.

3. **Adjust Height:** Determine the desired hanging height. The fixture features adjustable chains/rods (35.4" - 51.2" / 90-130cm). Adjust the length by removing or adding chain links or adjusting the rods as needed.



Image 4.2: The pendant light showing adjustable chains and rotatable frames for customizable ambiance.

- 4. Wire Connections:** Connect the fixture's wires to the household electrical wires (live to live, neutral to neutral, ground to ground) using wire nuts. Ensure all connections are secure.



Image 4.3: Illustration of making electrical wire connections.

5. **Secure Fixture:** Carefully lift the fixture and attach it to the mounting plate, securing it with the canopy screws.
6. **Install Bulbs:** Screw in four E26 base bulbs (max 40W each, not included) into the sockets.



Image 4.4: Close-up view of the E26 sockets and examples of compatible bulb types.

7. **Restore Power:** Once installation is complete, restore power at the circuit breaker and test the light fixture.

## 5. Operating Instructions

- **Turning On/Off:** Operate the light fixture using a standard wall switch connected to the circuit.
- **Adjusting Light Direction:** The four individual wood frames can be independently rotated to direct light as desired, allowing for varied lighting patterns and ambiance.
- **Bulb Compatibility:** This fixture is compatible with LED, halogen, A19, or ST64 bulbs with an E26 base, up to 40W per socket.

## 6. Maintenance

- **Cleaning:** To clean the fixture, ensure the power is off. Use a soft, dry cloth to wipe down the metal and wood surfaces. Avoid abrasive cleaners or solvents that may damage the finish.
- **Bulb Replacement:** Turn off power before replacing bulbs. Allow old bulbs to cool completely before removing. Replace with E26 base bulbs, not exceeding 40W.

- **Regular Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

## 7. Troubleshooting

- **Light does not turn on:**
  - Check the circuit breaker to ensure power is on.
  - Verify that bulbs are correctly installed and not burnt out.
  - Ensure all wire connections are secure.
- **Flickering lights:**
  - Ensure bulbs are fully screwed into sockets.
  - Check for loose wire connections.
  - If using dimmable bulbs, ensure they are compatible with your dimmer switch.

## 8. Specifications

Feature	Specification
Brand	HOMCOM
Model Number	B31-606V80BK
Overall Dimensions	31.5" L x 8.3" W x 35.4" - 51.2" H (80 x 21 x 90-130 cm)
Material	Alloy Steel, Wood
Number of Lights	4
Bulb Base	E26
Max Wattage per Bulb	40W
Voltage	110-130V (implied from E26 socket compatibility)
Power Source	Corded Electric
Net Weight	2.59 kg (approx. 5.7 lbs)
Room Type	Dining Room, Kitchen Island, Living Room, Hallway




Image 8.1: Detailed dimensions of the pendant light fixture.

## 9. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact HOMCOM customer service directly. Keep your proof of purchase for any warranty claims.

You can visit the [HOMCOM Store on Amazon](#) for more products and information.