

SHOKZ OpenFit Pro

SHOKZ OpenFit Pro True Wireless Earbuds Instruction Manual

Model: OpenFit Pro (SHOKZ T010)

1. INTRODUCTION

Thank you for choosing the SHOKZ OpenFit Pro True Wireless Earbuds. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it carefully to ensure optimal performance and longevity of your earbuds.

2. WHAT'S IN THE BOX

- OpenFit Pro True Wireless Earbuds
- Charging Case
- USB-C Charging Cable
- User Guide, Legal Statement, Warranty Card, Card Holder, Support Accessories
- App Card



Image: Contents of the OpenFit Pro package, showing the earbuds, charging case, USB-C cable, and various accessories.

3. PRODUCT OVERVIEW

The SHOKZ OpenFit Pro earbuds feature an open-ear design for comfort and situational awareness, powered by Shokz SuperBoost for rich audio. They are optimized for Dolby Atmos with head tracking and include innovative



Image: A pair of SHOKZ OpenFit Pro earbuds next to their charging case, highlighting their sleek design.

Key Features:

- **True-to-life audio:** Optimized for Dolby Atmos with head tracking, featuring Shokz SuperBoost and an 11 × 20 mm dual-diaphragm driver. DirectPitch 3.0 reduces sound leakage.
- **Secure Fit, All-Day Comfort:** Flexible nickel-titanium alloy ear hooks and Shokz Ultra-Soft Silicone 2.0 for a gentle, secure fit.
- **AI-Optimized Call Clarity:** Triple-mic system with AI voice recognition and wind-control technology for clear calls.
- **Innovative Open-Ear Noise Reduction:** Ear-adaptive algorithm for consistent noise reduction, with 5 EQ presets and custom profiles.
- **Long Battery Life:** Up to 50 hours total playtime with charging case, 12 hours on a single charge (NR off), 6 hours (NR on). Quick 10-minute charge provides 4 hours of playtime.
- **Durable Design:** IP55-rated for sweat, splashes, and dust resistance. Features physical buttons and wear detection.

4. SETUP

4.1 Bluetooth Connection

1. Place both earbuds into the charging case and open the lid.
2. Press and hold the button inside the charging case for 3 seconds until the LED flashes orange and green, indicating pairing mode.
3. On your mobile device, go to Bluetooth settings and ensure Bluetooth is enabled.
4. Select "OpenFit Pro by Shokz" from the list of available devices.
5. A message will confirm successful pairing.

Video: Instructions on how to establish a Bluetooth connection with your SHOKZ OpenFit Pro earbuds.

4.2 Wearing the Earbuds

1. Remove the earbuds from the charging case.
2. Place them over your ears, ensuring the SHOKZ logo side is facing outwards.
3. Rotate the earbuds back along your ears until they fit securely. You can shake your head slightly to check for

security and adjust as needed for comfort.

4. For additional support, attach the stability accessories to the ear hooks if desired.

Video: Guide on how to correctly wear your SHOKZ OpenFit Pro earbuds for a secure and comfortable fit.

4.3 Head Tracking Calibration (for Dolby Atmos)

For the best spatial audio experience with Dolby Atmos, calibrate head tracking before first use:

1. **Horizontal calibration:** Look straight ahead for 5 seconds.
2. **Vertical calibration:** Look down at least 40 degrees.
3. **Horizontal calibration:** Look straight ahead for 3 seconds.

Video: Instructions on how to optimize your SHOKZ OpenFit Pro for Dolby Atmos, including head tracking calibration.

5. OPERATING INSTRUCTIONS

5.1 Music Control

- **Play/Pause:** Press either earbud button once.
- **Skip Song:** Press either earbud button twice.
- **Previous Song:** Press either earbud button three times.

5.2 Call Control

- **Answer Incoming Call:** Press either earbud button once.
- **Reject Incoming Call:** Press either earbud button twice.
- **End Call:** Press either earbud button once.

5.3 Volume Control

- **Volume Down (Left Earbud):** Press the left earbud button once, then long-press (1s). Continue pressing to decrease volume gradually.
- **Volume Up (Right Earbud):** Press the right earbud button once, then long-press (1s). Continue pressing to increase volume gradually.

Video: Detailed instructions on how to control music playback, calls, and volume using the physical buttons on your SHOKZ OpenFit Pro earbuds.

5.4 Noise Reduction

To activate or deactivate noise reduction:

1. Long-press the button on either earbud. When turning on, you will hear two tones; release the button after the first tone.
2. Noise reduction requires both earbuds to be worn and is not available when using only one earbud.

Adjust noise reduction levels in the Shokz App using the slider to find the ideal setting for your surroundings.

Video: Guide on how to activate and adjust the noise reduction feature on your SHOKZ OpenFit Pro earbuds.

5.5 Shokz App Features

The Shokz App allows you to customize your listening experience:

- Check battery levels for earbuds and charging case.

- Choose from various EQ modes and enable "Optimized for Dolby Atmos."
- Adjust Open-Ear Noise Reduction settings.
- Customize button functions.

Video: Instructions on how to connect to and utilize the features of the Shokz App for your OpenFit Pro earbuds.

6. CHARGING

To charge your OpenFit Pro earbuds:

1. Place the earbuds into the charging case and shut the lid. Ensure they are securely magnetically attached. The indicator light will turn on.
2. The earbuds will start charging automatically. It takes approximately 70 minutes to fully charge the earbuds in the case.
3. For wired charging of a drained charging case and earbuds, connect the USB-C cable. This takes approximately 120 minutes.
4. The OpenFit Pro charging case also supports wireless charging. For best results, use a Qi-certified wireless charger. Fully charging a drained case and earbuds wirelessly takes approximately 180 minutes.

The LED on the charging case indicates battery level: orange for low battery, green for high battery. When charging, the LED will be solid orange and turn solid green once fully charged.

Video: Instructions on how to charge your SHOKZ OpenFit Pro earbuds using both wired and wireless methods.



Image: The SHOKZ OpenFit Pro charging case placed on a wireless charging pad, illustrating its wireless charging capability.

7. MAINTENANCE

Regular cleaning of your OpenFit Pro earbuds and charging case is crucial to prevent dirt or debris from affecting charging efficiency and proper function.

7.1 Cleaning the Charging Case

1. Use a pointed cotton swab with rubbing alcohol or water to clean the metal charging pins inside the case.
2. Wipe dry with a microfiber cloth to remove any excess liquid.

7.2 Cleaning the Earbuds

1. Wipe the metal contacts on the bottom of the earbuds with a microfiber cloth.
2. Ensure the earbuds are completely dry before placing them back into the charging case.
3. If the charging contacts are dirty, clean them promptly to ensure a proper connection.

**Do not bend or twist the earbuds during cleaning.*

Video: A step-by-step guide on how to properly clean your SHOKZ OpenFit Pro earbuds and their charging case.



Image: SHOKZ OpenFit Pro earbuds shown with water droplets, emphasizing their IP55 water and dust resistance.

8. TROUBLESHOOTING

8.1 Resetting the Earbuds

If you experience connectivity issues or other malfunctions, you may need to reset your earbuds:

1. Place both earbuds into the charging case.
2. Press and hold the charging case button for 15 seconds.
3. Wait until the orange LED light flashes for 5 seconds, indicating the reset is complete.

Video: [Instructions on how to reset your SHOKZ OpenFit Pro earbuds to resolve potential issues.](#)

9. SPECIFICATIONS

Feature	Specification
Brand	SHOKZ
Model Name	OpenFit Pro
Model Number	SHOKZ T010
Color	Black
Ear Placement	Open Ear
Noise Control	Environmental Noise Cancellation
Bluetooth Version	6.1
Bluetooth Range	33 Feet
Battery Average Life (Earbuds)	7 Hours
Total Playtime (with Case)	Up to 50 Hours
Water Resistance Level	IP55 (Water Resistant)
Control Method	Touch, Physical Buttons
Item Weight	99.3 Grams
Compatible Devices	Android, Mac, PC, Watch, iPhone

10. WARRANTY AND SUPPORT

The SHOKZ OpenFit Pro comes with a **2-year warranty**. For any support needs, please refer to the contact information provided in your Warranty Card or visit the official SHOKZ website.

Each item has a unique code that we verify before shipping, ensuring product authenticity.